

POINT I/O Digital and Analog Modules and POINTBlock I/O Modules

Catalog Numbers 1734-IA2, 1734-IA4, 1734-IA4K, 1734-IB2, 1734-IB4, 1734-IB4K, 1734-IB8, 1734-IB8K, 1734-IB4D, 1734-IM2, 1734-IM4, 1734-IV2, 1734-IV4, 1734-IV8, 1734-IV8K, 1734-OA2, 1734-OA4, 1734-OA4K, 1734-OB2, 1734-OB2EP, 1734-OB2E, 1734-OB4K, 1734-OB4K, 1734-OB4E, 1734-OB8K, 1734-OB8EK, 1734-OB2EK, 1734-OV2E, 1734-OV4E, 1734-OV8E, 1734-OV8EK, 1734-OW2E, 1734-OW4K, 1734-OW2C, 1734-OW4K, 1734-OX2, 1734-IE2C, 1734-IE2CK, 1734-IE2V, 1734-OE2C, 1734-OE2CK, 1734-OE2VK, 1734-OE2VK, 1734D-IA16, 1734D-IA8XOA8, 1734D-IA8XOW8, 1734D-IB16, 1734D-IB8XOB8E, 1734D-IB8XOW8



by **ROCKWELL AUTOMATION**

User Manual

Original Instructions

Important User Information

Read this document and the documents listed in the additional resources section about installation, configuration, and operation of this equipment before you install, configure, operate, or maintain this product. Users are required to familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.

Activities including installation, adjustments, putting into service, use, assembly, disassembly, and maintenance are required to be carried out by suitably trained personnel in accordance with applicable code of practice.

If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



WARNING: Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.

IMPORTANT Identifies information that is critical for successful application and understanding of the product.

These labels may also be on or inside the equipment to provide specific precautions.



SHOCK HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



BURN HAZARD: Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.

ARC FLASH HAZARD: Labels may be on or inside the equipment, for example, a motor control center, to alert people to potential Arc Flash. Arc Flash will cause severe injury or death. Wear proper Personal Protective Equipment (PPE). Follow ALL Regulatory requirements for safe work practices and for Personal Protective Equipment (PPE).

The following icon may appear in the text of this document.



Identifies information that is useful and can help to make a process easier to do or easier to understand.

Rockwell Automation recognizes that some of the terms that are currently used in our industry and in this publication are not in alignment with the movement toward inclusive language in technology. We are proactively collaborating with industry peers to find alternatives to such terms and making changes to our products and content. Please excuse the use of such terms in our content while we implement these changes.

Preface

About T	is Publication	7
Who Sh	uld Use This Manual	7
Summa	y of Changes	7
Additio	al Resources	8

About the Modules

Chapter 1

Digital Modules	. 11
Input Modules	. 11
Output Modules	. 12
Relay Output Modules	. 12
Analog Modules	. 13
Input Modules	. 13
Output Modules	. 14
Specialty Modules	. 14
Power Supplies, Wiring Base Assemblies, and Miscellaneous Modules	. 14
Secure Access to the System	. 14

Chapter 2

Use the Help Button	17
Configure Digital Modules	17
About Fault/Program Action and Configuration Dialogs	19
Understand Data and Connection Formats	19
Understand Transition to Hard Run Behavior	20
Work with Dialogs for Digital Input Modules	20
Work with Dialogs for Digital Output Modules	21
Configure Analog Modules	24
Understand Data and Connection Formats	25
Work with Dialogs for Analog Input Modules	25
Work with Dialogs for Analog Output Modules	29

Configure POI DeviceNet Net

Configure POINT I/O Modules

Using Studio 5000 Logix **Designer Application**

Chapter 3

NT I/O Modules for	Commissioning a Node	35
tworks	Using the RSNetWorx Commissioning Tool	35
	Use Sequential Auto Addressing	
	Using Third-party Configuration Software.	
	Configure Digital Modules Using RSNetWorx Software	
	Configure Analog Modules Using RSNetWorx Software	47

Chapter 4

POINT I/O Module Data	Digital Input Modules	53
	Digital DC Input Modules.	. 53
	Digital AC Input Modules	. 55
	Digital Output Modules	55

Digital DC Output Modules	55
Digital AC Output Modules	57
Relay Output Modules	57
Analog Input Modules	
Data	
Communicate with Your Module	
Scaling	
Channel Status	
Latch Alarms	
Alarm Disable	
Calibration Status	
Digital Filter	61
Update Rate	61
Notch Filter	61
Alarms	61
Range Status	62
Channel Indicator Behavior	62
Analog Output Modules	62
Data	62
Operational Modes	63
Scaling	64
Fault and Idle/Program Mode Action	64
Channel Status	64
Low and High Clamps	65
Latch Alarms	65
Alarm Disable	65
Channel Indicators	
POINTBlock I/O Modules	66
Chapter 5	

Calibrate Your Analog Modules

Troubleshoot with the Indicators

Chapter 5

Tools Required to Calibrate Your Analog Modules	. 71
Calibrate the Analog Current Input Module	. 72
Calibrate the Analog Current Output Module	. 75
Calibrate the Analog Voltage Input Module	. 79
Calibrate the Analog Voltage Output Module	. 82

Chapter 6

1734-IA2, 1734-IA4, 1734-IA4K 120V AC Input Module	93
1734-0A2, 1734-0A4, 1734-0A4K 120/220V AC Output Module	94
1734-IM2, 1734-IM4 220V AC Input Module	94
Troubleshoot Analog Modules	95
1734-IE2C, 1734-IE2CK Analog Current Input Module	95
1734-0E2C, 1734-0E2CK Analog Current Output Module	95
1734-IE2V, 1734-IE2VK Analog Voltage Input Module	96
1734-0E2V, 1734-0E2VK Analog Voltage Output Module	97
Troubleshoot I/O Communication Modules	
1734-PDN DeviceNet Communication Interface Module	97
1734-ADN, 1734-ADNX DeviceNet Adapter	98
1734-ACNR ControlNet Adapter	100
1734-APB PROFIBUS Adapter	102
1734-AENT EtherNet/IP Adapter	103
•	

Appendix A

	••	
	Digital Module Default Data Maps	105
	1734-IB2 Sink Input Module	105
	1734-IB4, 1734-IB4K Sink Input Module	106
	1734-IB8, 1734-IB8K Sink Input Module	106
	1734-IB4D Sink Input Module with Diagnostics	106
	1734-IV2 Source Input Module	107
	1734-IV4 Source Input Module	107
	1734-IV8, 1734-IV8K Source Input Module	107
	1734-IA2 Input Module	107
	1734-1A4, 1734-1A4K Input Module	107
	1734-IM2 Input Module	108
	1734-IM4 Input Module	108
	1734-0A2 Output Module	108
	1734-0A4, 1734-0A4K Output Module	108
	1734-0B2E, 1734-0B2 Electronically Protected Output Module	108
	1734-0B4E, 1734-0B4, 1734-0B4K Electronically Protected Output Module .	109
	1734-0B8E, 1734-0B8EK, 1734-0B8, 1734-0B8K Electronically Protected Out	put
	Module	109
	1734-OB2EP Protected Output Module	110
	1734-0V2E Output Module	110
	1734-0V4E Output Module	110
	1734-0V8E, 1734-0V8EK Output Module	110
	1734-OW2 Relay Sink/Source Output Module	111
	1734-0W4, 1734-0W4K Relay Sink/Source Output Module	111
	1734-0X2 Relay Output Module	111
I	Analog Module Default Data Maps	111
	1734-IE2C, 1734-IE2CK Analog Current Input Module	111
	1734-IE2V Analog Voltage Input Module	112
	1734-0E2C, 1734-0E2CK Analog Current Output Module	112
	1734-NF2V. 1734-NF2VK Analog Voltage Output Module	112
		••••

Default Data Maps

Mounting Dimensions

Appendix B

POINT I/O Module with a 1734-ADN, 1734-ACNR, 1734-AENT, or 1734-APB Adapter	113
POINT I/O Module with a 1734-PDN Module	114
POINTBlock Module	115

 	 	 	117
•••••	 	 	

About This Publication

This manual describes how to configure, calibrate, and troubleshoot your POINT I/O™ modules.

The POINT I/O modules in this manual are DeviceNet[®] ready. Each module can exist on the DeviceNet network as one of the following:

- As an individual node
- With an adapter (catalog number 1734-ADN or 1734-ADNX) as a single node

Table 1 - Adapter User Manual Reference Based On Network Type You Use

When you use these POINT I/O modules with an adapter, use this manual with the user manual of the adapter which you are using. See <u>Table 1</u> for user manual reference of your adapter.

When You Use POINT I/O Modules on This Network	See the User Manual for	Catalog Number	Publication Number
DeviceNet network	DeviceNet adapter	1734-ADN 1734-ADNX	<u>1734-UM002</u>
ControlNet® network	ControlNet adapter	1734-ACNR	<u>1734-UM008</u>
EtherNet/IP™ network	EtherNet/IP adapter	1734-AENT	<u>1734-UM011</u>
EtherNet/IP network	EtherNet/IP adapter	1734-AENTR	<u>1734-UM017</u>
PROFIBUS network	PROFIBUS adapter	1734-APB	<u>1734-UM005</u>

For applications that use these modules in a network with a 1734-PDN DeviceNet communication interface, or a 1734D-xx POINTBlock I/O module, this user manual is the primary documentation.

Who Should Use This Manual

This manual is intended for qualified personnel. We assume that:

- You know how to use the software RSNetWorx[™] for DeviceNet and Studio 5000 Logix Designer[®] application⁽¹⁾ for ControlNet and EtherNet/IP networks or similar configuration software to set up and calibrate these modules.
- You have the capability to download and use electronic data sheet (EDS) files.

If you do not qualify, see your software documentation or online help before attempting to use these modules.

Summary of Changes

This publication contains the following new or updated information. This list includes substantive updates only and is not intended to reflect all changes.

Торіс	Page
Updated template	Throughout
Added Inclusive Language acknowledgment	Important User Info
Added catalog numbers that ends with letter K	Throughout
Updated Additional Resources	8
Added topic Secure Access to the System	14 and 15
Removed chapters Install POINT I/O Modules and Install POINTBlock I/O Modules	-

⁽¹⁾ The Studio 5000 Logix Designer application is the rebranding of RSLogix 5000° software version 11 or later and will continue to be the product to program Logix 5000° controllers for discrete, process, batch, motion, safety, and drive-based solutions.

Additional Resources

These documents contain additional information concerning related products from Rockwell Automation. You can view or download publications at <u>rok.auto/literature</u>.

Additional Resources

Resource	Description
Analog Modules	1
POINT I/O 2 Current and 2 Voltage Input Analog Modules Installation Instructions, publication <u>1734-INO27</u>	Provides installation information for 2 current and 2 voltage input analog modules.
POINT I/O 2 Current Output and 2 Voltage Output Analog Modules Installation Instructions, publication <u>1734-INOO2</u>	Provides installation information for 2 current output and 2 voltage output analog modules.
Communication Devices	·
POINT I/O ControlNet Adapter Installation Instructions, publication <u>1734-IN582</u>	Provides installation information for ControlNet adapters.
POINT I/O ControlNet Adapter User Manual, publication <u>1734-UM008</u>	Describes how to configure and troubleshoot your ControlNet adapters.
POINT I/O DeviceNet Communication Interface Module Installation Instructions, publication <u>1734-IN057</u>	Provides installation information for DeviceNet communication interface modules.
POINT I/O DeviceNet Adapter Installation Instructions, publication <u>1734-IN026</u>	Provides installation information for DeviceNet adapters.
POINT I/O DeviceNet Adapter User Manual, publication <u>1734-UM002</u>	Describes how to install, configure, and troubleshoot your DeviceNet adapters.
POINT I/O EtherNet/IP Adapter Installation Instructions, publication <u>1734-IN590</u>	Provides installation information for EtherNet/IP adapters.
POINT I/O EtherNet/IP Adapter User Manual, publication <u>1734-UM011</u>	Describes how to install, configure, and troubleshoot your EtherNet/IP adapters.
POINT I/O and ArmorPOINT I/O Dual-port EtherNet/IP Adapters User Manual, publication <u>1734-UM017</u>	Describes how to configure and troubleshoot your dual-port EtherNet/IP adapters.
POINT I/O PROFIBUS Adapter Installation Instructions, publication 1734-IN014	Provides installation information for PROFIBUS adapters.
POINT I/O PROFIBUS Adapter Module User Manual, publication <u>1734-UM005</u>	Describes how to install, configure, and troubleshoot your PROFIBUS adapters.
POINT I/O Dual Port EtherNet/IP Adapter Installation Instructions, publication <u>1734-INO41</u>	Provides installation information for dual port EtherNet/IP adapter.
POINT I/O EtherNet/IP Adapter Installation Instructions, publication <u>1734-IN042</u>	Provides installation information for EtherNet/IP adapter.
Digital AC Input Modules	
POINT I/O 220V AC Input Modules Installation Instructions, publication <u>1734-IN008</u>	Provides installation information for 220V AC input modules.
POINT I/O 120V AC Input Modules Installation Instructions, publication <u>1734-IN010</u>	Provides installation information for 120V AC input modules.
Digital AC Output Modules	
POINT I/O 120V and 220V AC Output Modules Installation Instructions, publication <u>1734-IN009</u>	Provides installation information for 120V and 220V AC output modules.
Digital DC Input Modules	·
POINT I/O Input Modules Installation Instructions, publication <u>1734-IN051</u>	Provides installation information for DC input modules.
POINT I/O Source Input Modules Installation Instructions, publication <u>1734-IN052</u>	Provides installation information for source input modules.
Digital DC Output Modules	·
POINT I/O Protected Output Module Installation Instructions, publication <u>1734-IN586</u>	Provides installation information for the protected output module.
POINT I/O Protected Sink Output Modules Installation Instructions, publication <u>1734-1N585</u>	Provides installation information for protected sink output modules.
POINT I/O Protected Output Module Installation Instructions, publication <u>1734-IN056</u>	Provides installation information for the protected source output module.
POINT I/O Output Modules Installation Instructions, publication <u>1734-IN018</u>	Provides installation information for source output modules.
POINTBlock Modules	
POINTBlock AC 8 Input/8 Output Module Installation Instructions, publication <u>1734-IN022</u>	Provides installation information for AC 8 input/8 output module.
POINTBlock AC 8 Input/8 Relay Output Module Installation Instructions, publication <u>1734-INO23</u>	Provides installation information for AC 8 input/8 relay output module.
POINTBlock DC 8 Input/8 Output Module Installation Instructions, publication <u>1734-INO20</u>	Provides installation information for DC 8 input/8 output module.
POINTBlock DC 8 Input/8 Relay Output Module Installation Instructions, publication <u>1734-INO21</u>	Provides installation information for DC 8 input/8 relay output module.
POINTBlock AC 16 Input Module Installation Instructions, publication <u>1734D-IN001</u>	Provides installation information for AC 16 input module.
POINTBlock DC 16 Input Module Installation Instructions, publication <u>1734D-1N002</u>	Provides installation information for DC 16 input module.
Relay Modules	
POINT I/O 2 and 4 Relay Output Modules Installation Instructions, publication <u>1734-1N055</u>	Provides installation information for 2 and 4 relay output modules.
POINT I/O 2 Relay Output Module Installation Instructions, publication 1734-IN587	Provides installation information for 2 relay output module.

Additional Resources (Continued)

Resource	Description
Specialty Modules	
POINT I/O 5V and 24V Encoder/Counter Modules Installation Instructions, publication <u>1734-IN005</u>	Provides installation information for 5V and 24V encoder/counter modules.
POINT I/O Encoder/Counter Modules User Manual, publication <u>1734-UM006</u>	Describes how to configure and troubleshoot your encoder/counter modules.
POINT I/O 5V DC and 24V DC Very High Speed Counter Module Installation Instructions, publication $\underline{1734IN003}$	Provides installation information for 5V DC and 24V DC very high speed counter module.
POINT I/O Very High-speed Counter Modules User Manual, publication <u>1734-UM003</u>	Describes how to use, configure, and troubleshoot your very high-speed counter modules.
POINT I/O Address Reserve Module Installation Instructions, publication <u>1734-IN019</u>	Provides installation information for the address reserve module.
POINT I/O RS-232 and RS-485 ASCII Modules Installation Instructions, publication <u>1734-IN588</u>	Provides installation information for RS-232 and RS-485 ASCII modules.
POINT I/O ASCII Modules User Manual, publication <u>1734-UM009</u>	Describes how to use, configure, and troubleshoot your modules.
POINT I/O RTD and Isolated Thermocouple Input Modules Installation Instructions, publication <u>1734-IN011</u>	Provides installation information for RTD and isolated thermocouple input modules.
POINT I/O Thermocouple and RTD Modules User Manual, publication <u>1734-UM004</u>	Describes how to use, configure, and troubleshoot your modules.
POINT I/O Synchronous Serial Interface Absolute Encoder Module Installation Instructions, publication <u>1734-IN581</u>	Provides installation information for synchronous serial interface encoder modules
POINT I/O Synchronous Serial Interface Absolute Encoder Module User Manual, publication <u>1734-UM007</u>	Describes how to use, configure, and troubleshoot your modules.
Power Supplies, Wiring Base Assemblies, and Miscellaneous	
POINT I/O Cold Junction Compensation Wiring Base Assembly Installation Instructions, publication <u>1734-IN583</u>	Provides installation information for cold junction compensation wiring base assembly.
POINT I/O Field Potential Distributor Module Installation Instructions, publication <u>1734-IN059</u>	Provides installation information for field potential distributor module.
POINT I/O 24V DC Expansion Power Supply Installation Instructions, publication <u>1734-IN058</u>	Provides installation information for 24V DC expansion power supply modules.
POINT I/O 12O/24OV AC Expansion Power Supply Installation Instructions, publication <u>1734-IN017</u>	Provides installation information for I/O 12O/24OV AC expansion power supply modules.
POINT I/O Common Terminal Module and Voltage Terminal Module Installation Instructions, publication <u>1734-IN024</u>	Provides installation information for common terminal module and voltage terminal module.
POINT I/O Wiring Base Assembly Installation Instructions, publication <u>1734-IN511</u>	Provides installation information for wiring base assemblies 1734-TB and 1734-TBS.
POINT I/O Wiring Base Assembly Installation Instructions, publication <u>1734-IN013</u>	Provides installation information for wiring base assemblies 1734-TB3, 1734-TB3S, 1734-RTB3, 1734-RTB3, and 1734-RTB3S.
POINT I/O One-piece Terminal Bases Installation Instructions, publication <u>1734-IN028</u>	Provides installation information for one-piece terminal bases.
General	
Ethernet Reference Manual, publication ENET-RM002	Describes basic Ethernet concepts, infrastructure components, and infrastructure features.
System Security Design Guidelines Reference Manual, publication <u>SECURE-RM001</u>	Provides guidance on how to conduct security assessments, implement Rockwell Automation products in a secure system, harden the control system, manage user access, and dispose of equipment.
Industrial Components Preventive Maintenance, Enclosures, and Contact Ratings Specifications, publication <u>IC-TD002</u>	Provides a quick reference tool for Allen-Bradley industrial automation controls and assemblies.
Safety Guidelines for the Application, Installation, and Maintenance of Solid-state Control, publication <u>SGI-1.1</u>	Designed to harmonize with NEMA Standards Publication No. ICS 1.1-1987 and provides general guidelines for the application, installation, and maintenance of solid-state control in the form of individual devices or packaged assemblies incorporating solid-state components.
Industrial Automation Wiring and Grounding Guidelines, publication <u>1770-4.1</u>	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certifications website, rok.auto/certifications	Provides declarations of conformity, certificates, and other certification details.

Notes:

About the Modules

This chapter introduces the following POINT I/O and related modules:

- Digital modules
- Relay output modules
- Analog modules
- Specialty modules
- Power supplies, wiring base assemblies, and miscellaneous modules

Digital Modules

Table 2 - POINT I/O Digital Modules

Digital Module Description	Catalog Number
2, 4, and 8 sink input modules	1734-IB2, 1734-IB4, 1734-IB4K, 1734-IB8, 1734-IB8K, 1734-IB4D
2, 4, and 8 source input modules	1734-IV2, 1734-IV4, 1734-IV8, 1734-IV8K
2, 4, and 8 sink output modules	1734-0V2E, 1734-0V4E, 1734-0V8E, 1734-0V8EK
2, 4, and 8 protected source output modules	1734-0B2, 1734-0B4, 1734-0B4K, 1734-0B8, 1734-0B8K, 1734-0B2E, 1734-0B4E, 1734-0B8E, 1734-0B8EK
2 protected source output modules	1734-0B2EP
2 and 4 relay output modules	1734-0W2, 1734-0W4, 1734-0W4K
2 relay output modules	1734-0X2
2 and 4 120/220V AC output modules	1734-0A2, 1734-0A4, 1734-0A4K
2 and 4 120V AC input modules	1734-IA2, 1734-IA4, 1734-IA4K
2 and 4 220V AC input modules	1734-IM2, 1734-IM4

Table 3 - POINTBlock Modules

POINTBlock Module Description	Catalog Number
8 AC input and 8 AC output modules	1734D-IA8XOA8, 1734-IA8XOA8S
8 AC input and 8 relay output modules	1734D-IA8XOW8, 1734-IA8XOW8S
8 DC input and 8 DC output modules	1734D-IB8X0B8E, 1734-IB8X0B8ES
8 DC input and 8 relay output modules	1734D-IB8X0W8, 1734-IB8X0W8S
16 AC input modules	1734D-IA16, 1734-IA16S
16 DC input modules	1734D-IB16, 1734-IB16S

Input Modules

For DC input modules, the DC inputs are 24V DC nominal with an input range of 10...28.8V DC, and are offered with 2, 4, or 8 sinking/sourcing style inputs.

- Sinking input modules 1734-IB2, 1734-IB4, 1734-IB4D, and 1734-IB8
- Sourcing input modules 1734-IV2, 1734-IV4, and 1734-IV8

For AC input modules, the AC inputs are 120V AC nominal with an input range of 85...132V AC, or 220V AC nominal with an input range of 159...264V AC, and offered with sinking inputs.

The features of all input modules are as follows:

- Autobaud (matches the communication rate of existing devices on the network)
- Selectable input filter times (0...65 ms with 1 ms default)
- Sequential auto addressing

Output Modules

The 1734-0B2, 1734-0B4, 1734-0B8, 1734-0B2E, 1734-0B4E, and 1734-0B8E DC output modules have current limited sourcing outputs, which source a positive voltage of up to 1 A with respect to their DC return per channel. The 1734-0B2EP sources a positive voltage of up to 2 A with respect to its DC return per channel. The outputs are not isolated from each other. For these modules, DC outputs are 24V DC nominal, with a range of 10...28.8V DC. A number of output diagnostic features are incorporated to assist in troubleshooting.

The features of 1734-0B2E, 1734-0B2EP, 1734-0B4E, and 1734-0B8E modules are:

- Output diagnostics (short circuit and wire-off indication and reporting bits per channel)
- Current limited outputs
- Autobaud (matches the communication rate of existing devices on the network)
- Sequential auto addressing

The 1734-0V2E, 1734-0V4E, and 1734-0V8E modules are protected sink output modules protected to 1 A. The outputs are not isolated from each other. For these modules, DC outputs are 24V DC nominal, with a range of 10...28.8V DC. A number of output diagnostic features are incorporated to assist in troubleshooting. The 1734-0V2E, 1734-0V4E, and 1734-0V8E modules have no wire-off indication.

The features of 1734-0V2E, 1734-0V4E, and 1734-0V8E modules are:

- Output diagnostics (short circuit and reporting bits per channel)
- Current limited outputs
- Autobaud (matches the communication rate of existing devices on the network)
- Sequential auto addressing

The 1734-0A2 and 1734-0A4 AC output modules have sourcing outputs, which source a voltage of up to 0.75 A per channel. The outputs are not isolated from each other. For this module, AC outputs are 120/220V AC nominal, with a range of 74...264V AC.

The features of 1734-0A2 and 1734-0A4 modules are:

- Autobaud (matches the communication rate of existing devices on the network)
- Sequential auto addressing

Relay Output Modules

The two versions of relay modules are:

- 1734-0W2 and 1734-0W4 relay module
- 1734-0X2 relay module

The 1734-OW2 and 1734-OW4 relay outputs are Type A (Normally Open), the 1734-OX2 relay outputs are Type 2 Form C. Both modules outputs sink or source current with respect to power or return. Contact outputs are isolated from each other. Each output is rated 5...240V rms at 2 A (current is load-dependent).

The features of these modules are:

- Autobaud (matches the communication rate of existing devices on the network)
- Sequential auto addressing

Analog Modules

The 1734 analog modules consist of input modules (1734-IE2C and 1734-IE2V) and output modules (1734-0E2C and 1734-0E2V). Each module has two single-ended, non-isolated channels.

Catalog Number	Module Type	Number of Channels	Resolution
1734-IE2C, 1734-IE2CK	Analog Input	2	16 bits across 021 mA
1734-IE2V	Analog Input	2	15 bits plus sign across -10+10V
1734-0E2C, 1734-0E2CK	Analog Output	2	13 bits across 021 mA
1734-0E2V, 1734-0E2VK	Analog Output	2	14 bits across -10+10V

The features of the analog modules depend on the type of analog module (input or output). The features that are common to both input and output modules are:

• Data - The current input and output modules operate in unipolar mode only. The voltage input and output modules operate in unipolar or bipolar modes. You can scale the data returned from the module to any 16 bit signed integer (-32,768...+32,767).

Input modules produce 6 bytes of data:

- Channel O Data (2 bytes)
- Channel 1 Data (2 bytes)
- Channel O Status (1 byte)
- Channel 1 Status (1 byte)

Output modules consume 4 bytes of data:

- Channel O Data (2 bytes)
- Channel 1 Data (2 bytes)

Output modules produce 2 bytes of data:

- Channel O Status (1 byte)
- Channel 1 Status (1 byte)
- Operational modes (current and voltage)
 - Current Two modes
 - 0...20 mA
 - 4...20 mA (default mode)
 - Voltage Two modes
 - 0...10V (default mode)
 - -10...+10V
- Individually set channel mode
- Scaling Conversion to engineering units

Input Modules

The following features are available in the input modules:

- Latching alarms, when set, latch low and high-alarm status information. Available alarms include:
 - Low
 - Low Low
 - High
 - High High
- Disable alarms Disables all channel alarms and faults so they are not reported in the channel status field. Four different alarms are available.
- Settable update rate determines how often an input channel is scanned.

- Notch filter is selectable for both inputs (50 Hz, 60 Hz, 250 Hz, and 500 Hz).
- Digital filter sets a time constant.

Output Modules

The following features are available in the output modules:

- Latching alarms, when set, latch low and high clamp alarm status information.
- Low and high clamps can be set individually or on a channel basis. When the output value reaches clamp value, a status bit is set, indicating the output is clamped.
- Disable alarms Disables all channel alarms and faults so that they are not reported in the channel status field.
- Fault and Idle mode action let you select what happens to the output if a fault occurs or if the module is in Idle mode. The choices are the following:
 - Hold Last State
 - Low Clamp
 - High Clamp
 - User-defined value

Specialty Modules

For more information about the following POINT I/O specialty modules, see the installation instructions and user manuals listed in <u>Additional Resources on page 8</u>.

Module Description	Catalog Number
5V Encoder/Counter Module	1734-IJ
24V Encoder/Counter Module	1734-IK
24V Very High-speed Counter Module	1734-VHSC24
5V Very High-speed Counter Module	1734-VHSC5
ASCII RS-232 and RS-485 Modules	1734-232ASC, 1734-485ASC
Isolated Thermocouple Input Module	1734-IT2I
RTD Input Modules	1734-IR2, 1734-IR2E
Synchronous Serial Interface Encoder Module	1734-SSI

For more information about the following modules, see the installation instructions and user manuals listed in <u>Additional Resources on page 8</u>.

Catalog Number
1734-TBCJC
1734-FPD
1734-EP24DC
1734-CTM
1734-VTM
1734-TB, 1734-TBS, 1734-TB3, 1734-TB3S, 1734-TOP, 1734-TOPS, 1734-TOP3, 1734-TOP3S
1734-ARM

To secure access to a Logix 5000 controller and POINT I/O digital and analog modules by authorized users only, consider the following options:

- Follow the guidelines provided in the System Security Design Guidelines Reference Manual, publication <u>SECURE-RM001</u>.
- Password protect the source and execution of the control program.
- Deploy EtherNet/IP devices in accordance with recommended architectures and concepts. See the Converged Plantwide Ethernet (CPwE) Design and Implementation Guide, publication <u>ENET-TD001</u>.
- Implement physical barriers, such as locked cabinets.

Power Supplies, Wiring Base Assemblies, and Miscellaneous Modules

Secure Access to the System

To secure access to the system, consider the following options:

- Follow industry best practices to harden your PCs and servers, including antivirus/ antimalware and application allow list solutions.
- The recommendations are published at the Rockwell Automation technical support center in Knowledgebase article. See Rockwell Automation Customer Hardening Guidelines, Answer ID <u>546987</u>. To access technical support center, go to <u>rok.auto/knowledgebase</u>.
- Develop and deploy backup and disaster recovery policies and procedures. Test backups on a regular schedule.
- Minimize network exposure for all control system devices and systems, and make sure that they are not accessible from the Internet.
- Locate control system networks and devices behind firewalls and isolate them from the business network.
- Subscribe to Knowledgebase article Industrial Security Advisory Index, Answer ID <u>54102</u> at the Rockwell Automation technical support center so you have access to information about security matters that affect Rockwell Automation products. To access technical support center, go to <u>rok.auto/knowledgebase</u>.

Notes:

Configure POINT I/O Modules Using Studio 5000 Logix Designer Application

This chapter covers the instructions about how to configure digital and analog POINT I/O modules, using Studio 5000 Logix Designer application with one of the following:

- ControlNet network using a 1734-ACNR adapter
- EtherNet/IP network using a 1734-AENT adapter

Use the Help Button

Configure Digital Modules

The screen captures used in the procedure are for RSLogix 5000 software and it may not be exactly the same for Studio 5000 Logix Designer application.

From the dialogs you use to configure the digital and analog POINT I/O modules, select Help at the bottom of the dialog for information about how to complete entries on the dialogs.

From a warning dialog, select Help at the bottom of the dialog to get information about that specific error.

To configure POINT I/O digital modules in Studio 5000 Logix Designer application, using a ControlNet or EtherNet/IP network, proceed as follows:

- 1. Configure your adapter, referring to the user manual for your 1734-AENT adapter for EtherNet/IP networks or 1734-ACNR adapter for ControlNet networks with information on how to select a controller and communication module.
- 2. Add a digital module according to the instructions in your 1734-AENT or 1734-ACNR adapter user manual.

s an example,			ig appears.	
🔒 New Module				×
General Conne	ction Module Info Fault/Program Action	Configuration		
Type: Vendor: Parent:	1734-0B2E 2 Point 10V-28V DC Electronic Allen-Bradley myachr	ally Fused Outpu	t, Source	
Name:		Slot:	1 💌	
Description:				
- Module Defin	ition			
Series:	C Change			
Revision:	3.1			
Electronic Ke	ying: Compatible Module			
Connection:	Data			
Data Format:	Integer			
Status: Creati	ng	ОК	Cancel	Help

As an example, if you add 1734-OB2E, the New Module dialog appears.

3. Select the Connection tab at the top of the dialog.

Module Properties: myacnr:1 (1734-0B2E/C 3.1)	<u> </u>
General Connection Module Info Fault/Program Action Configuration*	_
Requested Packet Interval (RPI): 20.0 ms	
🗖 Inhibit Module	
Major Fault On Controller If Connection Fails While in Run Mode	
Les Scheduled Connection over ControlNet	
Module Fault	
•	• //

- 4. Leave the following options unchecked:
 - Inhibit Module
 - Major Fault On Controller If Connection Fails While in Run Mode
- 5. Complete the entry for Requested Packet Interval (RPI) as per the following table, if the field is selectable:

Adapter Configuration	RPI Value for Digital Module Type
Direct Connection	50 ms
Rack Optimization	RPI is not selectable

6. Select the Module Info tab to see the module identification and status information.

Module Properties: myacnr:1 (1734-0B2E/C 3	.1)	
General Connection Module Info Fault/Program	Action Configuration*	1
Identification Vendor: Product Type: Product Code: Revision: Serial Number: Product Name:	Status Major Fault: Minor Fault: Configured: Owned: Module Identity:	
I	R <u>e</u> fresh <u>E</u> e	set Mod

- 7. See the section <u>About Fault/Program Action and Configuration Dialogs</u> for information about the following tabs and dialogs, which you can see based on the module you have added:
 - Fault/Program Action
 - Configuration

About Fault/Program Action and Configuration Dialogs

You can see Fault/Program Action and Configuration dialogs based on the module and connection types. See the following table:

For Module Type	With Connection Type	You See These Tabs ⁽¹⁾	
i oi nouule iype	with connection type	Fault/Program Action	Configuration
	Data		X
	Listen Only		
Input	Listen Only - Rack Optimization		
	Rack Optimization		X
	Data	Х	X
	Listen Only		
Output	Listen Only - Rack Optimization		
	Rack Optimization	x	х

(1) You see tabs for General, Connection, and Module Info for all module and connection types.

Understand Data and Connection Formats

For digital modules, the choices for data format and connection type are as follows:

- Data Format
 - Integer
- Connection Type
 - Data
 - Listen Only
 - Listen Only Rack Optimization
 - Rack Optimization

When you change the entries for data format and connection type, note the following:

- You do not delete the existing module.
- You do not create a new module.
- You bring forward configuration data for the new settings.
- Any configuration data you do not bring forward sets to the default value.

After you apply new settings for data format and connection, note the following:

- This is the base configuration for the next change in connection and data format settings.
- You lose all configuration data from previous data formats.

The choices for connection type for modules depend on the communication type format for the parent adapter as per the following table:

Adaptar			Output Module			
Communication Format	Connection Type	Input Module	1734-0A2, 1734-0W2, 1734-0W4, 1734-0W4K, 1734-0X2	1734-0B2, 1734-0B4, 1734-0B4K, 1734-0B8, 1734-0B8K	1734-082E, 1734-084E, 1734-088E, 1734-088EK, 1734-082EP, 1734-0V2E, 1734-0V4E, 1734-0V8E, 1734-0V8EK	
	Data (default)	Х	х	х	x	
Listen Unly - Rack Ontimization	Listen Only	Х			x	
optimization	Listen Only - Rack Optimization	Х	х		x	
Nana	Data (default)	Х	х	х	x	
NUTIE	Listen Only	Х			x	
	Data (default)	Х	х	х	x	
Rack Optimization	Listen Only	Х				
	Rack Optimization	Х	х	х	x	

Understand Transition to Hard Run Behavior

While online with a controller in Remote Run mode, change fields on the dialogs you select from the New Module dialog.

📲 New Module		×
General Conner	ction Module Info Fault/Program Action Configuration	
Type: Vendor: Parent:	1734-0B2E 2 Point 10V-28V DC Electronically Fused Output, Source Allen-Bradley myachr	
Name:	Slot: 1 💌	
Description:		
– Module Defini	ition	
Series:	C Change	
Revision:	3.1	
Electronic Key	ying: Compatible Module	
Connection:	Data	
Data Format:	Integer	
Status: Creatir	ng OK Cancel Help	

When you switch the controller to Hard Run, note the following:

- You disable all controls except for the Description field on the General dialog, which remains active in all modes.
- You revert to each control that contains an edited value, including the Description field on the General dialog, to include the following dialogs:
 - General
 - Connection
 - Fault/Program Action
 - Configuration

Work with Dialogs for Digital Input Modules

To complete entries for the dialogs for input modules, proceed as follows:

- 1. Add an input module with these entries for connection type:
 - Data
 - Rack Optimization
- 2. From the top of the General dialog, select Configuration tab.

The Configuration dialog appears where you can configure the filter for input points for the following:

- Off to On
- On to Off

The Configuration dialog displays configuration data for each channel in individual rows in a table. Input modules support separate filter times for Off to On and On to Off transitions. The number of input channels varies based on the type of module as in these examples.

- The1734-IA2 module has 2 input channels (0...1).
- The 1734-IB4 module has 4 input channels (0...3).

See Figure 1 for a Configuration dialog of an 8-point input module.

Figure 1 - Configuration Dialog for 8-point Input Module

Point	Input Filter	Time (ms)					
	Off-≻On	On-≻Off					
0	1.000 🗘	1.000 韋					
1	1.000 🚔	1.000 🚔					
2	1.000 🌻	1.000 🚔					
3	1.000 🌻	1.000 🌻					
4	1.000 🜻	1.000 韋					
5	1.000 🌻	1.000 🌻					
6	1.000 🜻	1.000 🤹					
7	1.000 🜲	1.000 🚔					

3. Complete the entries in Configuration dialog. See the following table for information about how to make entries.

Feature	Description
Channel	Displays channels you use to set channel configuration parameters
Input Filter Time (ms)	 Displays Off to On or On to Off transition filter constant A high signal must be present for this amount of time before the module reports an On. A low signal must be present for this amount of time before the module reports an Off. Enter a value in milliseconds. The default is 1 ms (1000 μs).

- 4. From the Configuration dialog, perform one of the following:
 - Select another tab at the top of the dialog.
 - Select OK to save changes and close the dialog.
 - Select Cancel to return to default values.
 - Select Apply to save changes you made on any of the dialogs and it continues to display the dialog. The Apply button gets enabled only when you make changes to any of the dialogs.

Work with Dialogs for Digital Output Modules

Read this section to complete the Fault/Program Action and Configuration dialogs for output modules. You typically select these dialogs from the General dialog, when you add an output module with the following entries for connection type:

- Data
- Rack Optimization

Enter values for the Fault/Program Action and Configuration dialogs based on the following output modules:

- Without diagnostic status
- With overload diagnostic status
- With overload and open load diagnostic status

Enter Values on the Fault/Program Action Dialog

Enter values on this dialog to configure the module output state for output modules when the controller mode changes to Program or Fault mode. To complete the entries on this dialog, proceed as follows:

1. From the General dialog, select Fault/Program Action tab.

The Fault/Program Action dialog appears. See <u>Figure 2</u> for the Fault/Program Action dialog for an 8-point output module. The dialogs for 2-point and 4-point output modules are identical except for the number of points you can configure. Use this dialog to configure the Program Mode and Fault Mode for channels for the following modules:

- Without diagnostic status
- With overload diagnostic status
- With overload and open load diagnostic status

Figure 2 - Fault/Program Action Dialog for 8-point Output Module

Modul	e Properties: a	cnr:2 (1734-01	88/C 3.1)			<u> </u>
General	Connection 1	vlodule Info Fau	ult/Program Activ	on]		
				1		1
Boint	Output St	ate During				
FUIL	Program Mode	Fault Mode				
0	Off 💌	Off 💽				
1	Off 💌	Off 💽				
2	Off 💌	Off 🗾				
3	Off 💌	Off 🗾				
4	Off 💌	Off 💻				
5	Off 💌	Off 💌				
	Off 💌	Off 💌				
	011 💌	011 🗾				
Status	Offline		Or	Canad	1 Annalis II	Hala
o latas.	On mile					neip

2. Complete the entries in Fault/Program Action dialog. See the following table for information about how to make entries.

Feature	Description
Point	Displays the channel numbers.
Program Mode	 Select a value to determine the behavior of each output when the controller transitions to the Program Mode. Make a selection from the available values for each channel: Off (default) On Hold In Hard Run only, you can disable editing this feature.
Fault Mode	 Select a value to determine the behavior of each output when communication with the controller fails. Select from the available values for each channel: Off (default) On Hold In Hard Run only, you can disable editing this feature.

- 3. From the Fault/Program Action dialog, perform one of the following:
 - Select another tab at the top of the dialog.
 - Select OK, which closes the dialog.
 - Select Cancel to return to default values.
 - Select Apply to save changes you made on any of the dialogs and it continues to display the dialog. The Apply button gets enabled only when you make changes to any of the dialogs.

Enter Values on the Configuration dialog

Enter values on this dialog based on the type of module with the following:

- Overload diagnostic status
- Overload and open load diagnostic status

To complete the entries on this dialog proceed as follows:

1. From the General dialog, select Configuration tab.

The Configuration dialog appears, which displays configuration data for each channel in individual rows in a table. The number of output channels varies based on the type of module as in the following examples:

- The 1734-OB2E module has two output channels (0...1).
- The 1734-0B4E module has four output channels (0...3).
- The 1734-OB8E module has eight output channels (0...7).

See <u>Figure 3</u> for a Configuration dialog of a 4-point output module. The 2-point and 8-point output modules are identical except for the number of point you can configure.

Figure 3 - Configuration Dialog for 4-point Output Module

General	Connection	Module I	nfo Fault/F	Program Action	Configuration]	
Point	□ Latch Faults □	Auto Restart	Point 🗲 Fault				
0			Reset Reset				
3			Reset				
						4	

2. Complete the entries in Configuration dialog. See the following table for information about how to complete entries with No Load Detection.

Feature	Description				
Point	Displays the channel numbers).			
	 Use to determine how a sta Use latching for tracking tr You do not affect status LE 	tus bit acts after the cause of the fault is removed. ansient or momentary faults. Ds when using latched alarms.			
	If You Select	Then			
Latch Faults	Latch Faults (checked)	Alarm bits stay faulted if an alarm occurs. Clear the fault by using the clear latched alarm service for the channel (Reset pushbutton).			
	Reset Latch Faults (unchecked)	Alarm bits reflect the present state.			
	The Reset mode defines the A fault also occurs if you tu	e action of the output during a short circuit or overload. rn on an output when you do not apply field power to it.			
Auto Restart	Select	If you want the output to			
	Latched Off (unchecked)	Shut off			
	Auto Restart (checked)	Continually try to turn on			
Point Fault	 Select to clear latched alarms. A blue arrow denotes the use of explicit messaging. 				

- 3. From the Configuration dialog, complete the following header checkboxes:
 - No Load Detection
 - Latch Faults
 - Auto Restart

See <u>Figure 4</u> as an example, if you want to configure all of the channels the same way, you check the No Load Detection header. This checks all the checkboxes in the column and enables the bit for all the channels in the module.

Figure 4 - Configuration Dialog for 8 point Output Module

int	Detection	Latch Faults	Auto Restart	Point 🗧	
				Reset	
1				Reset	
2 3			<u>г</u>	Reset	
4				Reset	
5			Γ	Reset	
6				Reset	
7				Reset	

- 4. From the Configuration dialog, perform one of the following:
 - Select another tab at the top of the dialog.
 - Select OK, which closes the dialog.
 - Select Cancel to return to default values.
 - Select Apply to save changes you made on any of the dialogs and it continues to display the dialog. The Apply button gets enabled only when you make changes to any of the dialogs.

Configure Analog Modules

To configure POINT I/O analog modules in Studio 5000 Logix Designer application, proceed as follows:

- 1. Configure your adapter, referring to the user manual for your adapter for information on how to:
 - Configure the adapter
 - Add modules to the I/O configuration
 - Select a controller and communication module
- 2. According to the instructions in your adapter user manual, add an analog module and display the General dialog.
- 3. From the top of the General dialog, select Connection.
- 4. From the Connection dialog, leave the following unchecked:
 - Inhibit Module
 - Major Fault On Controller If Connection Fails While in Run Mode
- 5. From the Connection dialog, enter a value for Requested Packet Interval (RPI), if the field is selectable, per the table.

Adapter Configuration	RPI Default Value for Analog Module Type
Direct Connection	50 ms
Rack Optimization	RPI is not selectable

6. From the Connection dialog, select Choose Module Info from the top of the dialog to see a dialog that provides identification and status information.

 For information about the Fault/Program Action, Configuration, Alarm Configuration and Calibration tabs and dialogs, see the sections <u>Work with Dialogs for Analog Input</u> <u>Modules</u> and <u>Work with Dialogs for Analog Output Modules</u>. You can see these tabs based on the module you have added.

Understand Data and Connection Formats

For analog modules, the choices for data format and connection type are as follows:

- Data Format
- Integer

•

- Connection Type
 - Data
 - Listen Only
 - Listen Only Rack Optimization
 - Rack Optimization

When you change the entries for data format and connection type, note the following:

- You do not delete the existing module.
- You do not create a new module.
- You bring forward configuration data for the new settings.
- Any configuration data you do not bring forward sets to the default value.

After you apply new settings for data format and connection, note the following:

- This is the base configuration for the next change in connection and data format settings.
- You lose all configuration data from previous data formats.

The choices for connection type for modules depend on the communication type format for the parent adapter, as explained in the user manual for the adapter.

Work with Dialogs for Analog Input Modules

Read this section for information about how to complete entries on the following dialogs for analog input modules:

- Configuration
- Alarm Configuration
- Calibration

To display the dialogs, you typically select Configuration, Alarm Configuration, or Calibration at the top of the General dialog.

Work with the Configuration Dialog

This dialog does not appear for Listen Only connections. To complete the entries on this dialog, proceed as follows:

1. From the top of the General dialog, select Configuration.

The Configuration dialog appears for a current or voltage module, based on the type of module you have added. See <u>Figure 5</u> for a Configuration dialog for a current input module.

General C	Connection M	odule Info C	onfiguration],	Alarm Configuratio	on Calibration	1	
Channel	High Engineering	Low Engineering	Digital Filter (ms)	Current Range			
0	16383 🚔	3277 🚔	0 🌲	4-20 m.A 💌	1		
1	16383 🜩	3277 🜲	0 🚔	4-20 m.A 💌	Ī		
<u>R</u> eal Time <u>N</u> otch Filte	Sample (RTS) er :	: 100 60Hz	i ms ▼				
Status: I	Running			OK	Cancel	Apply	Help

Figure 5 - Configuration Dialog for a Current Input Module

2. From the Configuration dialog, complete the entries. See the following table for information on how to make entries.

For This Value	Select	Comments
High Engineering	-32,768+32,767	The default for 1734-IE2C analog input module is 16,383. The default for 1734-IE2V analog input module is 10,000.
Low Engineering	-32,768+32,767	The default for 1734-IE2C analog input module is 3,277. The default for 1734-IE2V analog input module is 0.
Digital Filter (ms)	010,000	The default is 0.
Current Range	40 mA 020 mA	The default is 420 mA.
Voltage Range	-10+10V 010V	Default is 010V
Real Time Sample (ms)	010,000	The default is 100. See <u>Table 4</u> for the relationship between Notch Filter and Real Time Sample.
Notch Filter	50 Hz 60 Hz 250 Hz 500 Hz	The default is 60 Hz. See <u>Table 4</u> for the relationship between Notch Filter and Real Time Sample.

Table 4 - Real Time Sample Values

Real Time	Notch Filter Setting				
Sample	50 Hz	60 Hz	250 Hz	500 Hz	
Min	120 ms	100 ms	24 ms	12 ms	

- 3. From the bottom of the Configuration dialog, perform one of the following:
 - Select another tab at the top of the dialog.
 - Select OK to save changes and close the dialog.
 - Select Cancel to return to default values.
 - Select Apply to save changes you made on any of the dialogs and it continues to display the dialog. The Apply button gets enabled only when you make changes to any of the dialogs.

Work with the Alarm Configuration Dialog

This dialog does not appear for Listen Only connections. To complete the entries on this dialog, proceed as follows:

1. From the top of the General dialog, select Alarm Configuration.

An Alarm Configuration dialog appears for a current or voltage module, based on the type of module you have added. See <u>Figure 6</u> for the Alarm Configuration dialog of a 1734-IE2C module. See the <u>Table 5</u> for the list of default values.

Figure 6 - Alarm Configuration Dialog for 1734-IE2C Module

Module Properties: myAaent:1 (1734-IE2C/C	3.1)	<u> </u>
General Connection Module Info Configuration Channel 0 1 Process Alarms : Unlatch <u>A</u> ll High High : 16733 $\frac{-}{-}$ Unlatch High High : 16547 $\frac{-}{-}$ Unlatch Low : 3113 $\frac{-}{-}$ Unlatch Low Low : 2867 $\frac{-}{-}$ Unlatch	Alarm Configuration Calibration	
Status: Running	OK Cancel Apply He	elp

Table 5 - Alarm Configuration Dialog Default Values

Alormo	Default Value		
Aldi Ilis	1734-IE2C	1734-IE2V	
High High	16,793	9,800	
High	16,547	9,500	
Low	3,113	500	
Low Low	2,867	200	

- 2. From the Alarm Configuration dialog, perform the following:
 - a. Select a channel button (for example, 0 or 1) for which you want to configure the alarms. The channel 0 is selected in <u>Figure 6</u>.
 - b. Set the values for Low, High, Low Low, and High High alarms in one of the following ways:
 - Enter the exact numerical value in the field against the corresponding alarm. You can use the up/down arrow to adjust the value.
 - Drag the pointer on the corresponding alarm slider control to set the desired value.
 - c. Choose one of the following unlatch options:
 - · Select Unlatch next to an individual alarm to unlatch each alarm one by one.
 - Select Unlatch All to unlatch all the alarms at once.

- d. Select the following checkboxes, if necessary:
 - Disable All Alarms If you select the Disable All Alarms checkbox, the module does not report any alarms. This is disabled in Hard Run mode only.
 - Latch Process Alarms If you select the Latch Process Alarms checkbox, this lets you latch the transient alarm conditions. This is disabled in Hard Run mode only.
- e. Select OK.

Work with the Calibration Dialog

To complete entries on this dialog proceed as follows. Perform calibration in Hard Run or Remote mode. For information about the tools and steps for calibration, see <u>Calibrate Your</u> <u>Analog Modules on page 71</u>.

1. From the General dialog, select Calibration.

The Calibration dialog appears for a current or voltage input module, depending on the module type.

See <u>Figure 7</u> for a Calibration dialog for a current input module.

Figure 7 - Calibration Dialog for a Current Input Module

General Connection Module Info Configuration	Alarm Configuration Calibration
Apply power to the power supply and module for at li calibrating the module.	east 10 minutes before
Channel Calibrate Calibration Range	Start Calibration
0 🔽 4 to 20 mA	
1 4 to 20 mA	
Calibrate Channels:	
C In Groups	
One At a Time	
Status: Running	OK Cancel Apply Help

- 2. Select the Calibrate checkbox to specify which channel to calibrate.
- 3. Under Calibrate Channels, select the option One At a Time.
- 4. Select Start Calibration, which is active when the system is online, and you have selected at least one of the channels.

When you press the F1 button on your keyboard or select Help from the wizards and warning messages that appear during calibration, you get detailed information about related procedures.

A warning dialog appears.

RSLogix !	5000	×
⚠	Danger: Calibration should not be performed on a module currently being used for control. All channels will freeze at their current values and control may be interrupted.	
	Continue with Calibration?	
	OK Cancel Help	

5. From the warning dialog, for a module not currently used for control, select OK. The Low Value dialog appears.



6. From the Low Value dialog, select Next to start calibration. The High Value dialog appears.

Input Calibration - High Value		×
Attach High Reference source(s) to t	the following channel(s).	
Channel 0		
Press "Next" to start the High Refere	ence Calibration (20 mA)	
<u>H</u> etry	<u> </u>	

7. From the High Value dialog, select Next to start calibration.

The Calibration Completed dialog appears. This dialog shows you the changed calibration constants of the channel that is saved.

Calibration Wizar	d - Calibration (Completed	×		
Calibration of the following channel(s) has been completed successfully:					
Channel O	: Success				
The calibration constants of the channel(s) have been saved.					
<u>R</u> etry	Next	<u>F</u> inish	<u>H</u> elp		

Work with Dialogs for Analog Output Modules

Read this section for information about how to complete entries on the following dialogs for analog output modules:

- Configuration
- Alarm Configuration
- Fault/Program Action
- Calibration

To display the dialogs, you typically select Fault/Program Action, Configuration, Alarm Configuration, or Calibration at the top of the General dialog.

Work with the Configuration Dialog

This dialog does not appear for Listen Only connections. To complete the entries on this dialog, proceed as follows.

1. From the top of the General dialog, select Configuration.

The Configuration dialog appears for a current or voltage module, based on the type of module you have added.

See <u>Figure 8</u> that shows configuration parameters for each channel in individual rows on the grid with, for example, 1734-0E2C having two output channels.

Figure 8 - Configuration Dialog of 1734-0E2C Module

Module Properties: MyACNR:1 (1734-0E2C/C 3.1)	
General Connection Module Info Configuration Alarm Configuration Fault Program Action Calib	ration
General Connection Module Info Configuration Alarm Configuration Fault Program Action Calib Channel Output Range High Engineering Low Engineering 0 4-20 mA 191 2 1638 2 1 0-20 mA 10000 2 1647 2	ration
Status: Offline OK Cancel Apply	Help

2. From the Configuration dialog, complete the entries. See the following table for information about how to make entries.

For This Value	Select	Comments
High Engineering	-32,768+32,767	The default for 1734-0E2C analog output module is 8,191. The default for 1734-0E2V analog output module is 10,000.
Low Engineering	-32,768+32,767	The default for 1734-0E2C analog output module is 1,638. The default for 1734-0E2V analog output module is 0.
Current Range	420 mA 020 mA	The default is 420 mA.
Voltage Range	-10+10V 010V	The default is 010V.

- 3. From the Configuration dialog, perform one of the following:
 - Select another tab at the top of the dialog.
 - Select OK to save changes and close the dialog.
 - Select Cancel to return to default values.
 - Select Apply to save changes you made on any of the dialogs and it continues to display the dialog. The Apply button gets enabled only when you make changes to any of the dialogs.

Work with Alarm Configuration Dialog

This dialog does not appear for Listen Only connections. To complete the entries on this dialog, proceed as follows:

1. From the top of the General dialog, select Alarm Configuration.

An Alarm Configuration dialog appears for a current or voltage module, based on the type of module you have added. See <u>Figure 9</u> for the Alarm Configuration dialog of a 1734-0E2C module. See the <u>Table 6</u> for the list of default values.

Figure 9 - Alarm Configuration Dialog for 1734-0E2C Module

Module Properties: MyACNR:1 (1734-0E2C/	C 3.1)	_ 🗆 ×
General Connection Module Info Configuratio	n Alarm Configuration* Fault Program Action Calibration	1
Channel 0 [™] 1 Clamp Limits: Unlatch <u>A</u> I <u>High</u> : 21080 <u></u> Unlatch Low: -21715 <u>Unlatch</u>	Disable All Alarms	
Status: Offline	OK Cancel Apply	Help

Table 6 - Alarm Configuration Dialog Default Values and Range

Alarms	Default Value	Range	
High	+32,767	-32,768 to +32,767	
Low	-32,768		

- 2. From the Alarm Configuration dialog, perform the following:
 - a. Select a channel button (for example, 0 or 1) for which you want to configure the alarms. The channel 0 is selected in Figure 9.
 - b. Set the values for Low and High alarms in one of the following ways:
 - Enter the exact numerical value in the field against the corresponding alarm. You can use the up/down arrow to adjust the value, if necessary.
 - Drag the pointer on the corresponding alarm slider control to set the desired value.
 - c. Choose one of the following unlatch options:
 - Select Unlatch next to an individual alarm to unlatch each alarm one by one.
 - Select Unlatch All to unlatch all the alarms at once.
 - d. Select the following checkboxes, if necessary:
 - Disable All Alarms If you select the Disable All Alarms checkbox, the module does not report any alarms. This is disabled in Hard Run mode only.
 - Latch Process Alarms If you select the Latch Process Alarms checkbox, this lets you latch the transient alarm conditions. This is disabled in Hard Run mode only.
 - e. Select OK.

Work with the Fault/Program Action Dialog

Use this dialog to configure and display the parameters controlling output states during Fault and Program conditions. This dialog does not appear for Listen Only connections. To complete the entries on the dialog, proceed as follows:

1. From the top of the General dialog, select Fault/Program Action tab.

A Fault/Program Action dialog appears.

🔲 Module	Properties: MyACNR	:1 (1734-OE20	./C 3.1)				
General	Connection Module	nfo Configurati	on Alarm Configurat	ion	Fault Program Ac	tion Calibration	וו
	-	· ·					1
Chann	el Fault Mode	Fault Value	Program Mode		Program Value		
0	Use Fault Value	- 0 *	Go to Low Clamp	-	0 ≑		
1	Hold Last State	<u> </u>	Use Program Value	-	0 韋		
Status:	Offline		OK]_	Cancel	Apply	Help

2. From the Fault/Program Action dialog, complete entries. See the following table for information about how to make entries.

For This Value	Select	Comments
Fault Mode	Hold Last State Go to Low Clamp Go to High Clamp Use Program Value	The default is Go to Low Clamp.
Fault Value	-32,768+32,767	The default is 0.
Program Mode	Hold Last State Go to Low Clamp Go to High Clamp Use Program Value	The default is Go to Low Clamp.
Program Value	-32,768+32,767	The default is 0.

- 3. From the bottom of the dialog, perform one of the following:
 - Select another tab at the top of the dialog.
 - Select OK to save changes and close the dialog.
 - Select Cancel to return to default values.
 - Select Apply to save changes you made on any of the dialogs and it continues to display the dialog. The Apply button gets enabled only when you make changes to any of the dialogs.

Work with the Calibration Dialog

To complete entries on this dialog, proceed as follows. Perform calibration in Hard Run or Remote mode. For information about the tools and steps for calibration, see <u>Calibrate Your</u> <u>Analog Modules on page 71</u>.

1. From the General dialog, select Calibration.

The Calibration dialog appears for a current or voltage output module, depending on the module type.

Module Properties: myACNR:5 (1734-IE2C/C 3.1)	
General Connection Module Info Configuration Alarm Configuration Apply power to the module for at least 10 minutes before calibrating the module. Channel Calibrating the module. Channel Calibration Range 0 4 to 20 mA 1 4 to 20 mA 4 to 20 mA	tion Calibration
Calibrate Channels: C In <u>G</u> roups C <u>O</u> ne At a Time	
Status: Running OK	Cancel Apply Help

- 2. From the Calibration dialog, select one of these:
 - In Groups
 - One At a Time
- 3. From the Calibration dialog, check the Calibrate checkbox to specify which channel to calibrate.
- 4. From the Calibration dialog, select Start Calibration, which is active when:
 - The system is online, and
 - You selected at least one of the channels

When you press the F1 button on your keyboard or select Help from the wizards and warning messages that appear during calibration, you get detailed information about related procedures.

A warning dialog appears.

RSLogix !	5000	×	
⚠	Danger: Calibration should not be performed on a module currently being used for control. All channels will freeze at their current values and control may be interrupted.		
	Continue with Calibration?		
	OK Cancel Help		

5. From the warning dialog, for a module not currently used for control, select OK. A Low Value dialog appears.

Input Calibration - Low Value	×
Attach Low Reference source(s) to the following channel(s):	
Channel 0	
Press "Next" to start the Low Reference Calibration (4 mA)	
<u>Betry</u>	<u>H</u> elp

6. Follow the instructions that you see in the Low Value dialog, and select Next. The High Value dialog appears.



- 7. Follow the instructions that you see in the High Value dialog and select Next to start calibration.
- 8. When the calibration completes successfully, the Calibration Completed dialog appears.

Calibration Wizard - Calibration Completed	×
Calibration of the following channel(s) has been completed successfully:	
Channel 0 : Success	
The calibration constants of the channel(s) have been sav	red.
Frain Mart Finish	Ulala
<u>nierry</u> <u>N</u> ext <u>Finish</u>	Help

If calibration fails, the Results dialog appears with the channels list that are failed in calibration.

Input Calibration - Results	×
Calibration of following channel(s) has been completed:	
Channel 0 : Fail	
Press "Retry" to calibrate the channel(s) that did not calibrate successfully.	
<u>R</u> etry <u>N</u> ext <u>Finish H</u> elp	

- 9. When the calibration is successful, select Finish. If calibration is failed, from the Results dialog, select Retry to calibrate the channel that did not calibrate successfully and repeat the process until calibration is successful.
- 10. Repeat calibration for each channel, if applicable.

Configure POINT I/O Modules for DeviceNet Networks

This chapter covers the instructions on how to configure POINT I/O modules in a DeviceNet network. If you are using a ControlNet, EtherNet/IP, or PROFIBUS network, see the appropriate user manual:

- POINT I/O ControlNet Adapter User Manual, publication <u>1734-UM008</u>
- POINT I/O EtherNet/IP Adapter Module User Manual, publication <u>1734-UM011</u>
- POINT I/O and ArmorPOINT I/O Dual-port EtherNet/IP Adapters User Manual, publication <u>1734-UM017</u>
- POINT I/O PROFIBUS Adapter Module User Manual, publication <u>1734-UM005</u>

To configure POINT I/O modules, use RSNetWorx[™] software to identify the network and configure the I/O modules with electronic data sheet (EDS) files. To obtain EDS files for use in configuration, go to <u>rok.auto/pcdc</u>.

Methods for commissioning nodes are the following:

- RSNetWorx commissioning pull-down
- Sequential auto addressing feature
- Third-party configuration software

Using the RSNetWorx Commissioning Tool

The RSNetWorx commissioning tool lets you commission devices (set the node address and the data rate parameters) that are either connected to a DeviceNet network or connected via a point-to-point connection.

The node commissioning tool works through RSLinx software. The RSNetWorx software does not have to be online when performing the operation.

Before you can add any device to a DeviceNet network, you must commission it. This means you must program into the device a node address and data rate. Some devices are precommissioned, meaning a node address (usually set to 63) and a data rate (usually set to 125 Kbps) are programmed into the device at the factory prior to shipment. You need to commission other devices in the field. Once a device has been commissioned and attached to a network, you can use the RSNetWorx for DeviceNet node commissioning tool to edit the node address and data rate that were set previously.

Exercise caution while editing node addresses when on a network. When you apply a new node address, it immediately overwrites the node address data in the device currently specified. If you decide to reassign node addresses, you should first determine the order in which this needs to be done so that all devices still have unique node addresses when you finish.

For example, if two of the devices on your network are a photoelectric sensor and a hand controller and you accidentally change the node address of the hand controller to be the same as that of the photoelectric sensor, then the photoelectric sensor no longer has a unique address. This means it is not able to provide data to the scanner. If you cannot access a device, because you have used its node address for another device, you have to remove it from the network, recommission it, then reinstall it on the network.

Commissioning a Node



ATTENTION: Do not change the data rate of devices while they are connected to a network. Erratic operation may result. We recommend that if you need to change the data rate of a device, you should remove it from the network, establish a point-to-point connection between the PC, which hosts the RSNetWorx for DeviceNet software, and the target device, recommission it, and then reconnect it to the network.

Use Sequential Auto Addressing

Sequential Auto Addressing (SAA) reassigns the node address of every module to the right of the one you select on the POINTBus™ network. Each module changes its node address to one greater than its neighbor.

IMPORTANT	Make sure that the node address of the selected module is the
	desired value before issuing the SAA command.

When this command is set, each module to the right gets a new address one greater than its neighbor. The addressing ripples through a line of POINT I/O modules, assigning a node number to each module installed in a mounting base on the same POINTBus network.

Follow these steps to Auto Address a line of POINT I/O modules.

- 1. Set the address of the first module you want to address.
- 2. Set the Auto Address command to Sequential Address.

All modules in line reset with new sequential addresses.

For example, assume you have five POINT I/O modules in a line, and the address of the first module is 10. After the Sequential Address command is sent to the first module, the node addresses of the modules in line are 10, 11, 12, 13, and 14.

Using Third-party Configuration Software

When using third-party configuration software, load the EDS files into the software and follow the designers instructions.

Configure Digital Modules Using RSNetWorx Software

The input modules use dialogs similar to 1734-IB4 module used in this procedure. To configure digital input modules, proceed as follows:

- 1. Open your RSNetWorx for DeviceNet software.
- 2. Use the selections on the left to construct your system. If your network is up, select Browse.


 After setting up your system, double-click on the module icon which you want to configure. If you are online, upload the configuration. A dialog similar to the following appears.

🧱 1734-IB4 /	4 Pt 24VDC Sink Input (3)	? ×
General De	evice Parameters EDS I/O Default	
ſ	1734-IB4 4 Pt 24VDC Sink Input	
<u>N</u> ame:	1734-IB4 4 Pt 24VDC Sink Input (3)	
<u>D</u> escription		
Add <u>r</u> ess:	6	
	Device Identity [Primary]	- 1
	Vendor: Rockwell Automation - Allen-Bradley [1]	
	Device: General Purpose Discrete I/O [7]	
	Product: 1734-IB4 4 Pt 24VDC Sink Input [130]	
	Catalog: 1734-IB4	
	Revision: 1.003	
		-
[OK Cancel Apply Help	,

4. Select the Device Parameters tab to get the dialog for setting the parameters.

Configure Input Modules

<u>Figure 10</u> shows the Device Parameters dialog for 1734-IB4 input module. All digital input modules have parameters similar to 1734-IB4 input module.

In Device Parameters dialog, you can see all the parameters for the module. These include filters, autobaud, sequential addressing, and communication rate (if you are not using autobaud).

Figure 10 - Device Parameters Dialog for 1734-IB4 Input Module

	📓 1734-IB4 4 Pt 24VDC Sink Input (3)				
	General Device Parameters E	DS I/O Default			
	Groups	Dn-Line © Single Upload From Device © All Start Monitor			
	Parameter	Current Value			
	🟦 (0001) Input Value #0	OFF			
	🟦 (0002) Input Value #1	OFF			
	🟦 (0003) Input Value #2	OFF			
If you see a lock next to an entry,	(0004) Input Value #3	OFF			
you cannot change that parameter.	(0005) Off-to-On Filter 0	999 us			
	(0006) On-to-Off Filter 0	999 us			
	(0007) Off-to-On Filter 1	999 us			
	(0008) On-to-Off Filter 1	999 us			
	(UUU9) Uff-to-Un Filter 2	999 us			
	(UU1U) Un-to-Uff Filter 2	999 us			
	(0011) Uff-to-Un Filter 3	999 us			
	(UU12) Un-to-Uff Filter 3	999 us			
	ОК	Cancel <u>Apply</u> Help			

The Groups dropdown list include the following:

- All parameters
- I/O
- Configuration
- POINTBus

To complete entries in the Device Parameters dialog, proceed with following procedure:

- 1. From the Groups dropdown list, select Configuration and the parameters you want.
- 2. Select one of the following options:
 - Single Select this option to change or configure parameters one at a time.
 - All Select this option to change all selections at once.

■ 1734-IB4 4 Pt 24VDC Sir	nk Inpu	t (3)			? ×
General Device Parameters	EDS I/0) Defa	sult]		
Groups All parameters All parameters 1/0 Configuration PointBus	On-Lin © Sir © All	e ngle		<u>U</u> pload F <u>D</u> ownload <u>S</u> tart	rom Device I To Device Monitor
Parameter		Curre	nt Val	ue	
🟦 (0001) Input Value #0		OFF			
🟦 (0002) Input Value #1		OFF			
🟦 (0003) Input Value #2		OFF			
🟦 (0004) Input Value #3		OFF			
(0005) Off-to-On Filter 0		999 i	IS		
(0006) On-to-Off Filter 0		999 i	IS		
(0007) Off-to-On Filter 1		999 i	IS		
(0008) On-to-Off Filter 1		999 i	IS		
(0009) Off-to-On Filter 2		999 i	IS		
(0010) On-to-Off Filter 2		999 i	IS		
(0011) Off-to-On Filter 3		999 i	IS		
(0012) On-to-Off Filter 3		999 i	IS		
ОК	Cano	el		Apply	Help

If autobaud is selected, the communication rate of this module automatically matches the communication rate of the existing devices on the network, and you are prevented from selecting a specific communication rate.

1734-IB4 4 Pt 24VDC Sir General Device Parameters	n <mark>k Inpu</mark> EDS I/	t (3) O Default	_	? ×
Groups Configuration ▼ Restore Default Values Parameter Help	On-Lir © Sii	ngle	Upload From De Download To De Start Monitor	vice evice
Parameter		Current Va	lue	
(0005) Off-to-On Filter 0		999 us		_
(0006) On-to-Off Filter 0		999 us		
(0007) Off-to-On Filter 1		999 us		
(0008) On-to-Off Filter 1		999 us		
(0009) Off-to-On Filter 2		999 us		
(0010) On-to-Off Filter 2		999 us		
(0011) Off-to-On Filter 3		999 us		
(0012) On-to-Off Filter 3		999 us		
(0013) Autobaud		Enable		-
		Enable Disable		
OK	Cano	el	Apply	Help

- 3. Select the filter of your choice and enter the filter time. Each input channel can have its own time selection.
- 4. Select Download To Device.

i 1734-IB4 4 Pt 24∀DC Sir	nk Inpu	ıt (3)	?	×
General Device Parameters	EDS I/	0 Default]		
Groups Configuration	On-Lir © Sii © All	ngle	Upload From Device Download To Device Start Monitor	
Parameter		Current Val	ue	
(0005) Off-to-On Filter 0		999		
(0006) On-to-Off Filter 0		999 us		
(0007) Off-to-On Filter 1		999 us		
(0008) On-to-Off Filter 1		999 us		
(0009) Off-to-On Filter 2		999 us		
(0010) On-to-Off Filter 2		999 us		
(0011) Off-to-On Filter 3		999 us		
(0012) On-to-Off Filter 3		999 us		
(0013) Autobaud		Enable		
OK	Cano	cel	Apply Help	

Configure Output Modules

All output modules use dialogs similar to the 1734-OB4E output module used in this procedure. To configure output modules, proceed with following procedure:

1. From the General Parameters dialog, select Device Parameters to get the dialog for setting parameters.

📓 1734-0B4	E 4 Pt 24VD	C Source Outp	ut (4)		? ×
General De	vice Paramete	rs EDS I/O Defa	ault		
	1734-OB4E 4	Pt 24VDC Source	Output		
<u>N</u> ame:	1734-OB4E 4	Pt 24VDC Source	e Output (4)		
<u>D</u> escription					
Add <u>r</u> ess:	7				1
	Device Ider Vendor: [Device: [Product: [Catalog: [Revision:]	titly [Primary] Rockwell Automat General Purpose D 1734-0B4E 4 Pt 2 1734-0B4E 1.003	ion - Allen-Bradl Discrete I/O [7] 4VDC Source C	ey [1]	
[OK	Cancel	Apply	Help	

2. From the Device Parameters dialog, set parameters for the module to include sequential addressing and autobaud or communication rate (if you are not using autobaud).

T734-DB4E 4 PC 24VDL Source General Device Parameters EDS Groups On- On- All parameters Image: Construction of the second sec	Ce Uutput [4] E Si //D Default E Line Upload From Device Single Download To Device All Start Monitor	
Parameter	Current Value	1
(0001) Output Value #0	OFF	
(0002) Output Value #1	OFF	
(0003) Output Value #2	OFF	-
(0004) Output Value #3	OFF	
🟦 (0005) Status of Output #0	No Fault	
🟦 (0006) Status of Output #1	No Fault	
🟦 (0007) Status of Output #2	No Fault	
🔒 (0008) Status of Output #3	No Fault	
🟦 (0009) No Load Status #0	No Fault	
🟦 (0010) No Load Status #1	No Fault	
🛍 (0011) No Load Status #2	No Fault	
(1) (0012) No Load Status #3	No Fault	Ŀ
OK Ca	ancel <u>A</u> pply Help	

The Groups dropdown list include the following:

- All parameters
- I/O output value
- I/O output status
- Reset services
- POINTBus
- Configuration

3. From the Groups dropdown list, select Configuration and the parameters you want.

aeneral Device rarameters	EDS IA	U Default		
Liroups	Onein		Upload Fi	om Device
) Sir	ngle	Download	LTo Device
Restore Derault Values	\odot All			
Parameter Help			<u>S</u> tart I	Monitor
Parameter		Current Va	lue	<u> </u>
(0001) Output Value #0		OFF		
(0002) Output Value #1		OFF		
(0003) Output Value #2		OFF		
(0004) Output Value #3		OFF		
🔒 (0005) Status of Output #	0	No Fault		
🔒 (0006) Status of Output #	1	No Fault		
🔒 (0007) Status of Output #	2	No Fault		
🔒 (0008) Status of Output #	3	No Fault		
🔒 (0009) No Load Status #0)	No Fault		
🔒 (0010) No Load Status #1	1	No Fault		
🔒 (0011) No Load Status #2	2	No Fault		
🔒 (0012) No Load Status #3	3	No Fault		•
Ĩ				

- 4. Select one of the following options:
 - Single Select this option to change or configure parameters one at a time.
 - All Select this option to change all selections at once.

The configurable parameters include the following:

- Fault Value - Off/On

37 1734-	OB4E/C 4pt D	C Output	?×
General	Parameters Co	nfiguration I/O Data EDS File	
	Select the param initiate an action	eter that you want to configure and using the toolbar.	
	巅	Monitor	
b ∠.	Parameter	Current Value	^
23	Fault Action #0	Fault Value	•
24	Fault Value #0	ON	Ŧ
25	Fault Action #1	OFF	
26	Fault Value #1	ON	
27	Fault Action #2	Fault Value	•
28	Fault Value #2	OFF	•
29	Fault Action #3	Fault Value	•
30	Fault Value #3	OFF	•
31	Idle Action #0	Idle Value	•
32	Idle Value #0	OFF	
33	Idle Action #1	Idle Value	•
34	Idle Value #1	OFF	•
35	Idle Action #2	Idle Value	•
36	Tdie Value #2	OFF	- M
<		Ш	>
	OK.	Cancel Apply	Help

- Fault Action - Fault Value/Hold Last State

1734-0B4E 4 Pt 24VDC 9	Source Ou	tput (4)	? ×
General Device Parameters	EDS I/O D	efault	,
Groups Configuration ▼ <u>R</u> estore Default Values <u>P</u> arameter Help	On-Line — ⊙ Single ⊙ All		Upload From Device Download To Device Start Monitor
Parameter	Cu	rrent Valu	e 🔟
(0023) Fault Action #0	Fa	ılt Value	-
(0024) Fault Value #0	Fau	ilt Value	
(0025) Fault Action #1	Ho	d Last Sta	ate
(0026) Fault Value #1	OF	F	
(0027) Fault Action #2	Fa	ult Value	
(0028) Fault Value #2	OF	F	
(0029) Fault Action #3	Fa	ult Value	
(0030) Fault Value #3	OF	F	
(0031) Idle Action #0	Idl	e Value	
(0032) Idle Value #0	OF	F	
(0033) Idle Action #1	Idl	e Value	
(0034) Idle Value #1	OF	F	
1			
ОК	Cancel		apply Help

- Idle Value - Off/On

📓 1734-0B4E 4 Pt 24VDC	Source	Output (4)	? ×
General Device Parameters	EDS I/	0 Default	
Groups	_ On-Lin	e	
Configuration	💿 Sir	nale	Upload From Device
Restore Default Values		igio	Download To Device
Parameter Help			Start Monitor
Parameter		Current Val	ue
(0027) Fault Action #2		Fault Value	
(0028) Fault Value #2		OFF	
(0029) Fault Action #3		Fault Value	
(0030) Fault Value #3		OFF	
(0031) Idle Action #0		Hold Last S	tate
(0032) Idle Value #0		OFF	
(0033) Idle Action #1		OFF	
(0034) Idle Value #1		ON	
(0035) Idle Action #2		Idle Value	
(0036) Idle Value #2		OFF	
(0037) Idle Action #3		Idle Value	
(0038) Idle Value #3		OFF	
1 I I I I I I I I I I I I I I I I I I I			
OK	Cano	el 📃	Apply Help

- Idle Action - Idle Value/Hold Last State

1734-0B4E 4 Pt 24VDC 9	Source	Output (4)		?	×
General Device Parameters	EDS I/	0 Default			
<u>G</u> roups	- On-Lin	e			
Configuration 🔹	@ \$i	ala	Upload F	rom Device	
Restore Default Values		igic	<u>D</u> ownload	d To Device	
Parameter Help	U AI		<u>S</u> tart	Monitor	
Parameter		Current Val	ue	<u> </u>	1
(0023) Fault Action #0		Hold Last S	tate		
(0024) Fault Value #0		ON			
(0025) Fault Action #1		Fault Value			
(0026) Fault Value #1		OFF			
(0027) Fault Action #2		Fault Value			1
(0028) Fault Value #2		OFF			
(0029) Fault Action #3		Fault Value			
(0030) Fault Value #3		OFF			
(0031) Idle Action #0		Idle Value		-	
(0032) Idle Value #0		ldle Value			
(0033) Idle Action #1		Hold Last SI	tate		
(0034) Idle Value #1		OFF		-	
I					
ОК	Cano	el	Apply	Help	

- Enable Latching Alarms - Latching Enabled/Latching Disabled

eneral	Parameters Configuration Select the parameter hat you initiate an action using the too	/O Data EDS File want to configure and liber.	
	扇 😭 ቀ 🗠	mitor	* *
6. 4.	Parameter	Current Value	2
36	Idle Value #2	OFF	
37	Idle Action #3	Idle Value	*
38	Idle Value #3	OFF	
39	Enable Latching Alarms #0	Latching Disabled	-
+0	Enable Latching Alarms #1	Latching Disabled	
41	Enable Latching Alarms #2	Latching Enabled	
42	Enable Latching Alarms #3	Latching Disabled	
43	Enable No Load #0	No Load Disabled	
44	Enable No Load #1	No Load Disabled	
45	Enable No Load #2	No toad Disabled	
46	Enable No Load #3	No Load Disabled	
47	Reset Mode #0	Latch Off	
48	Reset Mode #1	Latch Off	
49	Reset Mode #2	Labeb Off	

- Enable No Load - No Load Enabled/No Load Disabled

1	Select the parameter that you initiate an action using the too	want to configure and lbar.	
	🗟 🔁 🕈 Ma	mitor	
	Parameter	Current Value	
38	Idie Value #3	OFF	
39	Enable Latching Alarms #0	Latching Disabled	
40	Enable Latching Alarms #1	Latching Disabled	
41	Enable Latching Alarms #2	Latching Disabled	-
42	Enable Latching Alarms #3	Latching Disabled	-
43	Enable No Load #0	No Load Disabled	~
44	Enable No Load #1	No Load Disabled	-
45	Enable No Load #2	No Load Enabled	
46	Enable No Load #3	No Load Disabled	
47	Reset Mode #0	Latch Off	-
48	Reset Mode #1	Latch Off	-
49	Reset Mode #2	Latch Off	-
50	Reset Mode #3	Latch Off	
-			1.51

- Reset Mode - Latch Off/Auto Restart

Groups Configuration Parameter Help Parameter (0040) Enable Latching Alarms (0041) Enable Latching Alarms (0042) Enable Latching Alarms (0043) Enable No Load #0 (0044) Enable No Load #1 (0045) Enable No Load #2 (0046) Enable No Load #3 (0047) Reset Mode #0	Line Single All Lato Lato Lato No I No I	ent Va shing D shing D shing E Load E	Upload Fi Download Start I Disabled Disabled Disabled Disabled	om Devic I To Devic Monitor	
Corriguration Restore Default Values Parameter Help (0040) Enable Latching Alarms (0041) Enable Latching Alarms (0042) Enable No Load #0 (0043) Enable No Load #1 (0045) Enable No Load #2 (0046) Enable No Load #3 (0047) Reset Mode #0	Single All Curr Lato Lato Lato No I No I	ent Va shing D shing E shing E Load E	Download Start I Jisabled Disabled Disabled Disabled Disabled	I To Devic Monitor	
Parameter Help Parameter (0040) Enable Latching Alarms (0041) Enable Latching Alarms (0042) Enable Latching Alarms (0043) Enable No Load #0 (0044) Enable No Load #1 (0045) Enable No Load #3 (0046) Enable No Load #3 (0047) Reset Mode #0	All Curr Lato Lato Lato No l No l	ent Va shing D shing D shing E Load E	<u>Start I</u> lue Disabled Disabled inabled	Monitor	
Parameter (0040) Enable Latching Alarms (0041) Enable Latching Alarms (0042) Enable Latching Alarms (0043) Enable No Load #0 (0044) Enable No Load #1 (0045) Enable No Load #2 (0046) Enable No Load #3	Curr Lato Lato Lato No I No I	ent Va hing D hing D hing E Load E	lue Disabled Disabled Inabled Inabled		
(0040) Enable Latching Alarms (0041) Enable Latching Alarms (0042) Enable Latching Alarms (0043) Enable No Load #0 (0044) Enable No Load #1 (0045) Enable No Load #2 (0046) Enable No Load #3	Lato Lato Lato No I No I	ching D ching D ching E Load E	Disabled Disabled Inabled Inabled		
(0041) Enable Latching Alarms (0042) Enable Latching Alarms (0043) Enable No Load #0 (0044) Enable No Load #1 (0045) Enable No Load #2 (0046) Enable No Load #3 (0047) Reset Mode #0	Lato Lato Nol Nol	ching D ching E Load E)isabled inabled inabled		
(0042) Enable Latching Alarms (0043) Enable No Load #0 (0044) Enable No Load #1 (0045) Enable No Load #2 (0046) Enable No Load #3 (0047) Reset Mode #0	Lato Nol Nol	ching E Load E	nabled nabled		
(0043) Enable No Load #0 (0044) Enable No Load #1 (0045) Enable No Load #2 (0046) Enable No Load #3 (0047) Reset Mode #0	No l	Load E	nabled		
(0044) Enable No Load #1 (0045) Enable No Load #2 (0046) Enable No Load #3 (0047) Reset Mode #0	Nol		No Load Enabled		
(0045) Enable No Load #2 (0046) Enable No Load #3 (0047) Reset Mode #0		No Load Enabled			
(0046) Enable No Load #3 (0047) Reset Mode #0	Nol	No Load Enabled			
(0047) Reset Mode #0	Nol	Load E	nabled		
	Auto	Resta	art	-	
(0048) Reset Mode #1	Late	h Off			
(0049) Reset Mode #2	Auto	Auto Restart			
(0050) Reset Mode #3	Lato	h Off			
(0051) Autobaud	Ena	ble			÷
•					
					-

- Autobaud - Enable/Disable

T734-0B4E 4 Pt 24VDC	Source	Output (4)		? ×
Groups	⊢ On•Lin	o Derauit		1
Configuration	⊙ Sir	nale	Upload Fr	om Device
<u>R</u> estore Default Values	e un		<u>D</u> ownload	To Device
Parameter Help	U AI		<u>S</u> tart N	Ionitor
Parameter		Current Val	ue	<u> </u>
(0040) Enable Latching /	(0040) Enable Latching Alarms		isabled	
(0041) Enable Latching /	(0041) Enable Latching Alarms		. Latching Disabled	
(0042) Enable Latching Alarms		. Latching Enabled		
(0043) Enable No Load #0		No Load Er	nabled	
(0044) Enable No Load #1		No Load Er	nabled	
(0045) Enable No Load #	(0045) Enable No Load #2		nabled	
(0046) Enable No Load \$	#3	No Load Enabled		
(0047) Reset Mode #0		Auto Restart		
(0048) Reset Mode #1		Latch Off		
(0049) Reset Mode #2	(0049) Reset Mode #2		Latch Off	
(0050) Reset Mode #3	(0050) Reset Mode #3		Latch Off	
(0051) Autobaud		Enable		
		Enable		
	_	Disable		
ОК	Cano	el	Apply	Help

I

If autobaud is selected, the communication rate of this module automatically matches the communication rate of the existing devices on the network and you are locked out from selecting a communication rate.

5. From the Device Parameters dialog, select Download To Device.

To configure the 1734-OW2 relay output module, proceed with following procedure:

1. From the General dialog, select Device Parameters to get the dialog for setting parameters.

≣ 1734-0₩ 2	2 Pt Relay Output (6)		? ×
General De	vice Parameters EDS I/O De	fault	
	1734-0W2 2 Pt Relay Output		
<u>N</u> ame:	1734-0W2 2 Pt Relay Output	(6)	
<u>D</u> escription			
Add <u>r</u> ess:	8		
	Device Identity [Primary] Vender: Reckwell Autom	ation Allon Pradla	[1]
	Device: General Purpose	Discrete I/O [7]	
	Product: 1734-0W2 2 Pt F	Relay Output [135]	
	Catalog: 1734-0W2		
	Revision: 1.002		
[OK Cancel	Apply	Help

2. The EDS Editor dialog appears. From the EDS Editor dialog, select Upload to load the latest information.

EDS Edi	itor	x
?	Do you want to upload the configuration from the device, updating the software's configuration; or download the software's configuration to the device, updating the device?	
	For more information, press F1	
	Upload Download Cancel	

3. From the Device Parameters dialog, select Configuration from the Groups dropdown list to set the parameters for the module to include sequential addressing, autobaud, or the communication rate (if you are not using autobaud).

15031/	o Derauit			
C On-Lir	ne	Unload From Douring		
💿 Si	ngle	<u>o</u> pidad From Device		
		Download To Device		
		Start Monitor		
	Current Val	ue		
	Fault Value			
(0004) Fault Value #0				
(0005) Fault Action #1				
(0006) Fault Value #1				
(0007) Idle Action #0		Idle Value		
(0008) Idle Value #0				
	Idle Value			
	OFF			
(0011) Run/Idle Command				
(0012) Autobaud		Enable		
		Concline Concli		

The Groups dropdown list include the following:

- All parameters
- I/0
- POINTBus
- Configuration Select to set the parameters

Configurable parameters include the following:

• Fault Action - Fault Value/Hold Last State

1734-0\2 2 Pt Relay Output (6)					
General Device Parameters EDS I/	0 Default]				
Groups On-Lir Configuration Image: Configuration Bestore Default Values Image: Configuration Parameter Help Image: Configuration	ngle Upload From Device Download To Device Start Monitor				
Parameter	Current Value				
(0003) Fault Action #0	Fault Value				
(0004) Fault Value #0	Fault Value				
(0005) Fault Action #1	Hold Last State				
(0006) Fault Value #1	OFF				
(0007) Idle Action #0	Idle Value				
(0008) Idle Value #0	OFF				
(0009) Idle Action #1	Idle Value				
(0010) Idle Value #1	OFF				
(0011) Run/Idle Command	Idle				
(0012) Autobaud	Enable				
OK Can	cel <u>Apply</u> Help				

• Fault Value - Off/On

📓 1734-0\#2 2 Pt Relay 0.	utput (6)		? ×	
General Device Parameters EDS I/O Default					
Groups Configuration Eestore Default Values Parameter Help	On-Lir O Sir O All	ngle	Upload Fr Download Start I	rom Device I To Device Monitor	
Parameter		Current Val	ue		
(0003) Fault Action #0		Hold Last 9	itate		
(0004) Fault Value #0	(0004) Fault Value #0			•	
(0005) Fault Action #1	(0005) Fault Action #1				
(0006) Fault Value #1		ON			
(0007) Idle Action #0		Idle Value			
(0008) Idle Value #0	(0008) Idle Value #0				
(0009) Idle Action #1		Idle Value			
(0010) Idle Value #1		OFF			
(0011) Run/Idle Commar	(0011) Run/Idle Command				
(0012) Autobaud		Enable			
				I	
OK	Cano	el	Apply	Help	

• Idle Action - Idle Value/Hold Last State



- Idle Value Off/On
- Run/Idle Command Idle/Run
- Autobaud Enable/Disable
- 4. From the Device Parameters dialog, Groups dropdown list:
 - Select All parameters to display each item.
 - Select POINTBus to display only the Run/Idle Command and Autobaud.

Beneral Device Parameters	utput (3)	() ()
All parameters	On-Line Single	Upload From Device
Parameter (0001) Output Value #0 (0002) Output Value #1 (0003) Fault Action #0 (0004) Fault Value #1 (0005) Fault Action #1 (0006) Fault Value #1 (0007) Idle Action #0 (0008) Idle Value #0 (0009) Idle Action #1	Currer OFF Fault \ OFF Fault \ OFF Idle V. OFF	nt Value ▲
(0003) Idle Action #1 (0010) Idle Value #1 (0011) Run/Idle Commar (0012) Autobaud	Cancel	

- 5. To monitor the output, select Start Monitor from the Device Parameters dialog. Consider the following:
 - The output value is displayed for each scan.
 - Select All to scan all values.
 - The Start Monitor button turns to Stop Monitor during monitoring.
 - Select Stop Monitor to stop monitoring the selected parameters.
 - Identify monitoring by the ball appearing momentarily next to the selected item during each scan.

	☐ 1734-0₩2 2 Pt Relay Output (3)	? 2
	General Device Parameters EDS I/O Default Groups On-Line I/O Single Bestore Default Values On All Parameter Help Current Value	Upload From Device Download To Device Start Monitor
Monitoring is identified by the ball appearing momentarily next to the selected item during each scan.	[0001] Dutput Value #0 OFF (0002) Dutput Value #1 OFF	
	OK Cancel A	Apply Help

Configure Analog Modules Using RSNetWorx Software

In the following procedure, the 1734-IE2C analog current input module and 1734-OE2C analog current output module are used as a representative for all input and output analog modules. The actual dialogs for your particular module may not be identical to the one shown in this procedure.

To configure analog input modules, proceed as follows:

- 1. Open your RSNetWorx for DeviceNet software.
 - The RSNetWorx for DeviceNet dialog appears.
- From the RSNetworx for DeviceNet dialog, use the selections in the window on the left to construct your system, or if your network is up, select Browse.



- 3. Double-click on your module icon. The General dialog appears for your module.
- 4. From the General dialog, select Device Parameters tab to configure and set the parameters.

📓 1734-IE2C	2 Pt Curre	nt Input		? ×
General Dev	ice Paramet	ers EDS I/O Defa	sult	
1	734-IE2C 2	Pt Current Input		
<u>N</u> ame:	1734-IE2C 2	Pt Current Input		
<u>D</u> escription				
L L	~~			
Add <u>r</u> ess:				
	Device Ide	ntity [Primary]		
	Vendor:	Rockwell Automa	ion - Allen-Bradle	ey [1]
	Device:	Rockwell Automa	tion miscellaneou	ıs [115]
	Product:	1734-IE2C 2 Pt Ct	urrent Input [24]	
	Catalog:	1734-IE2C		
	Revision:	1.003		
	OK	Cancel	Apply	Help

5. An EDS Editor dialog appears. From the EDS Editor dialog, select Upload to load the existing parameters from the device.

EDS Ed	itor	X
?	Do you want to upload the configuration from the device, updating the software's configuration; or download the software's configuration to the device, updating the device?	1
	For more information, press F1	
	Upload Download Cancel	

6. In the Device Parameters dialog, select Configuration from the Groups dropdown list to select parameters.

1734-IE2L 2 Pt Lurrent Input	?
General Device Parameters EDS I	I/O Default
Groups Cn-L	ine
Configuration	Upload From Device
Restore Default Values	<u>D</u> ownload To Device
Parameter Help	ull <u>S</u> tart Monitor
Parameter	Current Value
(0002) Notch Filter	60 Hz
(0001) Update Rate	100 ms
(0007) Input Range #0	4mA to 20mA
(0008) Input Range #1	4mA to 20mA
🟦 (0009) Value Data Type #0	Signed Integer
🟦 (0010) Value Data Type #1	Signed Integer
(0011) Low Scaling #0	3277
(0012) Low Scaling #1	3277
(0013) High Scaling #0	16383
(0014) High Scaling #1	16383
(0015) Enable Alarm Latch #0	Disable
(0016) Enable Alarm Latch #1	Disable

- 7. Select one of the following options:
 - Single Select this option to change or configure parameters one at a time.
 - All Select this option to change all selections at once.

8. Change the configuration or apply the uploaded parameters. Select Download To Device to change the parameters.

1734-IE2C 2 Pt Current I	nput	an (11)	? ×
General Device Parameters	EDS IZ	U Default	
<u>G</u> roups	- Un-Lir	le	Upload From Device
	O Sir	ngle	
<u>R</u> estore Default Values	• All		
Parameter Help			<u>Start Monitor</u>
Parameter		Current Val	ue 🔼
(0018) Disable Alarms #1		Alarms Ena	bled
(0027) Digital Filter #0		0 ms	
(0028) Digital Filter #1		0 ms	
(0029) Low Alarm #0		3113	
(0030) Low Alarm #1		3113	
(0031) High Alarm #0		16547	
(0032) High Alarm #1		16547	
(0033) Low Low Alarm #0)	2867	
(0034) Low Low Alarm #1		2867	
(0035) High High Alarm #	0	16793	
(0036) High High Alarm #	1	16793	
(0043) Autobaud		Enable	-
•			
OK	Cano	:el	Apply Help

To configure the analog output module, proceed with the following procedure:

1. Double-click on your module icon.

The General dialog appears.

🖀 1734-0E2C 2 Pt Current Output (3)								
General Device Parameters EDS I/O Default								
1734-0E2C 2 Pt Current Output								
Name: 1734-0E2C 2 Pt Current Output (3)								
Description								
Address: 0								
Device Identity [Primary]								
Vendor: Rockwell Automation - Allen-Bradley [1]								
Device: Rockwell Automation miscellaneous [115]								
Product: 1734-0E2C 2 Pt Current Output [25]								
Catalog: 1734-0E2C								
Revision: 1.002								
OK Cancel Apply Help								

2. From the General dialog, select Device Parameters to set parameters. The EDS Editor dialog appears.

EDS Ed	itor	×
?	Do you want to upload the configuration from the device, updating the software's configuration; or download the software's configuration to the device, updating the device?	
	For more information, press F1	
	Upload Download Cancel	

3. From the EDS Editor dialog, select Upload to load the existing parameters from the device.

4. From the Device Parameters dialog, at the Groups dropdown list, select Configuration.

1734-OE2C 2 Pt Current General Device Parameters	Output	(3) O Defa	ult		?>	
Groups Configuration	On-Lir O Sir O All	ne ngle		Upload F Download Start	rom Device d To Device Monitor	
Parameter (0001) Group Run/Idle 0	Comm	Currei Idle	nt Val	ue	<u> </u>	
(0006) Output Range #0 (0007) Output Range #1	(0006) Output Range #0 (0007) Output Range #1			4mA to 20mA 4mA to 20mA		
(0008) Value Data Type (0009) Value Data Type	#0 #1	Signe Signe	d Inte d Inte	eger eger		
(0010) Fault State #0 (0011) Fault State #1		Goto Goto	Low Low	Clamp Clamp		
(0012) Idle State #0 (0013) Idle State #1		Goto	Low	Clamp Clamp		
(0014) Pault Value #0 (0015) Fault Value #1 (0016) Idle Value #0		0				
		-	_			
OK	Cano	el		Apply	Help	

5. From the Device Parameters dialog, set the Group Run/Idle Command parameter to Idle or Run. Any parameter with a lock symbol indicates that it is nonchangeable.

1734-0E2C 2 Pt Curren	t Outpul	: (3)		? ×			
General Device Parameters EDS I/O Default							
Groups	⊢On-Lir	ne					
Configuration -		nalo	Upload F	rom Device			
Restore Default Values		rigie	Download	d To Device			
 Parameter Help			<u>S</u> tart	Monitor			
Parameter		Current Val	ue	^ _			
(0001) Group Run/Idle	Comm	Idle		•			
(0006) Output Range #	:0	Ide					
(0007) Output Range #	:1	Run					
🔒 (0008) Value Data Type	e #0	Signed Inte	eger				
🟦 (0009) Value Data Type	e #1	Signed Inte	eger				
(0010) Fault State #0		Go to Low	Clamp				
(0011) Fault State #1		Go to Low	Clamp				
(0012) Idle State #0		Go to Low	Clamp				
(0013) Idle State #1		Go to Low	Clamp				
(0014) Fault Value #0		0					
(0015) Fault Value #1		0					
(0016) Idle Value #0		0					
1		1					
ОК	Can	cel	Apply	Help			

- 6. Select values for current or voltage.
 - For current, select 0...20 mA or 4...20 mA.
 - For voltage, select 0...10V or -10...+10V

1734-0E2C 2 Pt Current	Output	(3)			? ×		
General Device Parameters EDS I/O Default							
Groups Configuration ▼ <u>R</u> estore Default Values <u>P</u> arameter Help	On-Lir O Sir O All	ne		<u>U</u> pload F <u>D</u> ownload <u>S</u> tart	rom Device 1 To Device Monitor		
Parameter		Curre	nt Val	ue	<u> </u>		
(0001) Group Run/Idle C	Comm	Idle					
(0006) Output Range #0)	4mA to 20mA 🔹					
(0007) Output Range #1		4mA to 20mA					
🟦 (0008) Value Data Type	#0	0 V to	10 V	(Invalid)			
🟦 (0009) Value Data Type	#1	OmA t	o 20m	A A damarkan			
(0010) Fault State #0		0V to 5V (Invalid)			-		
(0011) Fault State #1		Golo	Low	Clamp			
(0012) Idle State #0		Go to Low Clamp					
(0013) Idle State #1		Go to Low Clamp					
(0014) Fault Value #0		0					
(0015) Fault Value #1		0					
(0016) Idle Value #0		0					
•							
OK	Cano	el		Apply	Help		

Fault states include the following:

- Hold Last State
- Go to Low Clamp
- Go to High Clamp
- Go to Fault Value

1734-0E2C 2 Pt Current	Output	(3)		? ×
General Device Parameters	EDS I/	0 Default		
Groups Configuration	On-Lir O Sii	ne ngle	Upload Fro	om Device
<u>R</u> estore Default Values Parameter Help	• AI		<u>D</u> ownload <u>S</u> tart M	lonitor
Parameter		Current Val	ue	<u> </u>
(0001) Group Run/Idle C	omm	Idle		
(0006) Output Range #0		4mA to 20n	hΑ	
(0007) Output Range #1		4mA to 20n	hΑ	
🟦 (0008) Value Data Type :	#0	Signed Inte	ger	
🟦 (0009) Value Data Type :	#1	Signed Inte	ger	
(0010) Fault State #0		Go to Low (Clamp	-
(0011) Fault State #1		Hold Last Si	tate	
(0012) Idle State #0		Go to Low (Clamp	
(0013) Idle State #1		Go to High	Clamp	
(0014) Fault Value #0		U to Fault	value	
(0015) Fault Value #1		0		
(0016) Idle Value #0		0		-
		1		
OK	Cano	el	Apply	Help

7. For parameter Enable Alarm Latch, select Disable or Enable Latching Alarms from the dropdown list.

1734-0E2C 2 Pt Current Output General Device Parameters EDS I/	(3) ? ×
Groups Configuration Bestore Default Values Barameter Help	ngle Upload From Device
Parameter	Current Value
(0018) Low Scaling #0	1638
(0019) Low Scaling #1	1638
(0020) High Scaling #0	8191
(0021) High Scaling #1	8191
(0022) Low Clamp #0	-32768
(0023) Low Clamp #1	-32768
(0024) High Clamp #0	32767
(0025) High Clamp #1	32767
(0026) Enable Alarm Latch #0	Disable 🔹
(0027) Enable Alarm Latch #1	Disable
(0028) Disable Alarms #0	Enable Latching Alarms
(0029) Disable Alarms #1	Alarms Enabled
OK Cano	cel <u>Apply</u> Help

8. For parameter Disable Alarms, select Alarms Enabled or Alarms Disabled from the dropdown list.



9. For parameter Autobaud, select Enable or Disable from the dropdown list.

	1734-0E2C 2 Pt Current	Output	(3)	?	×
G	eneral Device Parameters	EDS I/	0 Default		
	Groups Configuration ■ Bestore Default Values	On-Lir O Sir O All	ngle	Upload From Device	
-	Parameter Help		Current Va		
	(0019) Low Scaling #1		1638		
	(0020) High Scaling #0		8191		
	(0021) High Scaling #1		8191		
	(0022) Low Clamp #0		-32768		
	(0023) Low Clamp #1		-32768		
	(0024) High Clamp #0		32767		
	(0025) High Clamp #1		32767		
	(0026) Enable Alarm Lat	ch #0	Disable		
	(0027) Enable Alarm Lat	ch #1	Disable		
	(0028) Disable Alarms #	0	Alarms Enabled		
	(0029) Disable Alarms #	1	Alarms Ena	abled	
	(0036) Autobaud		Enable		
	•	_	Enable		
	ОК	Cano	Disable cel	Apply Help	

With current or voltage modules if you change range values, it affects the range or scaling of the module.

POINT I/O Module Data

Read this chapter for information about module status, input, output, configuration data, and default data maps for POINT I/O modules to include the following:

- Digital input modules
- Digital output modules
- Relay output modules
- Analog input modules
- Analog output modules
- POINTBlock I/O modules

Read this section for information about digital input modules.

Digital DC Input Modules

The POINT I/O digital DC input modules feature the following:

- 24V DC nominal DC inputs
- Input range of 10...28.8V DC
- 2, 4, or 8 sinking or sourcing style inputs
- Autobaud (matches the communication rate of existing devices on the network)
- Selectable input filter times (0...65 ms with 1 ms default)
- Sequential auto addressing

I/O messages are sent to (consumer) and received from (producer) these POINT I/O modules. These messages are mapped into the processor memory^(a). These POINT I/O modules produce 1 byte of input data (scanner Rx). They do not consume I/O data (scanner Tx).

Default Data Map - 1734-IB2 and 1734-IV2

Message Size: 1 Byte

	7	6	5	4	3	2	1	0
Produce (scanner Rx)	Not used						Ch1	ChO
Consume (scanner Tx)	No consumed data							
Where:	ChO = Inp	ut channe	el O, Ch1 =	Input char	nnel 1; 0 =	Off, 1 = On		

Default Data Map - 1734-IB4, 1734-IB4K, and 1734-IV4

Message Size: 1 Byte

	7	6	5	4	3	2	1	0
Produce (scanner Rx)	Not used	d Ch3 Ch2 Ch1						
Consume (scanner Tx)	No consumed data							
Where:	ChO = Input channel 0, Ch1 = Input channel 1, Ch2 = Input channel 2, Ch3 = Input channel 3; O = Off, 1 = On							

Digital Input Modules

⁽a) These are mapped through scan lists in DeviceNet networks and Direct, Listen Only, or Rack Optimized connections in ControlNet and EtherNet/IP networks.

Default Data Map - 1734-IB8, 1734-IB8K, 1734-IV8, and 1734-IV8K

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	
Consume (scanner Tx)	No consumed data								
Where:	ChO = Inpu channel 3, Ch7 = Inpu	ut channel (Ch4 = Inpu it channel 7	D, Ch1 = Inp it channel 4 7; 0 = Off, 1	ut channel 4, Ch5 = Inp = On	1, Ch2 = Inp out channel	out channe 5, Ch6 = In	2, Ch3 = In put channe	iput II 6,	

Default Data Map - 1734-IB4D - Produced Assembly Instance 101

Message Size: 2 Bytes

	7	6	5	4	3	2	1	0		
Produce 0 (Rx)	Fault 3	Fault 2	Fault 1	Fault O	Input 3	Input 2	Input 1	Input O		
Produce 1 (Rx)	SC 3	SC 2	SC 1	SC O	OW 3	OW 2	0W 1	0W 0		
Consume (Tx)	No consi	No consumed data								
Where:	0W = 0p	OW = Open wire, SC = Short circuit, Fault = Open wire or short circuit								

Default Data Map - 1734-IB4D - Produced Assembly Instance 23

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce 0 (Rx)	Fault 3	Fault 2	Fault 1	Fault O	Input 3	Input 2	Input 1	Input O	
Consume (Tx)	No consumed data								
Where:	Fault = Op	oen wire or	short circ	uit					

Default Data Map – 1734-IB4D – Configuration Assembly Instance 103

Message Size: 18 Bytes

	7	6	5	4	3	2	1	0
Consume O	Input 0 Off to On Filter	Byt	e O					
Consume 1	Input 0 Off to On Filter	Byt	e 1					
Consume 2	Input 0 On to Off Filter	Byt	e O					
Consume 3	Input 0 On to Off Filter	Byt	e 1					
Consume 4	Input 1 Off to On Filter	Byte	e 0					
Consume 5	Input 1 Off to On Filter	Byte	e1					
Consume 6	Input 1 On to Off Filter	Byte	e 0					
Consume 7	Input 1 On to Off Filter	Byte	e1					
Consume 8	Input 2 Off to On Filter	Byt	e O					
Consume 9	Input 2 Off to On Filter	Byt	e 1					
Consume 10	Input 2 On to Off Filter	Byt	e O					
Consume 11	Input 2 On to Off Filter	Byt	e 1					
Consume 12	Input 3 Off to On Filter	Byt	e O					
Consume 13	Input 3 Off to On Filter	Byt	e 1					
Consume 14	Input 3 On to Off Filter	Byt	e O					
Consume 15	Input 3 On to Off Filter	Byt	e 1					
Consume 16	Autobaud Disable				Enable OW3	Enable OW2	Enable OW1	Enable OWO
Consume 17	Produced Assembly In:	stan	се					
Produce (Rx)	No produced data							
Where:	OW = Open wire							

Digital AC Input Modules

The 1734 digital AC input modules feature the following:

- 120/220V AC nominal are AC inputs
- Input range of 65...132 for 120V AC inputs; 159...264 for 220V AC inputs
- Two sinking style inputs
- Autobaud (matches the communication rate of existing devices on the network)
- Selectable input filter times (0...65 ms with 1 ms default)
- Sequential auto addressing

I/O messages are sent to (consumer) and received from (producer) these POINT I/O modules. These messages are mapped into the processor memory^(a). These POINT I/O modules produce 1 byte of input data (scanner Rx). They do not consume I/O data (scanner Tx).

Default Data Map - 1734-IA2 and 1734-IM2

Message Size: 1 Byte

	7	6	5	4	3	2	1	0		
Produce (scanner Rx)							Ch1	ChO		
Consume (scanner Tx)	No consu	No consumed data								
Where:	ChO = Channel 0, Ch1 = Channel 1; 0 = Off, 1 = On									

Default Data Map - 1734-IA4, 1734-IA4K, and 1734-IM4

Message Size: 1 Byte

	7	6	5	4	3	2	1	0
Produce (scanner Rx)					Ch3	Ch2	Ch1	ChO
Consume (scanner Tx)	No consu	med data						
Where:	ChO = Cha	annel O, Ch	1 = Channe	el 1, Ch2 = 0	Channel 2, I	Ch3 = Char	nnel 3; 0 =	Off, 1 = On

Digital Output Modules

Read this section for information about digital output modules.

Digital DC Output Modules

The features of DC output modules include the following:

- 24V DC outputs with a range of 10...28.8V DC
- Output diagnostic features are incorporated to assist in troubleshooting
- Current limited outputs of up to 2 A with respect to their DC return
- Autobaud (matches the communication rate of existing devices on the network)
- Sequential auto addressing

I/O messages are sent to (consumer) and received from (producer) these POINT I/O modules. These messages are mapped into the processor memory^(a). These POINT I/O modules produce 1 byte of input data (scanner Rx). They consume 1 byte of output data (scanner Tx).

⁽a) These are mapped through scan lists in DeviceNet networks and Direct, Listen Only, or Rack-optimized connections in ControlNet and EtherNet/IP networks.

Default Data Map - 1734-0B2, 1734-0B2E, and 1734-0V2E

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Not	used			•		Ch1	ChO	Channel status (1734-0B2E module only) ⁽¹⁾
Where:	0 = 1	lo err	or, 1 =	Error					
Message Size: 1 Byte									
	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Not	used					Ch1	ChO	Channel state
Where:	0 = 0)ff.1=	On						

 The 1734-0B2, 1734-0B4, 1734-0B4K, 1734-0B8, and 1734-0B8K digital DC output modules produce 1 byte of data (scanner RX), but it is always zero.

Default Data Map - 1734-0B4, 1734-0B4K, 1734-0B4E, and 1734-0V4E

Message Size: 1 Byte

	7	6	5	4	3	2	1	0			
Produce (scanner Rx)	Not used			Ch3	Ch2	Ch1	ChO	Channel status (1734-0B4E module only) ⁽¹⁾			
Where:	0 = No	0 = No error, 1 = Error									
Message Size: 1 Byte											
	7	6	5	4	3	2	1	0			
Consume (scanner Tx)	Not used				Ch3	Ch2	Ch1	ChO	Channel state		

Where: 0 = Off, 1 = On

 The 1734-0B2, 1734-0B4, 1734-0B4K, 1734-0B8, and 1734-0B8K digital DC output modules produce 1 byte of data (scanner RX), but it is always zero.

Default Data Map - 1734-0B8, 1734-0B8K, 1734-0B8E, 1734-0B8EK, 1734-0V8E, and 1734-0V8EK

Message Size: 1 Byte

	7	6	5	4	3	2	1	0			
Produce (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Channel status (1734-0B8E and1734-0B8EK module only) ¹⁾		
Where:	0 = No error, 1 = Error										
Message Size: 1 Byte											
	7	6	5	4	3	2	1	0			
Consume (scanner Tx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Channel state		
Where:	0 = 0f	f, 1 = On									

 The 1734-0B2, 1734-0B4, 1734-0B4K, 1734-0B8, and 1734-0B8K digital DC output modules produce 1 byte of data (scanner RX), but it is always zero.

Default Data Map - 1734-0B2EP

Message Size: 1 Byte

	7	6	5	4	3	2	1	0				
Produce (scanner Rx)	Not u	sed					Ch1	ChO	Channel status			
Where:	0 = N	o erroi	r, 1 = Err	or					·			
Message Size: 1 Byte												
	7	6	5	4	3	2	1	0				
Consume (scanner Tx)	Not u	Not used Ch1 Ch0 Channel state										
Where:	0 = 0	0 = Off, 1 = On										

Digital AC Output Modules

The 1734-0A2 AC output module features include the following:

- 120V AC outputs with a range of 74...264V AC (120/220V AC nominal)
- Each output is rated at 0.10 A minimum to 0.75 A maximum
- Autobaud (matches the communication rate of existing devices on the network)
- Sequential auto addressing

Default Data Map - 1734-0A2

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	No pro	oduced	data						
Consume (scanner Tx)	Not used Ch1 Ch0								Channel state
Where:	0 = 0f	f, 1 = Or	1						

Default Data Map - 1734-0A4 and 1734-0A4K

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	No pro	oduced	data						
Consume (scanner Tx)	Not us	sed	Channel state						
Where:	0 = 0	ff, 1 = C)n						

Relay Output Modules

The relay output modules consist of 1734-0W2, 1734-0W4, and 1734-0X2 relay output modules. Features of the 1734-0W2 and 1734-0W4 relay modules include the following:

- Type A normally open relays
- · Sink or source current with respect to power or return
- Contact outputs isolated from each other
- Each output rated 5...240V DC/V rms at 2 A (current is load-dependent)
- Autobaud (matches the communication rate of existing devices on the network)
- Sequential auto addressing

Features of the 1734-0X2 relay modules include the following:

- Two Form C isolated (normally open; normally closed) electromechanical relays
- · Sink or source current with respect to power or return
- Contact outputs isolated from each other
- Each output rated 5...240V DC/V rms at 2 A (current is load-dependent)
- Autobaud (matches the communication rate of existing devices on the network)
- Sequential auto addressing

I/O messages are sent to (consumer) and received from (producer) these POINT I/O modules. These messages are mapped into the processor memory.

Default Data Map - 1734-0W2

Message Size: 1 Byte												
	7	6	5	4	3	2	1	0				
Produce (scanner Rx)	No proc	o produced data										
Consume (scanner Tx)	Not use	ed					Ch1	ChO	Channel state			
Where:	0 = Off	, 1 = On										

Default Data Map - 1734-0W4 and 1734-0W4K

Message Size: 1 Byte													
	7	6	5	4	3	2	1	0					
Produce (scanner Rx)	No pro	produced data											
Consume (scanner Tx)	Not use	ed		Channel state									
Where:	0 = Off	, 1 = On											

Default Data Map - 1734-0X2

Message Size: 1 Byte													
	7	6	5	4	3	2	1	0					
Produce (scanner Rx)	No pro	produced data											
Consume (scanner Tx)	Not us	ot used Ch1 Ch0 Channel state											
Where:	0 = No 1 = Nor	D = Normally open contact Off, Normally closed contact On I = Normally open contact On, Normally closed contact Off											

Analog Input Modules

The 1734-IE2C analog input module is a two-channel module that converts an analog input current to a digital value. The module resolution is 16 bits across 0...21 mA. The module has two modes:

- 0...20 mA
- 4...20 mA (default mode)
- Scaling to any 16-bit signed integer (-32,768...+32,767) Default for 1734-IE2C scalers are 3277 @ 4 mA for low and 16,383 @ 20 mA for high
- Operates in Unipolar mode

The 1734-IE2V analog input module is a two-channel module that converts an analog input voltage to a digital value. The module resolution is 16 bits across -10...+10V. The module has two modes.

- 0...10V DC (default mode)
- ±10V DC
- Scaling to any 16-bit signed integer (-32,768...+32,767) Default for 1734-IE2V scalers are 0 @ 0V for low and 10,000 @ 100V for high
- Operates in Unipolar or Bipolar modes

Data

The 1734-IE2C module operates in unipolar mode only. The 1734-IE2V module operates in unipolar or bipolar modes. Data returned from the module is scaled by the user to any 16-bit signed integer (-32,768...+32,767). The 6 bytes of data are read from the 1734-IE2C and 1734-IE2V modules. No data is written to the input modules.

- Channel O Data (2 bytes)
- Channel 1 Data (2 bytes)
- Channel O Status (1 byte)
- Channel 1 Status (1 byte)

Communicate with Your Module

I/O messages are sent to (consumer) and received from (producer) the POINT I/O modules. These messages are mapped into the processor's memory^(a). These POINT I/O input modules produce 6 bytes of input data (scanner Rx) and fault status data. It does not consume output data (scanner Tx).

⁽a) These are mapped through scan lists in DeviceNet networks and Direct, Listen Only, or Rack-optimized connections in ControlNet and EtherNet/IP networks.

Default Data Map - 1734-IE2C and 1734-IE2CK

Message Size: 6 Bytes																
	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
	Input C	Channel	0 High E	lyte					Input	Channel C) Low Byte	9				
Produce (cooppor Dy)	Input Channel 1 High Byte Input Channel 1 Low Byte															
	Status Byte for Channel 1 Status Byte for Channel 0															
	OR	UR	HHA	LLA	HA	LA	CM	CF	OR	UR	HHA	LLA	HA	LA	CM	CF
Consume (scanner Tx)	No con	nsumed	data													
Where:	CF = CI $LA = Lc$ $LLA = I$ $UR = U$ $CM = C$ $HA = HI$ $HHA =$ $OR = O$	hannel F ow Alarn Low/Lov nderran alibratic igh Alarn High/Hic verrang	Fault sta n; 0 = No v Alarm; ge; 0 = 1 on Mode m; 0 = N gh Alarm e; 0 = No	tus; $0 =$ 0 = rror, 0 = ror = ror, 0 = rror, 0 = r	No erro I = Fault error, 1 = (, 1 = Fau rmal, 1 = 1 = Fault error, 1 I = Fault	r, 1 = Fault Fault It Calibra = Fault	ult tion mo	de								

Default Data Map - 1734-IE2V

Message Size: 6 Bytes																
	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
	Input	Channel () High By	/te					Input	Channel	O Low By	/te				
Produce (cooppor Py)	Input	Channel 1	l High By	te					Input Channel 1 Low Byte Status Byte for Channel O							
	Status	s Byte for	Channe	1												
	OR	UR	HHA	LLA	HA	LA	CM	CF	OR	UR	HHA	LLA	HA	LA	CM	CF
Consume (scanner Tx)	No co	nsumed o	lata													
Where:	CF = C LA = L LLA = UR = L CM = C HA = H HHA = OR = C	Channel F .ow Alarm Low/Low Inderrand Calibratio Ligh Alarn High/Hig Overrange	ault stat n; 0 = No darm; 0 ge; 0 = N n Mode; n; 0 = No h Alarm; c; 0 = No	us; 0 = N error, 1 = 0 = No er 0 = Norn 0 = Norn 0 = No e error, 1 error, 1	o error, = Fault ror, 1 = F I = Fault nal, 1 = C = Fault error, 1 = = Fault	1 = Fault Fault Falibration Fault	t on mode									

Scaling

Select scaling for each channel by making the selection on the configuration dialog. Scaling is the conversion of unscaled data to engineering units.

The high and low scalers (Engineering Units) are signed integers. There are no restrictions on these units.

- Defaults for 1734-IE2C scalers are 3277 @ 4 mA for low and 16,383 @ 20 mA for high.
- Defaults for 1734-IE2V scalers are 0 @ 0V for low and 10,000 @ 100V for high.

Set each scaler individually or on a per channel basis.

The 1734-IE2C module reads a current input between 0 mA or 4 mA (low) and 20 mA (high) dependent on the mode selected. The 1734-IE2V module reads a voltage input between -10V or 0V (low) and +10V (high) dependent on mode selected.

Channel Status

Channel Status Byte

Channel Sta	atus Byte						
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit O
Overrange	Underrange	High High Alarm	Low Low Alarm	High Alarm	Low Alarm	CAL Mode	Channel Fault

- Channel Fault Description General channel health bit indicates whether the module is operating with or without faults. If any alarms or faults are detected, this bit is set. Channel Status can be read on a per channel basis or by reading the Channel Status Byte (Bit 0) in the Module Produce Assembly.
- Calibration Mode Bit This bit (Channel Status Bit 1) is set when you begin calibration. See the chapter <u>Calibrate Your Analog Modules on page 71</u> for calibration details. When set, the channel status indicator flashes green.
- Low Alarm Value Bit When the input signal is less than the Low Alarm value, this bit (Channel Status Bit 2) is set. The default value for this alarm is as follows:
 - 1734-IE2C module is 3113 counts (3.8 mA)
 - 1734-IE2V module is 500 counts = 500 mV (0.5V)
- High Alarm Value Bit When the input signal is more than the High High Alarm value, this bit (Channel Status Bit 3) is set. The default value for this alarm is as follows:
 - 1734-IE2C module is 16,547 counts (20.2 mA)
 - 1734-IE2V module is 9500 counts = 9500 mV (9.5V)
- Low Low Alarm Value Bit When the input signal is less than the Low Low Alarm value, this bit (Channel Status Bit 4) is set. The default value for this alarm is as follows:
 - 1734-IE2C module is 2867 counts (3.5 mA)
 - 1734-IE2V module is 200 counts = 200 mV (0.2V)
- High High Alarm Value Bit When the input signal is more than the High Alarm value, this bit (Channel Status Bit 5) is set. The default value for this alarm is as follows:
 - 1734-IE2C module is 16,792 counts (20.5 mA)
 - 1734-IE2V module is 9800 counts = 9800 mV (9.8V)
- Underrange Status Bit This bit (Channel Status Bit 6) is set when the module returned data is at a minimum. 1734-IE2C module is 98 counts (around 120 μA); 1734-IE2V module is -0.25 or -10.25V, depending on range. When set, the channel status indicator flashes red.
- Overrange Status Bit This bit (Channel Status Bit 7) is set when the module returned data is at a maximum. 1734-IE2C module is around 21 mA. 1734-IE2V module is +10.25V. When set, the channel status indicator flashes red.

Latch Alarms

The latch alarms let low and high alarm status information to be latched when an alarm is set. Even if an alarm is momentarily set, the status bit stays set until a reset latch service is issued. The default setting is Unlatched. Each channel can be configured individually.

Alarm Disable

This function disables all channel alarms and faults so they are not reported in the channel status field. The channel indicator stays steady green, alarms are ignored. The default state is Alarms Enabled. Each channel can be configured individually.

Calibration Status

This status bit is set when the channel is in Calibration mode. At Begin Calibration, the module is put into Calibration mode. This bit is reset when the Accept Low Calibration, or Accept High Calibration, commands are sent. This is **not** the Bad Calibration Status bit, which is set if the module is **not** calibrated.

Digital Filter

A digital filter is available on the input modules. You set a time constant that is used in the equation:

 $Yn = Yn-1 + (dt / (dt + T_{\Delta}) * (Xn-Yn-1))$

Where:

Yn = New data

Yn-1 = Old data

dt = Channel update rate in milliseconds

T_A = Digital filter time constant

Xn = Present unfiltered data

 T_A can be an integer from 0...10,000 ms. If set to 0, the filter is disabled.

The default setting is disabled. This is done by setting the time constant (TA) to zero. Each channel can be configured individually for time constant but the update rate (dt) is done on a per module basis.

Update Rate

The update rate determines how often a channel is scanned. The maximum rate is determined by the notch filter setting. The minimum update rate is 10,000 ms.

- 120 ms maximum update rate 50 Hz
- 100 ms update rate 60 Hz
- 24 ms update rate 250 Hz
- 12 ms update rate 500 Hz

Notch Filter

Select a notch filter. The notch filter is for both inputs. Valid settings are the following:

- 50 Hz 120 ms maximum update rate
- 60 Hz 100 ms update rate
- 250 Hz 24 ms update rate
- 500 Hz 12 ms update rate

The update rate determines the rate at which the inputs are sampled. The maximum update rate is determined by the notch filter setting. The notch filter parameter is used to select the fastest possible rate. The minimum update rate is 10,000 ms.

Alarms

Available alarms include the following:

- Low
- Low Low
- High
- High High

Each alarm has one status bit, which is set to indicate when the input goes beyond its setpoint. All Alarm Status bits can be read individually or from the Channel Status Byte (bits 2...5).

You can configure each channel alarm individually.

Range Status

The module reports both Underrange and Overrange status.

- Underrange Status This bit (Channel Status Bit 6) is set when the module returned data is at a minimum.
 - For the 1734-IE2C module, the value is 98 counts (around 120 μA).
 - For the 1734-IE2V module, the value is -0.25 or -10.25V, depending on mode.
 - When set, the channel status indicator flashes red.
 - On the 1734-IE2C module, a wire-off condition sets this bit.
- Overrange Status This bit (Channel Status Bit 7) is set when the module returned data is at a maximum.
 - For the 1734-IE2C module, the value is around 21 mA.
 - For the 1734-IE2V module, the value is +10.25V.
 - When set, the channel status indicator flashes red.
 - On the 1734-IE2V module, a wire-off condition sets this bit.

Channel Indicator Behavior

See the table for a listing of channel indicator states for given module conditions.

Indication	Probable Cause
Channel Status	
Off	The module is in CAL mode.
Steady green	Normal (channel scanning inputs)
Flashing green	The channel is being calibrated.
Steady red	No power or major channel fault
Flashing red	Channel is at the end of range: For 1734-IE2C module: 0 mA or 21 mA For 1734-IE2V module: -0.25V, -10.25V, or +10.25V

Analog Output Modules

The 1734-0E2C analog output module is a two-channel module that converts a digital code to an analog output current. The module resolution is 13 bits across 0...21 mA.

The 1734-OE2V analog output module is a two-channel module that converts a digital code to an analog output voltage. The module resolution is 14 bits across -10...+10V.

Data

The 1734-0E2C module operates in Unipolar mode; the 1734-0E2V module operates in Unipolar or Bipolar modes. Data sent to the module is scaled by the user to any 16-bit number. All data sent to the module is signed integer, ranging from -32,768...+32,767 counts.

The 1734-OE2C module:

- Consumes 4 bytes of data (scanner Tx) in this format:
 - Channel O Data (2 bytes)
 - Channel 1 Data (2 bytes)
- Produces 2 bytes of data (scanner Rx) in this format:
 - Channel O Status (1 byte)
 - Channel 1 Status (1 byte)

Default Data Map - 1734-0E2C and 1734-0E2CK

Message Size: 4 Bytes																			
	15	14	13	12	11	10	09	80	07	06	05	04	03	02	01	00			
Consume (Tx)	Output	Output Channel O High Byte									el O Low	Byte							
	Output	utput Channel 1 High Byte Output Channel 1 Low Byte																	
Message Size: 2 Bytes																			
	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00			
Produce (Py)	High By	yte - Cha	annel 1 S	tatus					Low By	/te - Cha	annel O	Status							
	Not us	ed			HCA	LCA	CM	CF	Not us	ed			HCA	LCA	CM	CF			
Where:	CF = CI CM = C LCA = I HCA =	hannel F alibratic Low Clar High Cla	ault sta n Mode; np Alarn mp Alari	tus; 0 = 0 = Nor n; 0 = No m; 0 = N	No error, 1 mal, 1 = Ca error, 1 = o error, 1 =	= Fault alibration Fault = Fault	mode												

The 1734-0E2V module:

- Consumes 4 bytes of data (scanner Tx) in this format:
 - Channel O Data (2 bytes)
 - Channel 1 Data (2 bytes)
- Produces 2 bytes of data (scanner Rx) in this format:
 - Channel O Status (1 byte)
 - Channel 1 Status (1 byte)

Default Data Map - 1734-0E2V and 1734-0E2VK

Message Size: 4 bytes																			
	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00			
Consume (Tx)	Outpu	t Chann	el O Hig	h Byte	•				Outpu	it Chanr	nel O Lo	w Byte		•					
	Outpu	t Chann	el 1 Higł	n Byte					Outpu	ıt Chanr	nel 1 Lov	v Byte							
Message Size: 2 Bytes																			
	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00			
Droduce (Dy)	High Byte Channel 1 Status									lyte Cha	nnel O	Status							
FIDUULE (NX)	Not us	sed			HCA	LCA	CM	CF	Not u	sed			HCA	LCA	CM	CF			
Where:	CF = 0 CM = 0 LCA = HCA =	Channel Calibrati Low Cla High Cla	Fault st on Mode mp Alar amp Ala	atus; 0 e; 0 = N m; 0 = rm; 0 =	= No erro lormal, 1 = No error, No error,	r, 1 = Fault Calibratior 1 = Fault 1 = Fault	ı mode												

Operational Modes

The 1734-0E2C module has these modes:

- 0...20 mA
- 4...20 mA (Default mode)

The 1734-0E2V module has these modes:

- O... 10V DC (Default mode)
- -10...+10V DC

You can set Channel Mode individually. The effective difference in the two modes is how you apply the scalers. There is no internal offset, meaning that the resolution is not changed.

For the 1734-0E2C module, in both modes, you assign the high scaler the value of 20 mA. For the low scaler you assign the following:

- In 0...20 mA mode, the value of 0 mA
- In 4...20 mA mode, the value of 4 mA

For the 1734-OE2V module, in both modes, you assign the high scaler the value of +10V. For the lower scaler you assign the following:

- In 0...10V mode, the value of 0V
- In ±10V mode, the value of -10V

Scaling

Scaling is the conversion of unscaled data to engineering units. The high and low scalers (engineering units) are Signed Integers. There are no restrictions on these units.

Default scaling points are 1638 @ 4 mA and 8191 @ 20 mA counts for the 1734-0E2C module and 0 and 10,000 for the 1734-0E2V module. Each scaler can be set individually and on a per-channel basis.

The 1734-OE2C module calculates and outputs a current between 0 mA or 4 mA (low scaler) and 20 mA (high scaler); the 1734-OE2V module calculates and outputs a voltage between -10V or 0V (low scaler) and +10V (high scaler).

Since scalers have no restrictions, use care when configuring the module. If the lower scaler is set to -32,768 and the module is in 4...20 mA (or -10V...+10V) mode, the module is incapable of setting the output to 0 mA (or less than -10V on the 1734-0E2V module) because that requires a number smaller than -32,768. -32,768 is the smallest number that you can represent with a signed integer.

Fault and Idle/Program Mode Action

You can select what happens to the output if a fault occurs or if the module is in Idle/Program mode. The choices are the following:

- Hold Last State
- Low Clamp
- High Clamp
- User Defined Value

The module default for both Fault and Idle/Program state is Low Clamp. All values are scaled. You can set each action individually and on a per channel basis. For an example of what would happen if the module lost communication, see the table.

Channel Configuration	When A Fault Occurs	When the Module is in Idle/Program Mode
Module Mode = 420 mA with Scalers set at 0 and 8191 counts Low Clamp = 0 counts High Clamp = 8191 counts Fault State = User Defined Idle State = Low Clamp Fault Value = 4095 counts	Channel O goes to 4095 counts, which equals 12 mA.	Channel O goes to O counts, which equals 4 mA.
Module Mode = 010V with Scalers set at 0 and 10,000 counts Low Clamp = 0 counts High Clamp = 10000 counts Fault State = User Defined Idle State = Low Clamp Fault Value = 5000 counts	Channel O goes to 5000 counts, which equals 5V.	Channel O goes to O counts, which equals OV.

Channel Status

The module status bits included in each Channel Status Byte are the following:

- Channel Fault
- CAL Mode

.

- Low Clamp
- High Clamp

Channel Status can be read individually using RSNetWorx software or by reading the Channel Status Byte in the Module Produce Assembly.

Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit O
Not Used				High Clamp	Low Clamp	CAL Mode	Channel Fault

- Channel Fault Bit This general channel health bit (Channel Status Bit 0) indicates that the module is operating with or without faults. If any alarms or faults are detected, this bit is set.
- Calibration Status Bit This status bit (Channel Status Bit 1) is set when the channel is in Calibration mode. At Begin Calibration, the module is put into Calibration mode. This bit does not get set until the Output Low Reference or Output High Reference commands are sent. Do not confuse this bit with the Bad Calibration Status bit, which is set if the module is **not** calibrated.
- Low Clamp Status Bit This status bit (Channel Status Bit 2) is set when the output data is clamped to its minimum level. The default value is -32,768 counts. Low Clamp Status can be read on a per-channel basis or by reading the Module Produce Assembly.
- High Clamp Status Bit This status bit (Channel Status Bit 3) is set when the output data is clamped to its maximum level. The default value is 32,767 counts. High Clamp Status can be read on a per channel basis or by reading the Module Produce Assembly.

Open-wire Detection (1734-OE2C and 1734-OE2CK only)

This condition has no unique status bit, but if an open-wire condition exists, the general Channel Status bit is set. The module cannot determine what the condition is: open wire or loss of field power. The channel indicators flash red.

Power Fail Detection (1734-0E2V and 1734-0E2VK only)

This condition has no unique status bit, but if a power failure condition exists, the general Channel Status bit is set. The Channel indicators go to steady red.

Low and High Clamps

The clamps define the maximum and minimum values of the output. These default to the following with the data scaled:

- -32,768 counts (0 mA or 4 mA) and +32,767 counts (21 mA) for the 1734-0E2C module
- -32,768 counts (0 or -10V) and +32,767 counts (+10V) for the 1734-0E2V module

Each clamp can be set individually and on a per-channel basis. When the output value reaches the clamp value, a status bit is set, indicating the output has been clamped. The clamps are absolute. Regardless of what is sent to the module or what the fault state values are, the module does not operate outside these settings.

Latch Alarms

The latched alarms let low and high clamp status information to be latched. If an output is clamped momentarily, the clamp status bit stays set until a reset latch service is issued. The default setting is Unlatched. Each channel can be configured individually. You can enable the Latch on a per-channel basis.

Alarm Disable

This function disables all channel alarms and faults so they are not reported in the channel status field. The channel status indicator stays steady green, and Latch Alarms are ignored. Change of state has no effect on module behavior. The default state is Alarms Enabled. Each channel can be configured individually. You can disable Alarms on a per channel basis or they can be set with the Module Configuration Assembly.

Channel Indicators

See the table for channel indicator states for a given module condition.

Indiantian	Proba	Probable Cause								
Indication	1734-0E2C, 1734-0E2CK	1734-0E2V, 1734-0E2VK								
Channel Status	÷	·								
Off	The module is in CAL mode.									
Steady green	The channel is actively controlling the out	The channel is actively controlling the outputs.								
Flashing green	The channel is calibrating.									
Flashing red	Open wire or no power	Low/High Clamp alarm								
Steady red	Unrecoverable fault - May require device replacement	Loss of field power								

POINTBlock I/O Modules

Mount the 1734D input/output modules on DIN rail with an integrated DeviceNet communication interface, 8 inputs and 8 outputs, removable terminations, and a POINTBus expansion port.

The modules include a non-isolated DeviceNet communication interface. The 24V DC from the DeviceNet connection powers a non-isolated DC/DC converter that generates +5V DC that powers the POINTBlock electronics and connects to the POINTBus port to power the expansion I/O electronics.

Madula	Tern	nination	Voltogo	
nouule	Cage Clamp	Spring Clamp	vollaye	
1734D-IB8X0B8E	Х		12/2/.V DC	
1734D-IB8XOB8ES		Х		
1734D-IB8X0W8	Х		12/2/JV DC	
1734D-IB8X0W8S		Х		
1734D-IA8XOA8	Х		1201/ 10	
1734D-IA8XOA8S		Х	IZUV AC	
1734D-IA8XOW8	Х		120V AC	
1734D-IA8XOW8S		Х	IZUV AC	
1734D-IA16	Х		120V AC	
1734D-IA16S		Х	IZUV AC	
1734D-IB16	Х		12/2/.V DC	
1734D-IB16S		Х		





ATTENTION:

 Whatever field power you supply is connected to the internal field power bus. For example, if 120V AC is applied to the power connections, there will be 120V AC applied to the modules through the internal field power bus.
 POINT 1/0 modules to the right of the module will also have that internal power

 POINT I/O modules to the right of the module will also have that internal power bus voltage applied, unless you use a 1734-FPD, 1734-EP24DC, or 1734-EPAC module to interrupt and change the field power bus voltage.

I/O messages are sent to (consumer) and received from (producer) the POINT I/O modules. These messages are mapped into the processor's memory.

The 1734D-IB8XOB8E module produces 1 byte of input data (scanner Rx) status. It consumes 1 byte of output data (scanner Tx).

Default Data Map - 1734D-IB8X0B8E

Message Size: 1	Byte								
	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Input Data
Where:	0 = 0f	f, 1 = On							
Message Size: 1	Byte								
	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Output Data (or State)
Where:	0 = 0f	f, 1 = On							

The 1734D-IB8XOW8 module produces 1 byte of input data (scanner Rx) status. It consumes 1 byte of output data (scanner Tx).

Default Data Map - 1734D-IB8X0W8

Message Size: 1 Byte

	7	6	5	4	3	2	1	0		
Produce (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Input Data	
Where:	0 = Off,	Off, 1 = 0n								
Message Size: 1 Byte										
	7	6	5	4	3	2	1	0		
Consume (scanner Tx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Output Data	
Where	0 = 0 f f	0 = Off, 1 = On								

The 1734D-IA8XOA8 module produces 1 byte of input data (scanner Rx) status. It consumes 1 byte of output data (scanner Tx).

Default Data Map - 1734D-IA8X0A8

Message Size: 1 Byte

		1								
	7	6	5	4	3	2	1	0		
Produce (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Input Data	
Where:	0 = Off	Off, 1 = 0n								
Message Size: 1 Byte										
	7	6	5	4	3	2	1	0		
Consume (scanner Tx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Output Data	
Where:	0 = Off	D = Off, 1 = On								

The 1734D-IA8XOW8 module produces 1 byte of input data (scanner Rx) status) It consumes 1 byte of output data (scanner Tx).

Default Data Map - 1734D-IA8XOW8

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Input Data
Where:	0 = 0ff,	Off, 1 = On							
Message Size: 1 Byte									
	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Output Data
Where:	0 = 0ff,) = Off, 1 = On							

The 1734D-IA16 module produces 2 bytes of input data (scanner Rx). It does not consume output data (scanner Tx).

Default Data - 1734D-IA16

1essage Size: 2 Bytes																
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Produce (scanner Rx)	115	114	113	112	111	110	19	18	17	16	15	14	13	12	11	10
Consume (scanner Tx)	No co	consumed data														
Where:	lx = C	x = Channel x; 0 = Off, 1 = On														

For 1734D-IB16 modules, I/O messages are sent to (consumer) and received from (producer) the POINTBlock I/O modules. These messages are mapped into the processors memory. This module produces 2 bytes of input data (scanner Rx) and does not consume output data (scanner Tx).

Default Data - 1734D-IB16

Message Size:	2 bytes	;														
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Produce (scanner Rx)	115	114	113	112	111	110	19	18	17	16	15	14	13	12	11	10
Consume (scanner Tx)	No ci	No consumed data														
Where:	x = (x = Channel x; 0 = Off, 1 = On														

Notes:

Calibrate Your Analog Modules

Read this chapter for information about how to calibrate analog modules. Your analog I/O module is factory-calibrated. You may choose to recalibrate your module in your system to increase its accuracy for your specific application. This chapter covers the following:

- Tools required to calibrate analog modules
- How to calibrate analog current input modules
- How to calibrate analog current output modules
- How to calibrate analog voltage input modules
- How to calibrate analog voltage output modules

You do not have to configure a module before you calibrate it. If you decide to calibrate your analog I/O modules first, you can configure it at the same time.

IMPORTANT	Analog I/O modules can be calibrated on a channel by channel basis or with the channels grouped together. Regardless of which option you choose, we recommend you calibrate all channels on your module each time you calibrate. This helps you maintain consistent calibration readings and improve module accuracy.
	Calibration is meant to correct any hardware inaccuracies that may be present on a particular channel or in your system. The calibration procedure compares a known standard, either input signal or recorded output, with the channels performance and then calculates a linear correction factor between the measured and the ideal. The linear correction factor is applied on every input or output in the same manner to obtain maximum accuracy.

When you calibrate input modules, use current or voltage calibrators to send a signal to the module to calibrate it.

When you calibrate output modules, use a digital multimeter to measure the signal that the module is sending out.

Tools Required to Calibrate

To maintain your modules accuracy specifications, we recommend you use calibration instruments with specific ranges. See <u>Table 7</u> for a list of the recommended instruments for each module.

Table 7 - Calibration Instruments	for Your Anal	og Modules
-----------------------------------	---------------	------------

Module	Recommended Instrument Range
1734-IE2C or 1734-IE2CK	120 mA (±0.15 μA) current source
1734-0E2C or 1734-0E2CK	Digital multimeter better than 0.6 µA
1734-IE2V	Voltage source 010V (±0.3 mV)
1734-0E2V	Digital multimeter better than 0.5 mV

You must be online to calibrate your analog I/O modules. We recommend the module not be actively controlling a process when you calibrate it.

IMPORTANT The module ignores output data sent to the module until after calibration ends. This could be hazardous if active control were attempted during calibration.

Input calibration consists of the following steps for an example of 2 channels:

Calibrate the Analog

Current Input Module

- 1. Connect the calibration system.
- 2. Allow the system to warm up for at least 10 minutes.
- Connect a current or voltage source to channel 0 by applying 4 mA (current) or 0V (voltage).
- 4. Begin the calibration.
- 5. Select both channels.
- 6. Accept Low Calibration for channel 0 (both status indicators flash).
- 7. Set the current or voltage source to a high value (20 mA current; or +10V voltage).
- 8. Accept High Calibration for channel 0 (channel 0 status indicator turns off if calibration was good, but channel 1 status indicator still flashing).
- 9. Connect a current or voltage source to channel 1.
- 10. With High Calibration now applied to channel 1, accept High Calibration for channel 1.
- 11. Set the current or voltage source to Low value.
- 12. Accept Low Calibration for channel 1.

To calibrate your current input module, connect the module in a system similar to that shown in the below figure.

IMPORTANT Apply power to the power supply and module for at least 10 minutes before calibrating the module. This allows the internal temperatures to stabilize and reduces drift errors.


1. Double-click the icon to bring up the General parameter dialog.

📓 1734-IE20	2 Pt Current Input (4)	? ×				
General De	General Device Parameters EDS I/O Default					
ſ	1734-IE2C 2 Pt Current Input					
<u>N</u> ame:	1734-IE2C 2 Pt Current Input (4)					
Description						
Add <u>r</u> ess:	63					
	Device Identity [Primary]					
	Vendor: Rockwell Automation - All	en-Bradley [1]				
	Device: Rockwell Automation mise	cellaneous (115)				
	Product: 1734-IE2C 2 Pt Current In	put [24]				
	Catalog: 1734-IE2C					
	Revision: 1.002					
[OK Cancel	ypply Help				

From the General parameter dialog, select Device Parameters tab. The EDS Editor dialog appears.

EDS Edi	itor	x
?	Do you want to upload the configuration from the device, updating the software's configuration; or download the software's configuration to the device, updating the device?	
	For more information, press F1	
	Upload Download Cancel	

- 2. From the EDS Editor dialog, select Upload to load the configuration from the device.
- 3. The Device Parameters dialog appears. From the Groups dropdown list, select Calibration.

1734-IE2C 2 Pt Current Input (4	l)	? ×
General Device Parameters EDS I/	'O Default	
General Device Parameters EDS I/ Groups On-Lin Calibration Image: Calibration I/O - Input Values Image: Calibration PointBus Image: Calibration Parameter Image: Calibration Image: Calibration Image: Calibration Parameter Image: Calibration Image: Calibration Image: Calibration Image: Calibration Image: Calibration Image: Calibration Image: Calibration Image: Calibration Calibration Image: Calibration Calibration Image: Calibration Calibration Image: Calibration Calibration	B Derault ne ngle Upload From Device Download To Device Start Monitor Current Value Good Calibration Good Calibration None Do Nothing	e Groups dropdown lis
OK Cano	cel <u>A</u> pply Help	P

4. Select Calibration Command from the Parameter column, then set its value to Begin Calibration. Make sure that Single is selected.

1734-IE2C 2 Pt Current Input (4) ? ×	
General Device Parameters EDS I/	0 Default	
Groups On-Lin Calibration Si Restore Default Values C Al Parameter Help	re	Make sure that Single is selected.
Parameter Start Monitor Parameter Current Value (a) (0041) Bad Cal Status #0 Good Calibration (a) (0042) Bad Cal Status #1 Good Calibration (0044) Calibration Channel Sel None None (0045) Calibration Command Begin Calibration		
OK Can	cel <u>A</u> pply Help	

5. Select Download To Device.

Both channel status indicators turn off.

6. Select Calibration Channel Select from the Parameter column, then set its value to a channel which you want to calibrate.

1734-IE2C 2 Pt Current I	nput (4)		? ×
General Device Parameters	EDS I/	0 Default		
Groups Calibration ★ Restore Default Values Parameter Help	On∙Lir ⊙ Sii ⊙ All	ne	Upload Fro Download	om Device To Device fonitor
Parameter		Current Va	lue	
(0041) Bad Cal Status # (0042) Bad Cal Status #	0	Good Calibration Good Calibration		
(0044) Calibration Channel Sel		None 🔽		
		Channel 0 Channel 1 Both Chanr	nels	
OK	Cano	el	Apply	Help

7. Select Download To Device.

- 8. Set current source to 4.00 mA.
- 9. Select Calibration Command from Parameter column and set its value to Accept Low Calibration from the dropdown list.

1734-IE2C 2 Pt Current I	nput (4)			? X
General Device Parameters	EDS I/	0 Defa	ult		
Groups Calibration Restore Default Values Parameter Help	On-Lir © Sir © All	ie ngle		Upload Fi Download Start I	rom Device 1 To Device Monitor
Parameter		Curren	nt Val	ue	
🟦 (0041) Bad Cal Status #0)	Good	Calib	ration	
🟦 (0042) Bad Cal Status #1		Good Calibration			
(0044) Calibration Chann	el Sel	Channel 1			
(0045) Calibration Command		Begin Calibration 🔹			-
		Do No	thing		
		Begin	Calibr t Low	ation Calibration	
		Accep	t Higł	n Calibration	
		Abort (Calibri	ation	
OK	Cano	el		Apply	Help

10. Select Download To Device.

The status indicator for the channel being calibrated flashes.

- 11. Set the current source to 20 mA.
- 12. Select Calibration Command from Parameter column and set its value to Accept High Calibration from the dropdown list.
- 13. Select Download To Device.

Calibrate the Analog

Current Output Module

Calibration is complete when High and Low calibration for the selected channels are done successfully.

14. Repeat the above steps to calibrate the other channels, noting that both high and low inputs must be accepted in order for the module to finish calibration.

Calibration is now complete. If the module does not accept calibration (the status indicator still flashing), select Abort Calibration option from the dropdown list and start over.

To calibrate your output module, connect the module in a DeviceNet system similar to the one shown in the figure, and follow this procedure.

IMPORTANT Apply power to the power supply and module for at least 10 minutes before calibrating the module. This allows internal temperatures to stabilize and reduces drift errors.



Current meter

1. Double-click the icon to bring up the General parameter dialog.

1734-0E2	C 2 Pt Curre	ent Output (4)		?)
General De	vice Paramete	ers EDS I/O Def	ault	
Ţ	1734-0E2C 2	Pt Current Output		
<u>N</u> ame:	1734-0E2C 3	2 Pt Current Outpu	ıt (4)	
<u>D</u> escription				
Add <u>r</u> ess:	19			
	Device Ider	ntity [Primary]—		
	Vendor:	Rockwell Automa	tion - Allen-Bradl	ey [1]
	Device:	Rockwell Automa	tion miscellaneo	us [115]
	Product:	1734-0E2C 2 Pt (Current Output [2	25]
	Catalog:	1734-0E2C		
	Revision:	1.002		$ \rightarrow $
[0K	Cancel	Apply	Help

- 2. From the General parameter dialog, select Device Parameters tab. The EDS editor dialog appears.
- 3. From the EDS editor dialog, select Upload to load the configuration from the device.

EDS Ed	itor	x		
?	Do you want to upload the configuration from the device, updating the software's configuration; or download the software's configuration to the device, updating the device?			
	For more information, press F1			
	Upload Download Cancel			

4. The Device Parameters dialog appears. From the Groups dropdown list, select Calibration.

□ 1724 0E2C 2 Dt Curront	Outout	(4)		2 \	а	
	output	(4)	_	1	Ľ	
General Device Parameters	EDS I/	0 Default 🗎				
Groups	- On-Lin	e	Upload From	m Device		
1/0 - Output Values	O All	ngle	Download T	o Device		— Groups drondown list
Calibration			<u>S</u> tart Mo	onitor	Π	
PointBus Parameter		Current Va	alue			
🔒 🔒 (0034) Bad Cal Status #	:0	Good Cali	bration		Ш	
💼 🟦 (0035) Bad Cal Status #	1	Good Calibration		Ш		
(0037) Calibration Chann	nel Sel	None				
(0038) Channel 0 Low V	/alue	0 mA			Ш	
(0039) Channel 0 High \	/alue	0 mA			Ш	
(0040) Channel 1 Low V	/alue	0 mA			Ш	
(0041) Channel 1 High \	/alue	0 mA			Ш	
(0042) Calibration Comm	hand	Abort Calib	oration		Ш	
					Ш	
					Ш	
					Ш	
					Ш	
					1	
ОК	Cano	:el	Apply	Help		

- 5. Select Calibration Command from Parameter column and set its value to Begin Calibration.
- 6. Select Download To Device.

Instruction Instruction Bestore Default Values On-Line Bestore Default Values On-Line Parameter Help On-Line				
Parameter	Current Value			
🟦 (0034) Bad Cal Status #0	Good Calibration			
🔒 (0035) Bad Cal Status #1	Good Calibration			
(0037) Calibration Channel Sel	None			
(0038) Channel 0 Low Value	0 mA			
(0039) Channel 0 High Value	0 mA			
(0040) Channel 1 Low Value	0 mA			
(0041) Channel 1 High Value	0 mA			
(0042) Calibration Command	Begin Calibration 🚽			
	Begin Calibration Output Low Reference Output High Reference Finish Calibration Abort Calibration			
OK Can	icel <u>A</u> pply Help			

7. Select Calibration Channel Select from the Parameter column and set its value to a channel which you want to calibrate.

8. Select Download To Device.

🚟 1734-0E2C 2 Pt Current	Output	(4)	? >	
General Device Parameters	EDS I/	0 Default		
Groups Calibration Bestore Default Values Parameter Help	On-Lir © Sir © All	ngle	Upload From Device	
Parameter		Current Va	alue	
🟦 (0034) Bad Cal Status #0)	Calibration FAULT		
🟦 (0035) Bad Cal Status #1		Calibration	FAULT	
(0037) Calibration Channe	el Sel	Channel 0		
(0038) Channel 0 Low Va	alue	0 mA		
(0039) Channel 0 High V	alue	0 mA		
(UU4U) Channel 1 Low Va	alue	Um A		
(0041) Channel T High V.	alue	U mA Da Nathin	-	
(0042) Calibration Comma	ariu	DUNUMIN	<u>y</u>	
OK	Cano	:el	Apply Help	

- 9. Select Calibration Command from the Parameter column and set its value to Output Low Reference.
- 10. Select Download To Device.

The selected channel status indicator flashes green.

1734-0E2C 2 Pt Current Output	(2) ? ×		
General Device Parameters EDS I/	0 Default		
Groups On-Lir Calibration Coline Restore Default Values Coline Parameter Help Coline	ngle Upload From Device Download To Device Start Monitor		
Parameter	Current Value		
🟦 (0034) Bad Cal Status #0	Calibration FAULT		
🟦 (0035) Bad Cal Status #1	Calibration FAULT		
(0037) Calibration Channel Sel	Channel 0		
(0038) Channel 0 Low Value	0 mA		
(0039) Channel 0 High Value	0 mA		
(0040) Channel 1 Low Value	0 mA		
(0041) Channel 1 High Value	0 mA		
(0042) Calibration Command	Output Low Reference		
OK Cano	cel <u>A</u> pply Help		

11. Enter the value shown on your digital voltmeter (DVM) for the Channel Low Value (4.044 in the example).

1734-0E2C 2 Pt Current Out	put (2)	? ×		
General Device Parameters ED	S I/O Default	1		
Groups Calibration Bestore Default Values Parameter Help	h-Line Single All	Upload From Device Download To Device		
Parameter	Current V	alue		
🟦 (0034) Bad Cal Status #0	Calibratio	Calibration FAULT		
🟦 (0035) Bad Cal Status #1	Calibratio	Calibration FAULT		
(0037) Calibration Channel Se	el Channel	0		
(0038) Channel 0 Low Value	4.044 m4	\		
(0039) Channel 0 High Value	0 mA			
(0040) Channel 1 Low Value	0 mA			
(0041) Channel 1 High Value	0 mA			
(0042) Calibration Command	Output L	ow Reference		
OK	Cancel	Apply Help		

- 12. Select Calibration Command from the Parameter column and set its value to Output High Reference.
- 13. Select Download To Device.

🖀 1734-0E2C 2 Pt Current Output	(2)		? ×	
General Device Parameters EDS I/	0 Default			
Groups Calibration	nole	<u>U</u> pload Fi	rom Device	
Bestore Default Values		<u>D</u> ownload	d To Device	
Parameter Help		<u>S</u> tart Monitor		
Parameter	Current Val	Je		
🟦 (0034) Bad Cal Status #0	Calibration I	Calibration FAULT		
🟦 (0035) Bad Cal Status #1	Calibration FAULT			
(0037) Calibration Channel Sel	Channel 1			
(0038) Channel 0 Low Value	4.044 mA			
(0039) Channel 0 High Value	20.231 mA			
(0040) Channel 1 Low Value	4.032 mA			
(0041) Channel 1 High Value	0 mA			
(0042) Calibration Command	Output High	Reference		
	Begin Calibr Output Low Output High Finish Calibr Abort Calibr	ation Reference Reference ation ation		
OK Can	cel	Apply	Help	

- 14. Enter the value shown on the DVM (which is 20.231 in this example) for Channel High Value parameter.
- 15. Repeat these steps for the other channel.
- 16. From the Device Parameters dialog, select All.

Select Calibration Command from Parameter column and set its value to Finish Calibration to complete the calibration process.

17. From the Device Parameters dialog, select Apply.

1734-0E2C 2 Pt Current	Output	(2)	? ×	
General Device Parameters	EDS I/	D Default	l,	
Groups	_ On-Lir	e		
Calibration	C Si	nale	Upload From Device	
Restore Default Values	0.4		Download To Device	
Parameter Help	I AI		<u>S</u> tart Monitor	
Parameter		Current V	'alue	
🟦 (0034) Bad Cal Status #I	0	Calibration FAULT		
🔒 (0035) Bad Cal Status #	1	Calibration FAULT		
(0037) Calibration Chann	hel Sel	Channel 1		
(0038) Channel 0 Low V	alue	4.044 m4		
(0039) Channel 0 High V	/alue	20.231 m	Α 🖉	
(0040) Channel 1 Low V	alue	4.032 m ⁴		
(0041) Channel 1 High V	/alue	20.23 m4		
(0042) Calibration Comm	and	Finish Ca	ibration	
OK	Cano	el	Apply Help	

18. The EDS Editor dialog appears. From the EDS Editor dialog, select Yes to download the configuration to the device.

EDS Edi	tor 🛛
٩	Do you want to download the configuration to the device; updating the device's configuration?
	Yes No Cancel

If calibration is done, the value of the Bad Cal Status reflects Good Calibration.

📓 1734-0E2C 2 Pt Current Output (2)				
General Device Parameters	EDS I/	0 Default		
Groups Calibration	-On-Lir	ne	Upload From Device	
Bestore Default Values		<u>D</u> ownload To De		
Parameter Help	U All		<u>S</u> tart Monitor	
Parameter		Current Val	ue	
🟦 (0034) Bad Cal Status #0)	Good Calib	ration	
🟦 (0035) Bad Cal Status #1	1	Good Calib	ration	

Your module is now calibrated.

To calibrate your voltage input module, connect the module in a DeviceNet system similar to that shown in the below figure.

IMPORTANT Apply power to the power supply and module for at least 10 minutes before calibrating the module. This allows internal temperatures to stabilize and reduces drift errors.

You can calibrate both voltage input channels at the same time using one voltage source.



Calibrate the Analog Voltage Input Module

- 1. Double-click the icon to bring up the General parameter dialog.
- 2. Select Device Parameters to view the parameters.

[©] 1734-IE2V/B	2pt Analog Voltage Input	? ×
General Devic	e Parameters 1/0 Defaults EDS File	
[] 17	34-IE2V/B 2pt Analog Voltage Input	
<u>N</u> ame:	1734-IE2V/B 2pt Analog Voltage Input	
<u>D</u> escription:		
<u>A</u> ddress:	3	
Device Ident	ity [Primary]	
Vendor:	Rockwell Automation - Allen-Bradley [1]	
Device:	Rockwell Automation miscellaneous [115]	
Product:	1734-IE2V/B 2pt Analog Voltage Input [55]	
Catalog:	1734-IE2V/B	
Revision:	2.005	
	OK Cancel Apply He	lp

The EDS Editor dialog appears.

3. From the EDS Editor dialog, select Upload to load the configuration from the device.

EDS Edi	itor 🛛	>
?	Do you want to upload the configuration from the device, updating the software's configuration; or download the software's configuration to the device, updating the device?	
	For more information, press F1	
	Upload Download Cancel	

4. The Device Parameters dialog appears. Select Calibration from the Groups dropdown list.



5. Select Calibration Channel Select from the Parameter column and set its value to a channel you want to calibrate.



6. Select Calibration Command from the Parameter column and set its value to Begin Calibration from the dropdown list.

Select Apply.



- 7. Select Download To Device. Both channel status indicators turn off.
- 8. Apply 0.0V to the input.
- 9. From Device Parameters dialog, change the Calibration Command value to Accept Low Calibration.
- 10. Select Download To Device.

The status indicator for the channel being calibrated flashes.



- 11. Set the voltage source to +10.0V.
- 12. From Device Parameters dialog, change the Calibration Command value to Accept High Calibration.
- 13. Select Download To Device.

Calibration is complete as soon as High and Low calibration for the selected channels are done successfully.

14. Repeat these steps to calibrate the other channels, if necessary.

Both high and low inputs must be accepted in order for the module to finish calibration.

Calibration is now complete. If the module does not accept calibration (the status indicator is still flashing), from the Device Parameters dialog, change the Calibration Command value to Abort Calibration and do this procedure again.

To calibrate your output module, connect the module in a DeviceNet system similar to that shown in the below figure and use this procedure.

IMPORTANT Apply power to the power supply and module for at least 10 minutes before calibrating the module. This allows internal temperatures to stabilize and reduces drift errors.



1. Double-click the icon to bring up the General parameter dialog.

🏁 1734-0E2V/	B 2pt Analog Voltage Output	? X
General Devic	e Parameters 1/0 Defaults EDS File	
17	34-0E2V/B 2pt Analog Voltage Output	
<u>N</u> ame:	1734-OE2V/B 2pt Analog Voltage Output	
<u>D</u> escription:		
<u>A</u> ddress:	2	
Device Ident	ity [Primary]	
Vendor:	Rockwell Automation - Allen-Bradley [1]	-
Device:	Rockwell Automation miscellaneous [115]	
Product:	1734-0E2V/B 2pt Analog Voltage Output [56]	
Catalog:	1734-0E2V/B	
Revision:	2.002	
		_
	OK Cancel Apply He	lp

2. From General parameter dialog, select Device Parameters tab.

Calibrate the Analog Voltage Output Module

3. The EDS Editor dialog appears. From the EDS Editor dialog, select Upload to load the configuration from the device.



4. The Device Parameters dialog appears. Select Calibration from the Groups dropdown list.



5. Select Calibration Channel Select from the Parameter column and set its value to a channel you want to calibrate.

^{같은} 1734-0E2V/	B 2pt Anal	og Voltage Ou	itput	? >
General Devic	e Parameters	I/O Defaults	EDS File	
17	34-0E2V/B 2	2pt Analog Volta	ge Output	
<u>N</u> ame:	1734-01	E2V/B 2pt Analo	g Voltage Outpu	1
Description:				
Address:	2	-		
- Device Ident	tity [Primary]			
Vendor:	Rockwell	Automation - Alle	n-Bradley [1]	
Device:	Rockwell	Automation misc	ellaneous [115]	
Product	1734-DE2	V/B 2pt Analog '	Voltage Output (56]
Catalog:	1734-OE2	V/B		
Revision:	2.002			
	OK	Cancel	Apply	Help

6. Select Calibration Command and set its value to Begin Calibration, then select Apply.

- 173	- 1734-DE2V/B 2pt Analog Voltage Output 🔹 👔						? X	
Gene	ral [)evice	Parameters	I/O Default	s	EDS File		
<u>G</u> rou Cali <u>B</u>	ups ibratio estor <u>P</u> ara	in e Defau ameter H	▼ It Values Help	Online OSingle		Upload Fro Download 1	m Device Fo Device onitor	
ID	Barameter Help 10 3 tot Parameter 34 Bad Cal Status #0 35 Bad Cal Status #1 37 Calibration Channel Select 38 Channel 0 Low Value 39 Channel 0 Low Value 40 Channel 1 Low Value 41 Channel 1 High Value 42 Calibration Command		Current Value Calibration FAI Calibration FAI Channel 0 0 V 0 V 0 V 0 V Begin Calibrati Begin Calibrati Output Low Re Output Low Re	ULT ULT on eference eference	•			
₹						Abort Calibratio	in j	•
			OK	Cancel	1	Apply	Hel	, 1

- 7. Select Download To Device.
 - The channel status indicator turns off.
- 8. Select a channel.
- 9. Select Download To Device.
- 10. Change the Calibration Command value to Output Low Reference, then select Download To Device.

The selected channel status indicator flashes green.

译 1734	1-0E	2¥78	2pt Analo	g Voltage Out	put	? ×
Genera	al C)evice F	^D arameters	1/0 Defaults 1	EDS File	
<u>G</u> rou	ps			Online	Lipland From Dourio	
Calib	oratio	n	_	🔿 Single		
<u>B</u> e	estore	e Defaul	lt Values	(C. All	<u>D</u> ownload To Devic	e
	<u>P</u> ara	ameter H	łelp	C An	<u>S</u> tart Monitor	
ID		012	Parameter		Current Value	
	34	1	Bad Cal S	tatus #0	Calibration FAULT	
	35	î.	Bad Cal S	tatus #1	Calibration FAULT	
	37		Calibration	Channel Select	Channel 0	
	38		Channel O	Low Value	0V	
	39		Channel 0	High Value	0 V	
	40		Channel 1	Low Value	0 V	
	41		Channel 1	High Value	0 V	
	42		Calibration	Command	Output Low Reference	-
					Begin Calibration	
					Output Low Reference Output High Reference Finish Calibration Abort Calibration	
		_				
			ОК	Cancel	<u>Apply</u> H	elp

11. Enter the value shown on your DVM (-10.1234 in the example) for the Channel Low Value.



12. Change the Calibration Command value to Output High Reference, then select Download To Device.

13. Enter the value shown on the DVM (10.0057 in this example) for the Channel High Value.



- 14. Repeat these steps for the other channels.
- 15. From the Device Parameters dialog, select All.

Change the Calibration Command value to Finish Calibration, then select Apply to complete the calibration process.

General Device Parameters]/('oltage Output ? 🗙 O Defaults EDS File
Groups Calibration Restore Default Values Parameter Help	Online C Single <u>U</u> pload From Device <u>D</u> ownload To Device <u>S</u> tart Monitor
ID a series Parameter 34 a Bad Cal Status 35 Bad Cal Status 37 Calibration Cha 38 Channel 0 Low 39 Channel 0 Hig 40 Channel 1 Low 41 Channel 1 Hig 42 Calibration Cor	Current Value \$ #0 Calibration FAULT \$ #1 Calibration FAULT annel Select Channel 0 w Value -10.1234 V h Value 10.0057 V w Value 0 V yblue 0 V mmand Finish Calibration
OK	Cancel <u>A</u> pply Help

The EDS Editor dialog appears.

16. From the EDS Editor dialog, select Yes to download the configuration to the module.



If calibration is done, the Bad Cal Status reflects Good Calibration.

Current Value	
Good Calibration	
Good Calibration	
	Current Value Good Calibration Good Calibration

Your module is now calibrated.

Troubleshoot with the Indicators

Read this chapter for information about troubleshooting with the following indicators:

- Module status
- Network status
- Power indication
- Calibration status
- I/O point status (On/Off/Fault or Diagnostic)

See each module's individual indicators for detailed information.

About Module Diagnostics

All status and diagnostic information (strobed, polled, cyclic, or change of state) is reported back over the network communication adapter. A single point of failure is detected and reported at the module and to the control system.



Network and Module Status Indications

The network and module status indications are the same for all modules.

Module Status Network Status



Network and Module Status Indications

Indication	Probable Cause	Recommended Action	
Module Status			
Off	No power is applied to the device.	Apply power to the device.	
Steady green	The device is operating normally.	None	
Flashing green	The device needs commissioning due to configuration missing, incomplete, or incorrect.	Configure the device properly.	
Flashing red	A recoverable fault is present. The device did not pass the internal test.	 Cycle power to the device. If the condition persists, replace the device. 	
Steady red	An unrecoverable fault - May require device replacement	Replace the device.	
Flashing red/green	The device is in self-test.	None	
Network Status			
Off	 The device is not online. The device has not completed Autobaud detection because there is no network traffic. The device has not completed the dup_MAC_id test. The device is not powered - Check the module status indicator. 	Apply power to the device, wait for the MAC_id to complete, and correct, as needed.	
Flashing green	The device is online but has no connections in the established state.	None - The device is in Idle or Program mode.	
Steady green	The device is online and has connections in the established state.	None	
Flashing red	One or more I/O connections are in a timed-out state.	Check for I/O module failure, and correct, as needed.	
Steady red	Critical link failure is present with a failed communication device. The device has detected an error that prevents it from communicating on the network.	Verify that the adapter and terminal bases are properly installed, and reinstall, as needed.	
Flashing red/green	Communication faulted device - The device has detected a network access error and is in a communication faulted state. The device has received and accepted an Identify Communication Faulted Request - Long protocol message.	Verify that the adapter is properly installed, and reinstall, as needed.	

Troubleshoot Digital Modules

The I/O status indicators provide input and output indications for each module. Individual meanings are indicated in the tables.

1734-IB2, 1734-IB4, 1734-IB4K, 1734-IB8, 1734-IB8K Sink Input Module



Indication	Probable Cause	Recommended Action
I/O Status		
Off	Input is in the Off state.	None
Yellow	Input is in the On state.	None

1734-IB4D Sink Input Module with Diagnostics



Indication	Probable Cause	Recommended Action
I/O Status		
Off	Input is in the Off state.	None
Yellow	Input is in the On state.	None
Red	A short circuit is detected.	Check I/O wiring or terminal base.
Flashing red	Open wire is detected.	Check I/O wiring or terminal base.

1734-0B2E, 1734-0B4E, 1734-0B8E, 1734-0B8EK Source Output Modules



Indication	Probable Cause	Recommended Action
1/O Status		
Off	All outputs are inactive.	None
Yellow	One or more outputs are active and under control.	None
Flashing red	Open circuit is detected - No load (Off state only).	Connect the load or disable no load detection.
Steady red	A short circuit is detected (On state only).	Remove the short or overloaded circuit.

1734-0B2, 1734-0B4, 1734-0B4K, 1734-0B8, 1734-0B8K Source Output Modules



Indication	Probable Cause	Recommended Action
I/O Status		
Off	All outputs are inactive.	None
Yellow	One or more outputs are active and under control.	None

1734-0B2EP Protected Output Module



Probable Cause	Recommended Action	
1/O Status		
All outputs are inactive.	None	
One or more outputs are active and under control.	None	
Open circuit is detected - No load (Off state only).	Connect the load or disable no load detection.	
A short circuit is detected (On state only).	Remove the short or overloaded circuit.	
	Probable Cause All outputs are inactive. One or more outputs are active and under control. Open circuit is detected - No load (Off state only). A short circuit is detected (On state only).	

1734-IV2, 1734-IV4, 1734-IV8, 1734-IV8K Source Input Module



Indication	Probable Cause	Recommended Action
I/O Status		
Off	Input is in the Off state.	None
Yellow	Input is in the On state.	None

1734-0V2E, 1734-0V4E, 1734-0V8E, 1734-0V8EK Protected Sink Output Module



Indication	Probable Cause	Recommended Action
I/O Status		
Off	All outputs are inactive.	None
Yellow	One or more outputs are active and under control.	None
Red	A short circuit is detected (On state only).	Remove the short or overloaded circuit.

1734-0W2, 1734-0W4, 1734-0W4K Relay Output Module

1734-0W2

Relay Output

Module Status

Network Status

Status of Output O

Status of Output 1



1734-0W4, 1734-0W4K

Module Status

Network Status

Relay Output



Indication	Probable Cause	Recommended Action
I/O Status		
Off	Output is Off (contacts open)	None
Yellow	Output is On (contacts closed)	None

1734-0X2 Relay Output Module



Indication	Probable Cause	Recommended Action
I/O Status		
Off	Output is Off	None
Yellow	Output is On	None

1734-IA2, 1734-IA4, 1734-IA4K 120V AC Input Module



Indication	Probable Cause	Recommended Action
I/O Status		
Off	Input is in the Off state.	None
Yellow	Input is in the On state.	None

1734-0A2, 1734-0A4, 1734-0A4K 120/220V AC Output Module



Indication	Probable Cause	Recommended Action
I/O Status		
Off	All outputs are inactive.	None
Yellow	One or more outputs are active and under control.	None

1734-IM2, 1734-IM4 220V AC Input Module



Indication	Probable Cause	Recommended Action
I/O Status		_
Off	Input is in the Off state.	None
Yellow	Input is in the On state.	None

Troubleshoot Analog Modules

Each analog module has I/O indicators to show the status of the inputs/outputs. See the individual module for I/O status information.

1734-IE2C, 1734-IE2CK Analog Current Input Module



Indication	Probable Cause	Recommended Action
Channel Stat	US	
Off	The module is in CAL mode.	None
Steady green	Normal operation is present with channel scanning inputs.	None
Flashing green	The channel is being calibrated.	None
Steady red	No power or major channel fault is present.	Apply field power or replace the module, as needed.
Flashing red	The channel is at the end of the range (0 mA or 21 mA).	Operate within the normal range.

1734-0E2C, 1734-0E2CK Analog Current Output Module



Indication	Probable Cause	Recommended Action		
Channel Stat	Channel Status			
Off	The module is in CAL mode.	None		
Steady green	The channel is actively controlling the outputs.	None		
Flashing green	The channel is calibrating.	None		
Steady red	An unrecoverable fault - May require device replacement	Replace the device.		
Flashing red	No power or open wire is present.	Apply power or verify wiring to load, and correct, as needed.		

1734-IE2V, 1734-IE2VK Analog Voltage Input Module

Module Status	Module
Network Status	Network Status
	Voltage Input
Status of Input O	0
Status of Input 1	1

Indication	Probable Cause	Recommended Action	
Channel Stat	Channel Status		
Off	The module is in CAL mode.	None	
Steady green	Normal operation is present with channel scanning inputs.	None	
Flashing green	The channel is being calibrated.	None	
Steady red	No power or major channel fault is present.	Apply field power or replace the module, as needed.	
Flashing red	The channel is at the end of the range (-0.25V, -10.25V, or +10.25V).	Operate within the normal range.	

1734-0E2V, 1734-0E2VK Analog Voltage Output Module



Indication	Probable Cause	Recommended Action
Channel Status		
Off	The module is in CAL mode.	None
Steady green	Normal operation present with channel actively controlling outputs.	None
Flashing green	The channel is being calibrated.	None
Flashing red	A Low or High Clamp alarm is present.	Operate within the normal range.
Steady red	No field power is present.	Apply the field power.

Troubleshoot I/O **Communication Modules**

The status indicators on the communication modules provide system power and DeviceNet power indications.

1734-PDN DeviceNet Communication Interface Module

System Power DeviceNet Power	

Indicator	Indication	Probable Cause	Recommended Action
System Power	Off	 The device is not active. DeviceNet power is Off, or the DC-DC converter problem is present. 	 Verify that DeviceNet power is On, and apply the power, if needed. Verify that backplane power is not exceeded, and correct, as needed. Replace the module.
	Green	 System power is On. DC-DC converter is active (5V). 	None
DeviceNet Power	Off	 The device is not active. DeviceNet power is Off.	Apply 24V power to the DeviceNet.
	Green	Power is On with 24V present.	None

1734-ADN, 1734-ADNX DeviceNet Adapter

1734-ADN DeviceNet Adapter

1734-ADNX DeviceNet Adapter



Adapter Status

Indication	Probable Cause	Recommended Action
Off	No power is applied to the device.	Apply power to the device.
Steady green	The device is operating normally.	None
Flashing green	The device needs commissioning due to configuration missing, incomplete, or incorrect.	Check the configuration and recommission the adapter.
Flashing red	A recoverable fault is present.	 Make sure that the adapter does not need a FLASH update. Verify that the MAC_id switch has not changed since power-up.
Steady red	An unrecoverable fault - May require device replacement	Replace the adapter.
Flashing red/ green	The device is in self-test.	Wait for the self-test to finish.

DeviceNet Status

Indication	Probable Cause	Recommended Action
Off	 The device is not online. The device has not completed the Dup_MAC_ID test. The device is not powered - Check the module status indicator. 	Apply power to the device, wait for no duplicate MAC_id to complete, and correct, as needed.
Flashing green	The device is online, but has no connections in the established state.	None - The device is in Idle or Program mode.
Steady green	The device is online and has connections in the established state.	None
Flashing red	One or more I/O connections are in a timed-out state.	Check for I/O module failure, and correct, as needed.
Steady red	Critical link failure is present with a failed communication device. The device has detected an error that prevents it from communicating on the network.	Verify that the adapter and terminal bases are properly installed, and reinstall, as needed.
Flashing red/ green	Communication faulted device - The device has detected a network access error and is in a communication faulted state. The device received and accepted an Identify Communication Faulted Request - Long protocol message.	Verify that the adapter is properly installed, and reinstall, as needed.

Subnet and POINTBus Status

Indication	Probable Cause	Recommended Action
Off	 The device is not online. The device has not completed the Dup_MAC_ID test. The device is not powered - Check the module status indicator. 	Check the adapter status indicator to determine if more time is needed to complete the dup_MAC_id test or if the adapter needs to be powered.
Flashing green	The device is online but has no connections in the established state.	None
Steady green	The device is online and has connections in the established state.	None
Flashing red	No scan list is available. I/O module is missing.	1. Make sure all I/O modules are connected and using the correct MAC IDs. 2. Check the Cycling Node Status parameter in RSNetWorx for DeviceNet software.
Steady red	Critical link failure - Failed communication device is present. The device has detected an error that prevents it from communicating on the network.	1. Make sure an I/O module is not using a MAC ID = 0. 2. Make sure that all backplane modules are communicating at the proper communication rate.

System Power

Indication	Probable Cause	Recommended Action
Off	Field power is Off or DC-DC converter problem is present.	1. Verify that field power is On. 2. Verify that backplane power (load current) is not exceeded. 3. Replace the adapter.
Green	System power is On. The DC-DC converter is active (5V).	None

Field Power

Indication	Probable Cause	Recommended Action
Off	Field power is Off.	Turn on the field power.
Green	Power is On with 24V present.	None

1734-ACNR ControlNet Adapter



Module Status

Indication	Probable Cause	Recommended Action
Off	No power is applied to the device.	Apply power to the device.
Alternating red/green	LED power cycle test (module self-test) is present.	None
Flashing red	Recoverable fault has occurred: • Firmware (NVS) update • MAC ID changed • CPU load exceeded	 Complete firmware update. Return the module to correct the node address. Reduce the CPU load.
Steady red	 Unrecoverable fault has occurred: Self-test failure (checksum failure or ramtest failure at power cycle) Firmware fatal error 	Replace the adapter.
Flashing green	Waiting for the connection or ControlNet cable break	Check the cable and make the connection as needed.
Steady green	The module is operating correctly (normal mode).	None

POINTBus Status

Indication	Probable Cause	Recommended Action
Off	The device is not powered - Check the module status indicator.	Apply power to the device.
Alternating red/green	LED power cycle test is present.	None
Flashing red	 Recoverable fault has occurred: At power-up the number of expected modules does not equal the number of modules present A module is missing Node fault (I/O connection timeout) 	 Change chassis size to match the number of modules present. Replace the missing module. Check for I/O Module failure and correct, as needed.
Flashing green	Adapter online with no connections established • Adapter chassis size has not been configured. • The controller is in Program/Idle mode. • ControlNet cable break • Firmware (NVS) update	 Set the adapter chassis size. None Check the cable and connect, as needed. Complete the firmware update.
Steady green	Adapter is online with connections established (normal operation, in run mode).	None
Steady red	An unrecoverable fault has occurred - The adapter is bus off.	 Cycle power to the device. If the condition persists, replace the device.

ControlNet A or B Status

Indication	Probable Cause	Recommended Action
Viewed Together (A and	B)	·
Both steady Off	Reset, no power, or entire network interface deactivated	None or cycle power.
Alternating red/green	Self-test mode is present.	None
Alternating red/Off	Incorrect configuration is present.	Check network address and other ControlNet configuration parameters.
Both steady red	Faulted unit is present.	Cycle power or reset the unit. If the fault persists, contact Allen-Bradley representative or distributor.
Viewed Individually (A o	r B)	·
Steady Off	The channel is disabled.	Program network for redundant media, if necessary.
Flashing red/green	Incorrect network configuration is present.	Cycle power or reset the unit. If the fault persists, contact Allen-Bradley representative or distributor.
Flashing red/Off	 Media fault No other nodes are present on the network. 	 Check media for items such as broken cables, loose connectors, and missing terminators. Add other nodes to the network.
Flashing green/Off	Temporary channel errors are present.The node is not configured to go on line.	Make sure that the configuration manager node is present and working and the selected address is not greater than selected UMAX ⁽¹⁾ .
Steady green	Normal operation - MAC frames are being received without detected errors.	None

(1) The configuration manager node is the node responsible for distributing ControlNet configuration data to all nodes on the network.

System Power

Indication	Probable Cause	Recommended Action
Off	Not active - Field power is Off or DC-DC converter problem is present.	 Verify that field power is On. Verify that backplane power (load current) is not exceeded. Replace the adapter.
Green	System power is On and the DC-DC converter is active (5V).	None

Field Power

Indication	Probable Cause	Recommended Action
Off	Not active - Field power is Off.	Apply power to the device.
Green	Power is On - 24V is present.	None

1734-APB PROFIBUS Adapter



Adapter Status

Indication	Probable Cause	Recommended Action
Off	No power is supplied.Hardware check is in progress.Initialization is in progress.	1. Apply the power. 2. Wait for power self-test to complete.
Green	Operation is normal.	None
Red	Hardware check fault is present.	Replace the device.

PROFIBUS Status

Indication	Probable Cause	Recommended Action
Off	No power is supplied. The bus is offline.	Apply power, verify the network cabling, and correct, as needed.
Steady green	Bus is online (data exchange).	None
Flashing green	Adapter received a CLEAR command from the master.	None
Steady red	Error in PROFIBUS initialization is present. No modules are installed in the backplane.	Verify the configuration, proper installation of modules, and correct, as needed.
Flashing red	1 Hz - Check_Configuration telegram is rejected. The maximum number of POINT I/O modules in master configuration are overridden. 2 Hz - SetPrm telegram is rejected. The first byte in user parameter data does not equal zero. The maximum number of user parameter bytes are overridden.	Check the configuration.

POINTBus Status

Indication	Probable Cause	Recommended Action
Off	 No power is supplied. Hardware check is in progress. Initialization is in progress. 	Apply the power.
Steady green	Normal operation is present.	None
Flashing red	1 Hz - Incorrect POINT I/O module is installed. POINT I/O module is removed from the backplane.	Verify the module installation, no modules removed, and correct, as needed.
Steady red	Critical link failure (BUS_OFF) is present.	Check the network cabling, and correct, as needed.

System Power

Indication	Probable Cause	Recommended Action
Off	System power is not applied.	 Verify that the field power is On. Verify that the backplane power (load current) is not exceeded. Replace the adapter.
Green	System power (5V) is present.	None

Field Power

Indication	Probable Cause	Recommended Action
Off	Field power is not applied.	Apply the field power (24V).
Green	Field power (24V) is applied.	None

1734-AENT EtherNet/IP Adapter



Module Status

Indication	Probable Cause	Recommended Action
Off	No power is applied to the device.	Apply power to the device.
Flashing red/green	LED power cycle test (module self-test) is present.	None
Steady green	The device is operating normally.	None
Flashing red	A recoverable fault has occurred. • Firmware (NVS) update is present. • Address switches have changed.	Complete the firmware update.Verify the address switches.
Steady red	 An unrecoverable fault has occurred. Self-test failure is present (checksum failure, or ramtest failure at power cycle). Firmware fatal error is present. 	Replace the adapter.

POINTBus Status

Indication	Probable Cause	Recommended Action
Off	The device is not powered - Check the module status indicator.	Apply power to the device.
Flashing red/green	LED power cycle test is present.	None
Flashing red	 A recoverable fault occurred: At power cycle the number of expected modules does not equal the number of modules present. A module is missing. Node fault (I/O connection timeout) has occurred. 	 Configure the chassis size. Check for missing module and reinstall as needed. Check for I/O module failure and correct as needed.
Steady red	An unrecoverable fault has occurred - The adapter is bus off.	 Cycle power to the device. If the condition persists, replace the device.
Flashing green	Firmware (NVS) update is in progress.	None
Steady green	Adapter is online with connections established (normal operation, Run mode).	None

System Power

Indication	Probable Cause	Recommended Action
Off	Not active - The field power is Off or DC-DC converter problem is present.	 Verify that power is On, and apply power if needed. Verify that backplane power is not exceeded, and correct, as needed. Replace the adapter.
Green	System power is On. The DC-DC converter is active (5V).	None

Field Power

Indication	Probable Cause	Recommended Action
Off	Not active - The field power is Off.	Apply the field power.
Green	Power is On. 24V is present.	None

Network Activity

Indication	Probable Cause	Recommended Action
Off	No link is established.	Verify the network cabling, and correct, as needed.
Flashing green/Off	Transmit or receive activity is present.	None
Steady green	Link is established.	None

Network Status

Indication	Probable Cause	Recommended Action
Off	The device is not initialized. The module does not have an IP address.	Apply power to the device, verify the IP address, and correct, as needed.
Flashing green	No CIP™ connections are present. The device has an IP address, but no CIP connections are established.	None
Steady green	CIP connections are present. The device is online and has an IP address, and CIP connections are established.	None
Flashing red	One or more CIP connections have timed out.	Check for I/O module failure and controller operation, and correct, as needed.
Steady red	A duplicate IP address is detected.	Verify the IP address setting and correct, as needed.
Flashing red/green	The module is performing a self-test (which only occurs during the power cycle test).	None

Default Data Maps

Read this appendix for a list of default data maps for POINT I/O modules.

For the Default Data Map of	See Page
Digital Modules	•
1734-IB2 Sink Input Module	105
1734-IB4, 1734-IB4K Sink Input Module	106
1734-IB8, 1734-IB8K Sink Input Module	106
1734-IV2 Source Input Module	107
1734-IB4D Sink Input Module with Diagnostics	106
1734-IV4 Source Input Module	107
1734-IV8, 1734-IV8K Source Input Module	107
1734-IA2 Input Module	107
1734-IA4, 1734-IA4K Input Module	107
1734-IM2 Input Module	108
1734-IM4 Input Module	108
1734-OA2 Output Module	108
1734-0A4, 1734-0A4K Output Module	108
1734-OB2E, 1734-OB2 Electronically Protected Output Module	108
1734-0B4E, 1734-0B4, 1734-0B4K Electronically Protected Output Module	109
1734-0B8E, 1734-0B8EK, 1734-0B8, 1734-0B8K Electronically Protected Output Module	109
1734-OB2EP Protected Output Module	110
1734-OV2E Output Module	110
1734-OV4E Output Module	110
1734-0V8E, 1734-0V8EK Output Module	110
1734-OW2 Relay Sink/Source Output Module	111
1734-OW4, 1734-OW4K Relay Sink/Source Output Module	111
1734-OX2 Relay Output Module	111
Analog Modules	
1734-IE2C, 1734-IE2CK Analog Current Input Module	111
1734-IE2V Analog Voltage Input Module	112
1734-0E2C, 1734-0E2CK Analog Current Output Module	112
1734-0E2V, 1734-0E2VK Analog Voltage Output Module	112

Digital Module Default Data Maps

I/O messages are sent to (consumer) and received from (producer) the POINT I/O modules. You map these messages into the processor memory.

1734-IB2 Sink Input Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0
Produce (scanner Rx)	Not use	Not used					Ch1	ChO
Consume (scanner Tx)	No consumed data							
Where:	Ch0 = I	ChO = Input channel 0, Ch1 = Input channel 1; 0 = Off, 1 = On					• On	

1734-IB4, 1734-IB4K Sink Input Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0
Produce (scanner Rx)	Not used				Ch3	Ch2	Ch1	ChO
Consume (scanner Tx)	No consumed data							
Where:	ChO = Input channel 0, Ch1 = Input channel 1, Ch2 = Input channel 2, Ch3 = Input channel 3; 0 = Off, 1 = On					t		

1734-IB8, 1734-IB8K Sink Input Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0
Produce (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO
Consume (scanner Tx)	No consumed data							
Where:	ChO = Input channel 0, Ch1 = Input channel 1, Ch2 = Input channel 2, Ch3 = Input channel 3, Ch4 = Input channel 4, Ch5 = Input channel 5, Ch6 = Input channel 6, Ch7 = Input channel 7; $\Omega = \Omega$ ff, 1 = On							el 2, nel 5,

1734-IB4D Sink Input Module with Diagnostics

Default Data Map - Produced Assembly Instance 101

Message Size: 2 Bytes

	7	6	5	4	3	2	1	0
Produce O (scanner Rx)	Fault 3	Fault 2	Fault 1	Fault O	Input 3	Input 2	Input 1	Input O
Produce 1 (scanner Rx)	SC 3	SC 2	SC 1	SC O	OW 3	0W 2	OW 1	0W 0
Consume (scanner Tx)	No consume	lo consumed data						
Where:	OW = Open w)W = Open wire, SC = Short circuit, Fault = Open wire or short circuit						

Data Map - Produced Assembly Instance 23

Message Size: 1 Byte

	7	6	5	4	3	2	1	0
Produce 0 (scanner Rx)	Fault 3	Fault 2	Fault 1	Fault O	Input 3	Input 2	Input 1	Input O
Consume (scanner Tx)	No consumed data							
Where:	Fault = Open wire or short circuit							

Default Data Map - Configuration Assembly Instance 103

Message Size: 18 Bytes

	•								
	7	6	5	4	3	2	1	0	
Consume O	Input 0 Off to On Filter Byt	te O							
Consume 1	Input 0 Off to On Filter Byt	te 1							
Consume 2	Input 0 On to Off Filter Byt	te O							
Consume 3	Input 0 On to Off Filter Byt	te 1							
Consume 4	Input 1 Off to On Filter Byte	e 0							
Consume 5	Input 1 Off to On Filter Byte	e 1							
Consume 6	Input 1 On to Off Filter Byte	e 0							
Consume 7	Input 1 On to Off Filter Byte	e 1							
Consume 8	Input 2 Off to On Filter Byt	e O							
Consume 9	Input 2 Off to On Filter Byt	:e 1							
Consume 10	Input 2 On to Off Filter Byt	:e 0							
Consume 11	Input 2 On to Off Filter Byt	:e 1							
Consume 12	Input 3 Off to On Filter Byt	:e 0							
Consume 13	Input 3 Off to On Filter Byt	ie 1							
Consume 14	Input 3 On to Off Filter Byt	:e 0							

Default Data Map - Configuration Assembly Instance 103 (Continued)

Message Size: 18 Bytes											
	7	6	5	4	3	2	1	0			
Consume 15	Input 3 On to Off Filter By	nput 3 On to Off Filter Byte 1									
Consume 16	Autobaud Disable				Enable OW3	Enable OW2	Enable OW1	Enable OWO			
Consume 17	Produced Assembly Instar	nce									
Produce (scanner Tx)	No produced data										
Where:	OW = Open wire										

1734-IV2 Source Input Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0		
Produce (scanner Rx)	Not used Ch1 Ch0									
Consume (scanner Tx)	No consumed data									
Where:	ChO = Input channel 0, Ch1 = Input channel 1; 0 = Off, 1 = On									

1734-IV4 Source Input Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Not used				Ch3	Ch1	Ch1	ChO	
Consume (scanner Tx)	No consumed data								
Where:	ChO = Input channel 0, Ch1 = Input channel 1, Ch2 = Input channel 2, Ch3 = Input channel 3; 0 = Off, 1 = On								

1734-IV8, 1734-IV8K Source Input Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0
Produce (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch1	Ch1	ChO
Consume (scanner Tx)	No consumed data							
Where:	ChO = Input channel 0, Ch1 = Input channel 1, Ch2 = Input channel 2, Ch3 = Input channel 3, Ch4 = Input channel 4, Ch5 = Input channel 5, Ch6 = Input channel 6, Ch7 = Input channel 7; 0 = Off, 1 = On							

1734-IA2 Input Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)							Ch1	ChO	
Consume (scanner Tx)	No consumed data								
Where:	ChO = Channel O, Ch1 = Channel 1; O = Off, 1 = On								

1734-IA4, 1734-IA4K Input Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0
Produce (scanner Rx)					Ch3	Ch2	Ch1	ChO
Consume (scanner Tx)	No consumed data							
Where:	ChO = Channel O, Ch1 = Channel 1, Ch2 = Channel 2, Ch3 = Channel 3; O = Off, 1 = On							

1734-IM2 Input Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)							Ch1	ChO	
Consume (scanner Tx)	No consumed data								
Where:	ChO = Channel O, Ch1 = Channel 1; O = Off, 1 = On								

1734-IM4 Input Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0
Produce (scanner Rx)					Ch3	Ch2	Ch1	ChO
Consume (scanner Tx)	No consumed data							
Where:	ChO = Channel 0, Ch1 = Channel 1, Ch2 = Channel 2, Ch3 = Channel 3; 0 = Off, 1 = On							

1734-0A2 Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	No pr	oduce	d data						
Consume (scanner Tx)	Not u	sed	Channel state						
Where:	ChO = Channel O, Ch1 = Channel 1; O = Off, 1 = On								

1734-0A4, 1734-0A4K Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0			
Produce (scanner Rx)	No pr	lo produced data									
Consume (scanner Tx)	Not u	Not used Ch3 Ch2 Ch1 Ch0 Channel st									
Where:	ChO = Channel O, Ch1 = Channel 1; Ch2 = Channel 2, Ch3 = Channel 3; O = Off, 1 = On										

1734-0B2E, 1734-0B2 Electronically Protected Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Not u	ised					Ch1	Ch0	Channel status (1734-0B2E only)
Where:	0 = N 1 = Ei	o erro ror	r						

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Not used						Ch1	ChO	Channel state
Where:	0 = Off 1 = On								
1734-0B4E, 1734-0B4, 1734-0B4K Electronically Protected Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Not used				Ch3	Ch2	Ch1	ChO	Channel status (1734-0B4E only)
Where:	0 = 1 1= E	No er irror	ror						

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Not use	ed			Ch3	Ch2	Ch1	ChO	Channel state
Where:	0 = Off 1 = On								

1734-0B8E, 1734-0B8EK, 1734-0B8, 1734-0B8K Electronically Protected Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Channel status (1734-0B8E and 1734-0B8EK only)
Where:	0 = No 1 = Erro	error or							

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Channel state
Where:	0 = Off 1 = On								

1734-0B2EP Protected Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Not u	sed					Ch1	ChO	Channel status
Where:	0 = N 1 = Er	o erroi ror							

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Not us	sed					Ch1	ChO	Channel state
Where:	0 = Of 1 = On	f							

1734-0V2E Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Not u	sed					Ch1	ChO	Channel status
Where:	0 = N 1 = Er	o erro ror	r						

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Not u	sed					Ch1	ChO	Channel state
Where:	0 = 0 1 = 0r	ff							

1734-0V4E Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Not u	sed			Ch3	Ch2	Ch1	ChO	Channel status
Where:	0 = No 1 = Er	o error ror							

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Not us	sed			Ch3	Ch2	Ch1	ChO	Channel state
Where:	0 = 0f 1 = 0n	f							

1734-0V8E, 1734-0V8EK Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Produce (scanner Rx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Channel status
Where:	0 = No 1 = Err	o error or							

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Ch7	Ch6	Ch5	Ch4	Ch3	Ch2	Ch1	ChO	Channel state
Where:	0 = N 1 = Er	o erro ror	or						

1734-OW2 Relay Sink/Source Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Not us	sed					Ch1	ChO	Channel state
Where:	0 = 0f 1 = 0n	f							

1734-0W4, 1734-0W4K Relay Sink/Source Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Not us	sed			Ch3	Ch2	Ch1	ChO	Channel state
Where:	0 = Of 1 = On	f							

1734-0X2 Relay Output Module

Message Size: 1 Byte

	7	6	5	4	3	2	1	0	
Consume (scanner Tx)	Not us	Not used						ChO	Channel state
Where:	0 = NO contact Off, NC contact On 1 = NO contact On, NC contact Off								

Analog Module Default Data Maps

I/O messages are sent to (consumer) and received from (producer) the POINT I/O modules. You map these messages into the processor memory.

1734-IE2C, 1734-IE2CK Analog Current Input Module

Message Size: 6 Bytes

	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
	Input	t Chan	nel O Hig	h Byte	;				Input	t Chan	nel O Lo	ow Byt	e			
Produce	Input	t Chan	nel 1 Higl	h Byte					Input	t Chan	nel 1 Lo	w Byte	;			
(scanner Rx)	Statu	Status Byte for Channel 1 Status Byte for Channel 0														
	OR	OR UR HHA LLA HA LA CM CF OR UR HHA LLA HA LA CM											CF			
Consume (scanner Tx)	No co	lo consumed data														
Where:	CF = CM = LA = HA = LLA = HHA = UR = OR =	Chann Calibr Low A High A = Low/ = High Under Overra	el Fault : ation Mo larm; 0 = larm; 0 = Low Alar /High Ala range; 0 =	status de; 0 No er No e m; 0 arm; 0 = No e No er	; 0 = 1 = Norr rror, 1 rror, 1 = No e = No error, 1 ror, 1	No erro mal, 1 = = Fauli = Faul rror, 1 error, 1 1 = Faul = Faul	or, 1 = t t = Faul 1 = Fau 1 = Fau ult	Fault pration t ult	ı mode	!						

Channel Status

Channel St	Channel Status Bytes										
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit O				
Overrange	Underrange	High High Alarm	Low Low Alarm	High Alarm	Low Alarm	CAL Mode	Channel Fault				

1734-IE2V Analog Voltage Input Module

Message Size: 6 Bytes

	15	14	13	12	11	10	09	80	07	06	05	04	03	02	01	00
	Input	t Chai	nnel O I	ligh E	Byte				Inpu	t Cha	nnel O	Low E	yte			
Produce (scanner Ry)	Input	t Chai	nnel 1 H	igh B	yte				Inpu	t Cha	nnel 1 l	Low B	yte			
	Statu	us Byt	e for C	hann	el 1				Stat	us By	te for C	Chann	el O			
	OR	UR	HHA	LLA	HA	LA	CM	CF	OR	UR	HHA	LLA	HA	LA	CM	CF
Consume (scanner Tx)	No c	o consumed data														
Where:	CF = CM = LA = HA = LLA = HHA = UR = OR =	Chan Calib Low High = Low = Hig Unde Over	nel Fau tration Alarm; (Alarm; (Alarm; /Low A h/High errange; (range; (lt sta Mode) = No 0 = N larm; Alarm; ; 0 = No) = No	tus; 0 ; 0 = 1 o erro o erro 0 = N n; 0 = No erro o erro	l = No Norma r, 1 = or, 1 = lo erra No er nor, 1 ror, 1 =	error al, 1 = Fault Fault or, 1 = ror, 1 = Faul Fault	; 1 = F Calibr Fault = Fau It	ault ation	mod	9					

1734-0E2C, 1734-0E2CK Analog Current Output Module

Message Size: 4 bytes

	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Consume (Tx)	Outpu	ut Cha	nnel O	High	Byte				Output Channel O Low Byte							
	Outpu	ut Cha	nnel 1	High E	3yte				Outpu	ut Cha	nnel 1	Low E	Byte			

Message Size: 2 Bytes

	15	14	13	12	11	10	09	80	07	06	05	04	03	02	01	00			
Produce (Rx)	High	n Byte	e Cha	nnel	1 Statu	S			Low	Byte	Cha	hannel O Status							
	Not	used			HCA	LCA	CM	CF	Not	used		HCA LCA CM CI							
Where:	CF = CM = LCA HCA	= Cha = Cali = Lo [,] = Hio	nnel brati w Cla gh Cl	Fault on M mp <i>I</i> amp	: status ode; 0 Alarm; (Alarm;	;; 0 = N = Norr) = No 0 = No	lo erro nal, 1 = error, error,	r, 1 = Calil 1 = Fa 1 = F	Faul bratio ault ault	t on m	ode								

Channel Status

Channel St	atus Bytes						
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit O
Not used				High Clamp	Low Clamp	CAL Mode	Channel Fault

1734-0E2V, 1734-0E2VK Analog Voltage Output Module

Message Size: 4 bytes

	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Consume (scanner Tx)	Outpu	utput Channel O High Byte									nanne	el O Li	ow By	/te		
	Outpu	Jutput Channel 1 High Byte								out Cl	nanne	el 1 Lo	ow By	te		

Message Size: 2 Bytes

	15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00
Produce (scapper Py)	Channel 1 Status High Byte Channel 0 Status Low Byte															
	Not	used			HCA	LCA	CM	CF	Not	ot used HCA LCA CM CF						CF
Where:	CF = CM = LCA HCA	Char Calil = Lov = Hig	nnel F bratic v Clar ıh Cla	ault s n Moo np Ala mp Al	tatus; de; 0 = arm; 0 arm; 0 arm; 0	0 = No Norma = No er = No e	error II, 1 = ror, 1 rror, 7	, 1 = F Calib = Fai 1 = Fa	ault ratior ult ult	n mod	le					

Mounting Dimensions

Read this appendix for mounting dimensions for the following:

- POINT I/O module with a 1734-ADN, 1734-ACNR, 1734-AENT, or 1734-APB adapter
- POINT I/O module with a 1734-PDN module
- POINTBlock I/O modules

See the figure for mounting dimensions for a POINT I/O module with a network adapter. The example figure shows a 1734-ADN adapter.



Secure DIN rail to mounting surface approximately every 200 mm (7.8 in.).

POINT I/O Module with a 1734-ADN, 1734-ACNR, 1734-AENT, or 1734-APB Adapter

POINT I/O Module with a 1734-PDN Module

See the figure for mounting dimensions for POINT I/O module with a 1734-PDN DeviceNet Communication Interface module.



Secure DIN rail to mounting surface approximately every 200 mm (7.8 in.).

POINTBlock Module

See the figure for mounting dimensions for a 1734D POINTBlock module. L = $60.0 + [\# \text{ of } I/0 \times 12.0] + [\# \text{ of FPD} \times 25.4] \text{ mm}$



Secure DIN rail to mounting surface approximately every 200 mm (7.8 in.).

Notes:

Numerics

1734D-IA16 module about 11 1734D-IA8X0A8 module about 11 1734D-IA8X0W8 module about 11 1734D-IB16 module about 11 1734D-IB8X0B module about 11 1734D-IB8X0W8 module about 11 1734-IA2 module about 11 default data map 107 troubleshoot 93 1734-IA4, 1734-IA4K module about 11 default data map 107 troubleshoot 93 1734-IB2 module about 11 default data map 105 troubleshoot 89 1734-IB4, 1734-IB4K module about 11 default data map 106 troubleshoot 89 1734-IB4D module about 11 default data map 106 troubleshoot 89 1734-IB8, 1734-IB8K module about 11 default data map 106 troubleshoot 89 1734-IE2C, 1734-IE2CK module about 13 default data map 111 troubleshoot 95 1734-IE2V module about 13 default data map 112 1734-IE2V, 1734-IE2VK module troubleshoot 96 1734-IM module about 11 default data map 108 troubleshoot 94 1734-IV2 module about 11 default data map 107 troubleshoot 91 1734-IV4 module about 11 default data map 107 troubleshoot 91

1734-IV8, 1734-IV8K module about 11 default data map 107 troubleshoot 91 1734-0A2 module about 11 default data map 108 troubleshoot 94 1734-0A4, 1734-0A4K module about 11 default data map 108 troubleshoot 94 1734-0B2 module about 11 default data map 108 troubleshoot 90 1734-0B2E module about 11 default data map 108 troubleshoot 90 1734-0B2EP module about 11 default data map 110 troubleshoot 91 1734-0B4, 1734-0B4K module about 11 default data map 109 troubleshoot 90 1734-0B4E module about 11 default data map 109 troubleshoot 90 1734-0B8, 1734-0B8K module about 11 default data map 109 troubleshoot 90 1734-0B8E, 1734-0B8EK module about 11 default data map 109 troubleshoot 90 1734-0E2C, 1734-0E2CK module about 13 default data map 112 troubleshoot 95 1734-0E2V, 1734-0E2VK module about 13 default data map 112 troubleshoot 97 1734-0V2E module about 11 default data map 110 troubleshoot 92 1734-0V4E module about 11 default data map 110 troubleshoot 92 1734-0V8E, 1734-0V8EK module about 11 default data map 110 troubleshoot 92

1734-0W2 module about 11 default data map 111 troubleshoot 92 1734-0W4, 1734-0W4K module about 11 default data map 111 troubleshoot 92 1734-0X2 module about 11 default data map 111 troubleshoot 93

A

about analog input modules 13 analog output modules 14 digital input modules 11 digital output module 12 relay output modules 12 alarm 60, 61 configuration dialog 27 disable 60, 65 latch 60 analog input modules 13, 58 modules 13, 58, 62, 71 output modules 14, 62

C

calibrating analog current input module 72 analog current output module 75 analog modules 71 analog voltage input module 79 analog voltage output module 82 calibration dialog 28, 32 instruments 71 status bit 60 status indicators 87 channel indicator states 62, 66 channel status analog input modules 59 analog output modules 64 clamps cage 66 high 14, 51, 65 low 14, 51, 65 spring 66 commissioning nodes 35 tool 35 configure analog modules using RSLogix 5000 software 24 configure digital modules using RSLogix 5000 software 17 using RSNetWorx software 36 configure the module 53 **ControlNet network** 7, 35

D

data maps 53, 105 - 112 default data maps 53, 105 - 112 DeviceNet network 7, 35 diagnostics, module 87 digital ac input modules 55 ac output modules 57 dc input modules 53 dc output modules 55 filter 61

dimensions for mounting 113 disable alarms 60, 65

E

EDS, electronic data sheet 35, 36 electronic data sheet 35 EtherNet/IP network 7, 35

F

fault and idle mode state 64 filter notch 26, 61

H

high alarm 27, 31, 61 high high alarm 27, 61

I

indicators, LED 87

L

latch alarms 60, 65 LED indicators 87 low alarm 27, 31, 61 low low alarm 27, 61

M

module status 53 module diagnostics 87 module status indicator 87 mounting

> dimensions POINT I/O module with a 1734-ADN adapter 113 dimensions POINT I/O module with a 1734-PDN DeviceNet Communication Interface module 114 dimensions POINTBlock module 115

N

network DeviceNet 35 PROFIBUS 7 network status indicator 87 node commissioning tool 35 notch filter 26, 61

0

over range status 62

Ρ

POINTBus 36 power indicator 87 PROFIBUS network 7

R

range status 62 relay module 12 output modules 57 RSNetWorx software 35 for DeviceNet node commissioning tool 35

S

SAA, sequential auto addressing 36 scaling analog input modules 59 analog output modules 64 sequential auto addressing 36 specialty modules 14

Τ

third party configuration software 36

troubleshoot

1734-ACNR adapter 100 1734-ADN adapter 98 1734-AENT adapter 103 1734-APB adapter 102 1734-IA2 module 93 1734-IB2 module 89 1734-IB4, 1734-IB4K module 89 1734-IB8, 1734-IB8K module 89 1734-IE2C, 1734-IE2CK module 95 1734-IE2V module 96 1734-IM2 module 94 1734-IV2 module 91 1734-IV4 module 91 1734-IV8, 1734-IV8K module 91 1734-0A2 module 94 1734-0B2 module 90 1734-0B2EP module 91 1734-0B4, 1734-0B4K module 90 1734-0B4E module 90 1734-0B8, 1734-0B8K module 90 1734-0B8E, 1734-0B8EK module 90 1734-0E2C, 1734-0E2CK module 95 1734-0E2V, 1734-0E2VK module 97 1734-0V2E module 92 1734-0V4E module 92 1734-0W2 module 92 1734-0W4, 1734-0W4K module 92 1734-0X2 module 93 analog modules 95 digital modules 89 I/Ó communications modules 97

U

under range status 62 update rate 61

Notes:

Rockwell Automation Support

Use these resources to access support information.

Technical Support Center	Find help with how-to videos, FAQs, chat, user forums, Knowledgebase, and product notification updates.	<u>rok.auto/support</u>
Local Technical Support Phone Numbers	Locate the telephone number for your country.	rok.auto/phonesupport
Technical Documentation Center	Quickly access and download technical specifications, installation instructions, and user manuals.	rok.auto/techdocs
Literature Library	Find installation instructions, manuals, brochures, and technical data publications.	<u>rok.auto/literature</u>
Product Compatibility and Download Center (PCDC)	Download firmware, associated files (such as AOP, EDS, and DTM), and access product release notes.	rok.auto/pcdc

Documentation Feedback

Your comments help us serve your documentation needs better. If you have any suggestions on how to improve our content, complete the form at <u>rok.auto/docfeedback</u>.

Waste Electrical and Electronic Equipment (WEEE)



At the end of life, this equipment should be collected separately from any unsorted municipal waste.

Rockwell Automation maintains current product environmental compliance information on its website at rok.auto/pec.

Allen-Bradley, expanding human possibility, FactoryTalk, Logix 5000, POINT I/O, POINTBus, RSNetWorx, RSNetWorx for DeviceNet, RSLogix 5000, Rockwell Automation, Studio 5000 Logix Designer, and TechConnect are trademarks of Rockwell Automation, Inc.

CIP, ControlNet, DeviceNet, and EtherNet/IP are trademarks of ODVA, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş. Kar Plaza İş Merkezi E Blok Kat:6 34752, İçerenköy, İstanbul, Tel: +90 (216) 5698400 EEE Yönetmeliğine Uygundur

Connect with us. 存 🞯 in 🗙

rockwellautomation.com

expanding human possibility°

AMERICAS: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204–2496 USA, Tel: (1) 414.382.2000 EUROPE/MIDDLE EAST/AFRICA: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2663 0600 ASIA PACIFIC: Rockwell Automation SEA Pte Ltd, 2 Corporation Road, #04–05, Main Lobby, Corporation Place, Singapore 618494, Tel: (65) 6510 6608 UNITED KINGDOM: Rockwell Automation Ltd., Pitfield, Kiln Farm, Milton Keynes, MK11 3DR, United Kingdom, Tel: (44)(1908) 838–800

Publication 1734-UM001F-EN-P - August 2024

Supersedes Publication 1734-UM001E-EN-P - July 2013